Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Easytry123 Replacement Remote for Linsar 42LED808 and Telefunken RC4875

Easytry123 Replacement Remote Control User Manual

For Linsar 42LED808 and Telefunken RC4875 LCD LED HDTV Televisions

Introduction

This manual provides instructions for the Easytry123 replacement remote control, designed for use with Linsar 42LED808 and Telefunken RC4875 LCD LED HDTV televisions. This remote is a direct replacement and does not require programming or setup codes. Please ensure your TV model is listed for compatibility.

Setup

1. Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, pushing it until it clicks securely into place.



Image: Rear view of the remote control with the battery cover removed, revealing the slots for two AAA batteries. This illustrates the correct orientation for battery insertion.

2. Initial Use

This replacement remote control is designed for immediate use with compatible Linsar 42LED808 and Telefunken RC4875 televisions. No programming, setup codes, or synchronization steps are required. Simply install the batteries and point the remote towards your television to begin operation.

Operating Instructions

The remote control features standard television functions. Below is a general guide to common button functions. Refer to your television's original manual for specific functions of advanced buttons.



Image: Front view of the remote control, displaying its full layout of buttons including power, number pad, volume, channel, menu, navigation, and media controls.

- **Power (Red Button):** Turns the television on or off.
- **Number Pad (0-9):** Selects channels directly.
- **Volume (+V / -V):** Increases or decreases the audio volume.
- **Channel (+P / -P):** Changes channels up or down.
- **Mute (Speaker with X):** Mutes or unmutes the television audio.
- **Menu:** Accesses the television's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate through menus and confirm selections.
- **Exit:** Exits the current menu or on-screen display.
- **Back:** Returns to the previous screen or menu.
- **Source/Input:** Changes the input source (e.g., HDMI 1, AV).
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback if supported by the TV.

Note: While this remote is a functional replacement, some advanced or specific functions present on your original TV remote may not be fully supported or mapped identically. Please test all functions to ensure compatibility with your specific television model.

Maintenance

Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not spray cleaner directly onto the remote.
- Avoid using harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or

internal components.

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Troubleshooting

- **Remote not responding:**
  - Ensure the remote is pointed directly at the TV's infrared sensor.
  - Check if the batteries are installed correctly with the correct polarity (+/-).
  - Replace the batteries with fresh AAA batteries.
  - Remove any obstructions between the remote and the TV.
- **Some functions do not work:**
  - This replacement remote may not support all advanced functions of your original TV remote. Verify if the specific function is available on this remote's button layout.
  - Ensure your TV model (Linsar 42LED808 or Telefunken RC4875) is explicitly listed as compatible. This remote is not a universal remote.
- **Remote works intermittently:**
  - Batteries may be low. Replace them.
  - Ensure there is no strong light source (like direct sunlight or bright fluorescent lights) interfering with the infrared signal.

Specifications

Brand	Easytry123
Compatible Devices	Linsar 42LED808, Telefunken RC4875 LCD LED HDTV Televisions
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Special Feature	Ergonomic
Batteries Required	2 x AAA (not included)

Warranty Information

Specific warranty details for this Easytry123 replacement remote control are not provided in the product information. Please refer to the retailer's return policy or contact the seller directly for warranty inquiries.

Customer Support

For further assistance or questions regarding your Easytry123 replacement remote control, please contact the seller

or retailer from whom you purchased the product. Please have your purchase details ready when contacting support.

© 2026 Easytry123. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07W47K4WF

More documents and user manuals: **https://manuals.plus/**