Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

havit HV M66 CR/CV

Havit M66 Waterproof Outdoor Bluetooth Speaker User Manual

Model: HV M66 CR/CV | Brand: Havit

1. Introduction

Thank you for choosing the Havit M66 Waterproof Outdoor Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual carefully before using the product and retain it for future reference.

2. Product Overview

The Havit M66 is a durable, portable Bluetooth speaker designed for outdoor use, featuring waterproof capabilities and high-quality stereo sound. Its compact design and robust construction make it ideal for various environments.



Figure 1: Front View. This image displays the front of the Havit M66 speaker, highlighting its robust speaker grille and the distinctive black body with orange accents.



Figure 2: Top Panel Controls. Illustrated here are the control buttons located on the top surface of the speaker, including buttons for track navigation, play/pause, and power.



Figure 3: Side Panel with Ports. This view shows the side of the speaker with a protective cover over the USB charging port and AUX input, designed to maintain its waterproof integrity.



Figure 4: Product Packaging. The retail packaging for the Havit M66 speaker, displaying the brand logo, product image, and key features such as its IPX7 waterproof rating.

3. Setup

3.1 Charging the Speaker

1. Connect the provided USB charging cable to the speaker's charging port (located under the protective flap on the side, refer to Figure 3).
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Allow approximately 3-4 hours for a full charge.
4. Once fully charged, the indicator light will change or turn off, depending on the model.

3.2 Bluetooth Pairing

1. Ensure the speaker is fully charged before first use.
2. Press and hold the Power button (refer to Figure 2) for 3 seconds to turn on the speaker. A power-on tone will sound, and the Bluetooth indicator light will flash rapidly, indicating pairing mode.
3. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select 'Havit M66' from the list of found devices. If prompted for a password, enter '0000'.
5. Once successfully paired, the speaker will emit a confirmation tone, and the Bluetooth indicator light will stop flashing and remain solid.
6. The speaker is now ready to play audio from your device.

4. Operating Instructions

4.1 Power On/Off

- **Power On:** Press and hold the Power button for 3 seconds.
- **Power Off:** Press and hold the Power button for 3 seconds.

4.2 Music Playback

- **Play/Pause:** Press the Play/Pause button (refer to Figure 2) once.
- **Next Track:** Press the Next Track button once.
- **Previous Track:** Press the Previous Track button once.
- **Volume Control:** Volume is controlled via your connected Bluetooth device.

4.3 Answering Calls

- When a call comes in, the speaker will ring.
- **Answer Call:** Press the Play/Pause button once to answer.
- **End Call:** Press the Play/Pause button once during a call to end it.
- **Reject Call:** Press and hold the Play/Pause button for 2 seconds to reject an incoming call.

4.4 AUX Mode

- Connect a 3.5mm audio cable (not included) from your audio source to the AUX port on the speaker (refer to Figure 3).
- The speaker will automatically switch to AUX mode.
- Control playback and volume directly from your audio source device.

5. Maintenance

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure the charging port and AUX port covers are securely closed when not in use, especially in wet environments, to maintain waterproof integrity.
- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping the speaker or subjecting it to strong impacts.
- If the speaker will not be used for an extended period, charge it fully every 3 months to preserve battery life.

6. Troubleshooting

Q: Speaker does not turn on.

A: Ensure the speaker is fully charged. Connect it to a power source and allow it to charge for at least 30 minutes before attempting to power on again.

Q: Cannot pair the speaker with my device.

A: Ensure the speaker is in pairing mode (Bluetooth indicator flashing rapidly). Make sure Bluetooth is enabled on your device and it is within range (up to 10 meters). Try restarting both the speaker and your device. Clear previous Bluetooth connections on your device if necessary.

Q: No sound or low volume.

A: Check the volume level on both the speaker (via your connected device) and your audio source. Ensure the speaker is properly paired. If using AUX mode, ensure the cable is fully inserted and functional.

Q: Sound distortion.

A: Move the speaker closer to your Bluetooth device to reduce interference. Ensure the speaker is not overcharged or undercharged. Try playing a different audio file to rule out source issues.

Q: Water ingress despite being waterproof.

A: Ensure all port covers are securely sealed before exposure to water. The speaker is designed to be waterproof, but not for prolonged submersion beyond its IPX7 rating (up to 1 meter for 30 minutes). Do not expose to saltwater or chemicals.

7. Specifications

Feature	Detail
Brand	Havit
Model Number	HV M66 CR/CV
Connectivity Technology	Bluetooth
Audio Output Mode	Stereo
Mounting Type	Tabletop
Material	Iron

Feature	Detail
Product Dimensions	145 x 100 x 65 cm
Waterproof Rating	IPX7
Manufacturer	Havit
First Available Date	7 August 2019

8. Warranty and Support

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Havit website. Keep your proof of purchase for any warranty claims.

For further assistance, please contact Havit customer service through their official channels.

© 2024 Havit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07W5QK8RT

More documents and user manuals: **https://manuals.plus/**