Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pulsar EE3433BLKACTCO

Pulsar EE3433BLKACTCO Crystal Can Bluetooth Speaker User Manual

Model: EE3433BLKACTCO

Introduction

The Pulsar Crystal Can Bluetooth Speaker (Model EE3433BLKACTCO) is a portable audio device designed to deliver clear sound with dynamic LED light effects. This speaker features Bluetooth connectivity for wireless audio streaming from your smartphone or tablet, and an auxiliary input for wired connections. Its compact design and rechargeable battery make it ideal for use in various settings.



Image: The Pulsar Crystal Can Bluetooth Speaker displaying purple LED lights, positioned next to a smartphone.

Package Contents

Please check the box for the following items:

- Pulsar Crystal Can Bluetooth Speaker (EE3433BLKACTCO)
- USB Charging Cable
- 3.5mm AUX Audio Cable
- User Manual (this document)



Image: Retail packaging for the Pulsar Crystal Can Bluetooth Speaker, showing product features and branding.

Controls and Indicators

Familiarize yourself with the speaker's controls located on the bottom panel:



Image: The bottom panel of the speaker, displaying the power switch, volume/track controls, light mode button, and charging/AUX ports.

1. Power Switch (ON/OFF): Slide to turn the speaker on or off.

2. '+' Button: Press to increase volume. Press and hold to skip to the next track.

3. '-' Button: Press to decrease volume. Press and hold to skip to the previous track.

4. Light Mode Button (Bulb icon): Press to cycle through the 6 different LED light modes, including the LED Galaxy effect.

5. Play/Pause Button: Press to play or pause audio playback.

6. Charging Port: Connect the USB charging cable here.

7. AUX Input: Connect the 3.5mm AUX audio cable for wired connections.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the small end of the USB charging cable to the speaker's charging port and the larger end to a USB power adapter (not included) or a computer's USB port. The LED indicator (if present, usually near the charging port) will show charging status and turn off when fully charged. A full charge takes approximately 3 hours and provides up to 4 hours of playback.

2. Powering On/Off

Slide the **Power Switch** on the bottom of the speaker to the "ON" position to turn it on. Slide it to "OFF" to power down the speaker.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and within 10 meters (33 feet) of your Bluetooth device.
2. The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing LED light (color may vary).
3. On your smartphone or tablet, go to the Bluetooth settings menu.
4. Search for available devices and select "Pulsar Crystal" or "EE3433BLKACTCO" from the list.
5. Once paired, the speaker will emit an audible confirmation tone, and the LED light will stop flashing.
6. The speaker will automatically reconnect to the last paired device when powered on, if the device is within range and Bluetooth is enabled.

4. AUX Connection

For devices without Bluetooth, or if you prefer a wired connection:

1. Connect one end of the 3.5mm AUX audio cable to the AUX input port on the speaker.
2. Connect the other end of the AUX cable to the headphone jack or audio output of your device.
3. The speaker will automatically switch to AUX mode.

Operating

Playing Audio

- **Bluetooth Mode:** After successful pairing, start playing music on your connected device. The audio will stream through the speaker.
- **AUX Mode:** Once connected via the AUX cable, start playing music on your device.

Volume Control

Press the **'+'** button to increase volume and the **'-'** button to decrease volume. You can also adjust the volume directly from your connected device.

Track Control (Bluetooth Mode Only)

- Press the **Play/Pause** button to pause or resume playback.
- Press and hold the **'+'** button to skip to the next track.
- Press and hold the **'-'** button to go to the previous track.

LED Light Modes

Press the **Light Mode Button** (bulb icon) on the bottom of the speaker to cycle through the 6 available light modes. These modes include various colors and effects, such as the LED Galaxy effect.



Image: Speaker displaying blue LED lights.



Image: Speaker displaying green LED lights.



Image: Speaker displaying red LED lights.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Recharge it regularly, even if not in use for extended periods.
- **Water Resistance:** This speaker is **not waterproof**. Avoid exposure to water or excessive moisture.

Troubleshooting

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB charging cable.
No sound from the speaker.	◦ Increase the volume on both the speaker and your connected device. ◦ Ensure the speaker is correctly paired via Bluetooth or connected via AUX cable. ◦ If using Bluetooth, try unpairing and re-pairing the device.
Bluetooth pairing fails.	◦ Ensure the speaker is in pairing mode (flashing LED). ◦ Make sure Bluetooth is enabled on your device. ◦ Move the speaker closer to your device (within 10 meters). ◦ Turn off other Bluetooth devices nearby to avoid interference. ◦ Restart both the speaker and your Bluetooth device.
LED lights are not working.	Press the Light Mode Button to cycle through the modes. Ensure the speaker is powered on.

Specifications

Model Name	EE3433BLKACTCO
Brand	Pulsar
Connectivity Technology	Bluetooth, Auxiliary
Speaker Output Power	3 Watts
Audio Output Mode	Stereo
Special Features	360 LED lights, Bluetooth Compatible, LED Light Effects, Rechargeable
Recommended Uses	For smartphone or tablet
Compatible Devices	MP3 Player, Smartphone, Tablet
Color	Black
Average Battery Life	4 hours
Charging Time	3 hours
Waterproof	No
Maximum Range	10 Meters
Control Method	Application (Note: Manual buttons are also present)
Speaker Size	13.5 Centimeters (Height)
Number of Audio Channels	2.0

Warranty and Support

This Pulsar product comes with a**Limited Warranty**. Please refer to the warranty card included in your package for specific terms and conditions.
For technical support or warranty claims, please contact your retailer or the manufacturer directly. Keep your proof of purchase for warranty service.

© 2023 Pulsar. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07W7F7CZ7

More documents and user manuals: **https://manuals.plus/**