LEGO 70428

LEGO Hidden Side Jack's Beach Buggy 70428 Instruction Manual

Brand: LEGO

Model: 70428

Introduction

The LEGO Hidden Side Jack's Beach Buggy 70428 set offers a unique play experience by merging physical LEGO building with an augmented reality (AR) app. This manual provides instructions for assembly, operation, and care of your product.

Key Features

- Combines physical LEGO building with an augmented reality (AR) app for interactive play.
- The beach buggy reveals a digital ghost world when viewed through a smart device with the free LEGO AR app.
- Includes Jack, Parker, and possessed mechanic Scott Francis minifigures.
- Designed for ages 7 and up.
- When built, the model measures over 3" (10cm) high, 4" (11cm) long, and 3" (8cm) wide.

Setup and Assembly

1. Building the LEGO Model

Follow the step-by-step instructions provided in the physical building guide included with your LEGO set. Ensure all 170 pieces are accounted for before beginning assembly.



Image: The fully assembled LEGO Jack's Beach Buggy set, featuring the buggy, three minifigures, and a gas pump accessory.

2. App Installation

To access the augmented reality features, download the free LEGO Hidden Side AR app from your smart device's app store. Ensure your device meets the minimum system requirements for AR functionality.

Your browser does not support the video tag.

Video: An official video demonstrating the LEGO Hidden Side Jack's Beach Buggy 70428 set, including its assembly and augmented reality app integration. The video shows how to build the set, interact with the minifigures, download the app, and experience the AR gameplay in both single-player and multiplayer modes.

Operating the Augmented Reality Experience

1. Activating AR Play

Launch the LEGO Hidden Side AR app on your smart device. Position your device's camera over the assembled Jack's Beach Buggy model. The app will scan the model and bring the digital ghost world to life on your screen.



Image: A hand holding a smartphone, showing the LEGO Hidden Side AR app overlaying digital elements onto the physical Jack's Beach Buggy set, creating an augmented reality scene.

2. Gameplay Modes

The app offers both single-player and multiplayer modes. In single-player, explore, solve mysteries, and hunt ghosts. In multiplayer, collaborate or compete with friends by connecting multiple devices to the same physical set.



Image: Three children engaged in multiplayer augmented reality gameplay, each using a smartphone to interact with the LEGO Jack's Beach Buggy set on a table.

3. Interacting with the Digital World

Interaction with the physical LEGO model triggers events and reveals hidden elements within the digital world of the app. Follow on-screen prompts to battle boss ghosts like Trucker Dale and collect digital items.

Maintenance and Care

Cleaning LEGO Bricks

To clean LEGO bricks, use a mild soap solution and lukewarm water (not exceeding 40°C or 104°F). Rinse thoroughly with clear water and allow to air dry at room temperature. Avoid using hot water, harsh chemicals, or abrasive materials, as these can damage the plastic.

Storage

Store your LEGO set in a cool, dry place away from direct sunlight to prevent discoloration and warping. Keep small pieces in a container to avoid loss.



Image: Various disassembled LEGO pieces from the Jack's Beach Buggy set, including the main buggy chassis, wheels, and minifigure parts, laid out on a wooden table.

Troubleshooting

App Not Recognizing Model

- Ensure adequate lighting in the play area.
- Verify that the LEGO model is fully assembled and placed on a flat, contrasting surface.
- Check that your smart device's camera lens is clean and unobstructed.
- Confirm that the LEGO Hidden Side AR app is updated to the latest version.

Performance Issues (Lag, Crashes)

- Close other applications running in the background on your smart device.
- Restart the app and your smart device.
- Ensure your device meets the recommended specifications for the LEGO Hidden Side AR app.

Specifications

Feature	Detail
Model Name	Jack's Beach Buggy
Model Number	70428
Brand	LEGO
Number of Pieces	170
Dimensions (Built)	Over 3" (10cm) high, 4" (11cm) long, 3" (8cm) wide
Recommended Age	7+ years
Material	Plastic
Augmented Reality App	LEGO Hidden Side AR (Free download)

Warranty and Support

For information regarding product warranty, missing pieces, or general support, please visit the official LEGO customer service website or contact their support team directly. Details can typically be found on the LEGO Group's official website or within the packaging of your product.
Online Support: www.lego.com/service
App Support: For issues related to the LEGO Hidden Side AR app, please refer to the app's help section or the LEGO website's digital product support pages.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question