Ninja NJ110GR

Ninja Food Chopper Express Chop (NJ110GR) Instruction Manual

1. Product Overview

The Ninja Food Chopper Express Chop (Model NJ110GR) is a compact kitchen appliance designed for efficient food preparation. It features a powerful 200-watt motor and a 16-ounce (2-cup) processing bowl, making it suitable for mincing, chopping, grinding, and blending various ingredients. Its design prioritizes ease of use and convenient storage.



Image: Fully assembled Ninja Food Chopper Express Chop, ready for use.

2. Important Safety Information

Please read all instructions carefully before using the Ninja Food Chopper Express Chop. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Sharp Blades:** The chopping blades are extremely sharp. Handle with care when assembling, disassembling, or cleaning to avoid injury. Always hold the blade assembly by the shaft.
- **Electrical Safety:** Ensure the appliance is unplugged from the electrical outlet when not in use, before assembling or disassembling parts, and before cleaning. Do not immerse the motor base in water or other liquids.
- **Child Safety:** Keep the appliance and its cord out of reach of children. Close supervision is necessary when any appliance is used by or near children.
- **Proper Use:** Do not use the appliance for anything other than its intended household use. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- **Ventilation:** Do not block the motor base vents. Ensure adequate ventilation during operation.

3. Components

The Ninja Food Chopper Express Chop (NJ110GR) includes the following main components:

- **Motor Base:** The power unit with a 200-watt motor.
- **16-Ounce Chopping Bowl:** A clear plastic bowl with measurement markings.
- **Chopping Blade Assembly:** Stainless steel blades for processing ingredients.
- **Storage Lid:** A lid for the chopping bowl, allowing for convenient storage of processed ingredients.



Image: All components of the Ninja Food Chopper Express Chop.

4. Setup and Assembly

Follow these steps to correctly assemble your food chopper:

1. Place the 16-ounce chopping bowl onto a clean, dry, and level surface.
2. Carefully place the chopping blade assembly onto the center post inside the chopping bowl. Ensure it sits securely.
3. Add your desired ingredients to the chopping bowl. Do not exceed the MAX fill line indicated on the bowl.
4. Place the motor base onto the top of the chopping bowl, aligning the tabs. Press down firmly to engage the motor.
5. Plug the power cord into an electrical outlet. The unit is now ready for operation.

5. Operating Instructions

The Ninja Food Chopper Express Chop uses a simple pulse action for processing ingredients.

- **Pulsing:** With the unit assembled and plugged in, press down firmly on the top of the motor base to activate the blades. Release to stop. Use short, quick pulses for coarse chopping, and longer pulses for finer results or blending.
- **Monitoring:** Observe the consistency of your ingredients through the clear chopping bowl. Stop processing when the desired texture is achieved.
- **Even Chopping:** For best results, ensure ingredients are cut into roughly 1-inch pieces before placing them in the bowl. Do not overfill the bowl, as this can lead to uneven chopping or strain the motor.
- **Liquid Ingredients:** When processing liquids or soft ingredients, ensure the storage lid is securely closed if you intend to store them immediately after processing.



Image: Ninja Food Chopper Express Chop in action, processing tomatoes and herbs.

6. Care and Maintenance

Proper care ensures the longevity and performance of your food chopper.

- **Cleaning:** Always unplug the motor base before cleaning. The chopping bowl, chopping blade assembly, and storage lid are dishwasher safe. For hand washing, use warm, soapy water. Exercise extreme caution when handling the sharp blades.
- **Motor Base:** Wipe the motor base clean with a damp cloth. Do not immerse the motor base in water or place it in a dishwasher.
- **Storage:** The components are designed for stackable storage. Place the blade assembly inside the chopping bowl, then secure the storage lid on top, and finally invert the motor base over the lid for compact storage.

7. Troubleshooting

If you encounter issues with your Ninja Food Chopper, refer to the following common problems and solutions:

- **Unit Does Not Turn On:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Verify that the motor base is correctly seated and locked onto the chopping bowl. The unit will not operate if not properly assembled.
- **Food Not Chopping Evenly:**
  - Do not overfill the chopping bowl. Process ingredients in smaller batches if necessary.
  - Ensure ingredients are cut into uniform, manageable pieces (e.g., 1-inch cubes) before processing.
  - Use short, quick pulses to allow ingredients to fall to the bottom of the bowl for more consistent results.
- **Motor Overheating:**
  - If the motor stops during operation, it may be due to overheating. Unplug the unit and allow it to cool down for at least 15 minutes before resuming use.
  - Reduce the amount of ingredients being processed or cut them into smaller pieces to ease the load on the motor.

8. Specifications

- **Brand:** Ninja
- **Model Name:** NJ110GR
- **Power:** 200 Watts
- **Bowl Capacity:** 16 Ounces (approximately 2 cups)
- **Blade Material:** Stainless Steel
- **Power Source:** Corded Electric
- **Product Dimensions:** 1 x 1 x 1 inches (Note: This dimension appears to be a placeholder and may not reflect actual product size.)
- **Item Weight:** 1 pound
- **Dishwasher Safe Parts:** Chopping Bowl, Chopping Blade, Storage Lid (Motor base is not dishwasher safe)

9. Warranty and Support

For warranty information or customer support, please refer to the documentation included with your product or visit the

official Ninja website. Do not attempt to repair the appliance yourself if it malfunctions, as this may void your warranty and pose safety risks. Contact authorized service personnel for assistance.