Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

USA Toyz Astroshot Gemini Extreme

USA Toyz Astroshot Gemini Extreme Shooting Game Instruction Manual

Model: Astroshot Gemini Extreme

1. Safety Information

Please read all instructions before use. Adult supervision is recommended during play. Do not aim at eyes or face. Use only the foam balls provided or approved replacements. Keep small parts away from children under 3 years of age to prevent choking hazards.

2. Package Contents

Verify that all components listed below are included in your package:

- 1 x Astroshot Moving Standing Shooting Target
- 2 x Air Popper Toy Foam Blaster Guns
- 30 x Soft Foam Balls (15 blue, 15 orange)



Image: All components of the USA Toyz Astroshot Gemini Extreme Shooting Game.

3. Setup Guide

3.1 Assembling the Moving Target

1. Unpack all target frame pieces and the target fabric.
2. Connect the plastic poles to form the base and vertical supports of the target stand. Ensure all connections are secure.
3. Slide the target fabric onto the assembled frame, ensuring the scoring holes are facing forward.
4. Insert 4 AA batteries (not included) into the battery compartment located at the base of the target stand. This powers the moving mechanism.



Image: Step-by-step visual guide for assembling the moving target.

3.2 Loading the Air Popper Guns

1. Take a soft foam ball.
2. Insert the foam ball into the front barrel of the air popper gun. The gun can hold multiple balls (up to 10).
3. Repeat until the desired number of balls are loaded.



Image: Visual guide for loading foam balls into the air popper gun.

4. Operating Instructions

4.1 Using the Air Popper Guns

1. Once the foam balls are loaded, hold the gun firmly.
2. Aim the gun at the target.
3. Rapidly push the pump handle forward to launch the foam balls. The harder and faster you pump, the further the balls will travel (up to 26 ft).



Image: Air popper gun in action, demonstrating the firing mechanism.

4.2 Engaging with the Moving Target

1. Turn on the power switch at the base of the target stand.
2. The target will begin to move side-to-side, offering a dynamic challenge. It features dual-speed movement for varied gameplay.
3. Aim for the four scoring holes of varying sizes on the target fabric to score points.



Image: Detail of the moving target's base, showing the wheel for side-to-side movement and indicating dual-speed modes.

5. Maintenance

- **Cleaning:** Wipe down the plastic components of the guns and target stand with a damp cloth. Do not immerse electronic parts in water.
- **Storage:** When not in use, disassemble the target stand and store all components in the original packaging or a suitable container to prevent loss or damage. Remove batteries if storing for extended periods.
- **Foam Balls:** Keep foam balls clean and dry. Replace any damaged or worn-out balls to ensure optimal performance and safety.

6. Troubleshooting

- **Gun not firing:** Ensure foam balls are properly loaded into the barrel. Check that the pump mechanism is fully extended before

pushing forward.

- **Target not moving:** Verify that 4 AA batteries are correctly installed and are not depleted. Ensure the power switch at the base is in the 'ON' position.
- **Balls not traveling far:** Ensure the pump action is firm and rapid. Check foam balls for damage or wear that might affect aerodynamics.

7. Product Specifications

Feature	Detail
Product Dimensions	12 x 16 x 43 inches
Item Weight	3.27 pounds
Item Model Number	UT-ASGMNI-EXT
Manufacturer Recommended Age	6 years and up
Power Source (Target)	4 x AA Batteries (not included)
Ball Range	Up to 26 feet
Compatibility	Compatible with Nerf equipment

8. Warranty and Support

For any product inquiries, technical support, or warranty information, please contact USA Toyz customer service. You can find contact details and additional resources by visiting the official USA Toyz Store online.
Visit the USA Toyz Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07WF2C3QZ

More documents and user manuals: **https://manuals.plus/**