Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Rozi GLA-718

Rozi Air Fryer XXL User Manual

Model: GLA-718 | Brand: Rozi

Important Safety Information

Please read this user manual thoroughly before operating the appliance and save it for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not immerse the main unit, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep the appliance and its cord out of reach of children.
- Do not operate the appliance if the plug, power cord, or the appliance itself is damaged.
- Always unplug the appliance after use and before cleaning.
- Hot surfaces: The appliance's outer surfaces may become hot during use. Always use oven mitts when handling hot components.
- Do not block the air inlet or outlet vents.
- Do not place the appliance against a wall or other appliances. Leave at least 10 cm (4 inches) free space on the back and sides and 10 cm (4 inches) free space above the appliance.

Product Overview

The Rozi Air Fryer XXL is designed for healthy cooking with rapid hot air circulation. It features a large capacity and intuitive controls.



Image: The Rozi Air Fryer XXL, a black appliance with a silver top, featuring a pull-out basket filled with golden french fries.

Components:

- Main Air Fryer Unit
- Removable Non-stick Coated Fry Basket (5.5QT capacity)
- Stainless Steel Grill / Rack
- Food Tongs
- User Manual (this document)
- Recipe Book



Image: A close-up view of the non-stick frying pot, highlighting its flat basket design and the included stainless steel bracket.

Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials and promotional labels from the air fryer.
2. **Cleaning:** Wash the fry basket and stainless steel grill with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the main unit with a damp cloth. Ensure all parts are completely dry before use.
3. **Placement:** Place the air fryer on a stable, horizontal, and heat-resistant surface. Ensure there is adequate air circulation around the unit (at least 10 cm clearance on all sides).
4. **Pre-heating (Optional for first use):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 350°F (175°C) to burn off any manufacturing residues. A slight odor may be present, which is normal.

Operating Instructions

Control Panel Overview:



Image: The digital control panel of the Rozi Air Fryer, displaying various icons for 8 cooking presets including French fries, Ribs, Shrimp, Cake, Chicken Leg, Steak, Fish, and Pizza.



Image: A hand interacting with the LED touchscreen control panel of the Rozi Air Fryer, showing the digital display and touch-sensitive buttons for temperature, time, and mode selection.

- **Power Button:** Turns the appliance on/off.
- **Temperature Control:** Adjusts cooking temperature (180°F-400°F).
- **Timer Control:** Sets cooking time (0-60 minutes).
- **Preset Functions:** Select from 7 built-in presets for common dishes (French fries, Ribs, Shrimp, Cake, Chicken Leg, Steak, Fish, Pizza).
- **Memory Function:** The air fryer will stop working automatically when food is done.
- **Keep Warm Function:** Maintains food temperature for up to 2 hours after cooking.



Image: A mother and child smiling in a kitchen, with the Rozi Air Fryer on the counter. Text highlights the 'Keep Warm Function' which keeps food fresh and crispy.

Cooking Process:

1. **Prepare Food:** Place ingredients in the fry basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the fry basket back into the main unit until it clicks into place. The appliance will not operate if the basket is not properly inserted.
3. **Set Time and Temperature:** Use the temperature and timer controls, or select a preset function.
4. **Start Cooking:** Press the power button to begin. The 360° Rapid Hot Air Circulation Technology will cook your food.



Image: A diagram showing the internal structure of the air fryer with arrows indicating the 360-degree rapid hot air circulation around food, along with temperature and time ranges.

5. **Shake Basket (Optional):** For some foods, shaking the basket halfway through cooking ensures even browning. Pull out the basket, shake, and reinsert. The air fryer will resume cooking.
6. **Finish Cooking:** The timer will beep when cooking is complete. Carefully pull out the basket and remove food using tongs.

Benefits of Air Frying:

The Rozi Air Fryer utilizes advanced 360° Rapid Hot Air Circulation Technology to cook food, resulting in a crispy exterior and tender interior with significantly less oil compared to traditional deep frying. This method allows you to enjoy healthier versions of your favorite fried foods.



Image: A visual comparison between air frying and deep frying. The air fryer side shows food being cooked by circulating hot air, while the deep frying side shows food submerged in hot oil, emphasizing the 'Less Oil, More Healthy' aspect of air frying.

Maintenance and Cleaning

Regular cleaning will extend the life of your Rozi Air Fryer and ensure optimal performance.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Basket and Grill:** The removable non-stick coated basket and stainless steel grill are dishwasher safe. Alternatively, they can be cleaned with hot water, dish soap, and a non-abrasive sponge. Avoid using metal utensils or abrasive cleaning materials to protect the non-stick coating.
3. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. For the interior, use a soft, damp cloth and mild detergent if necessary. Do not immerse the main unit in water.

4. **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; Basket not inserted correctly.	Ensure the power cord is securely plugged into a grounded outlet. Push the basket firmly into the main unit until it clicks.
Food is not cooked evenly.	Basket is overfilled; Food not shaken.	Do not overfill the basket. Shake smaller ingredients halfway through the cooking process.
White smoke coming from the appliance.	Grease residue from previous use; Fatty ingredients.	Clean the basket and main unit thoroughly after each use. For fatty foods, excess oil may drip into the drawer, causing smoke. This is normal.
Fresh fries are not crispy.	Incorrect potato type; Not properly dried; Too much oil.	Use fresh potatoes suitable for frying. Ensure potato sticks are thoroughly dried before adding a light coating of oil.

Technical Specifications

Specification	Value
Model Number	GLA-718
Rated Voltage	120V
Rated Frequency	60Hz
Rated Power	1800W
Fry Basket Capacity	5.5QT (5.2 Liters)
Adjustable Temperature	180°F - 400°F
Timer Range	0 - 60 minutes
Product Dimensions (D x W x H)	14.5" x 13.3" x 16.5"
Net Weight	12.1 lbs
Material	Stainless Steel

Specification	Value
Control Method	Touch
Nonstick Coating	Yes
Dishwasher Safe Parts	Basket, Grill

Warranty and Support

Rozi is committed to 100% customer satisfaction. If you have any questions or concerns regarding your Rozi Air Fryer XXL, please do not hesitate to contact us directly.

For support, please contact us via Amazon's messaging system. Provide your order number and a detailed description of the issue for prompt assistance.

Your satisfaction is our top priority, and we are dedicated to resolving any issues you may encounter.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07WF6NFPM

More documents and user manuals: **https://manuals.plus/**