Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine RMAMU171

JustFine Replacement Remote Control Instruction Manual

Model: RMAMU171

Introduction

This document provides instructions for the JustFine replacement remote control, model RMAMU171. This remote is designed to be compatible with various Sony Micro Hi-Fi Audio Systems, including models CMT-BT60, RMAMU171, CMTBT80WB, CMT-SBT100, HCDSBT100B, HCD-SBT300W, and CMTSBT300WB. It functions as a direct replacement for your original remote control.

Setup

Battery Installation

The remote control requires batteries for operation. Batteries are not included with this product. Please follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the latch and slide the cover downwards to open the compartment.
3. Insert two new batteries (typically AAA size, not specified, but common for remotes) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back of the remote control. This view shows the textured back panel and the battery compartment cover, which slides open to allow for battery insertion. The latch for opening the compartment is visible at the bottom.

Once batteries are installed, the remote control is ready for use. No additional programming is required.

Operating Instructions

This replacement remote control is pre-programmed and ready to use with your compatible Sony Micro Hi-Fi Audio System. Simply point the remote control towards your audio system and press the desired function button.

Compatibility

This remote control is compatible with the following Sony Micro Hi-Fi Audio System models:

- Sony CMT-BT60
- Sony RMAMU171

- Sony CMTBT80WB
- Sony CMT-SBT100
- Sony HCDSBT100B
- Sony HCD-SBT300W
- Sony CMTSBT300WB

Usage Tips

- Ensure there is a clear line of sight between the remote control and the audio system's infrared receiver.
- The maximum effective range for operation is approximately 10 meters (33 feet).
- Avoid placing obstacles between the remote and the audio system.

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, it is recommended to remove the batteries to prevent leakage, which could damage the device.

Troubleshooting

Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-).
- **Replace Batteries:** If the batteries are old or depleted, replace them with new ones.
- **Line of Sight:** Verify that there are no obstructions between the remote control and the audio system's infrared receiver.
- **Distance:** Ensure you are within the effective operating range (approximately 10 meters).

Intermittent Operation

- This often indicates low battery power. Replace the batteries.
- Ensure the remote is pointed directly at the audio system.

Specifications

Feature	Description

Brand	JustFine
Model	RMAMU171
Compatible Devices	Sony Micro Hi-Fi Audio Systems (CMT-BT60, RMAMU171, CMTBT80WB, CMT-SBT100, HCDSBT100B, HCD-SBT300W, CMTSBT300WB)
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Maximum Range	10 Meters (33 feet)
Power Source	Batteries (not included)

Warranty and Support

Warranty Information

This product is sold with a 30-day quality warranty and a money-back guarantee. For any issues or concerns regarding the product's quality within this period, please refer to your purchase documentation for return or replacement procedures.

Customer Support

If you encounter any problems or have questions about your JustFine replacement remote control, please contact the seller directly through the platform where the purchase was made. Provide your order details for prompt assistance.

© 2023 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07WFP8LKX

More documents and user manuals: **https://manuals.plus/**