xingzhihua ZH/JT-01

xingzhihua ZH/JT-01 Air Conditioner Remote Control User Manual

Model: ZH/JT-01

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your xingzhihua ZH/JT-01 Air Conditioner Remote Control. Please read this manual thoroughly before use to ensure proper functionality and longevity of the device.

The ZH/JT-01 remote control is designed for use with specific Chigo and VOLTAS air conditioning units, including models compatible with ZH/JT-03. It is important to verify that the buttons and model number of this remote match your original remote control before purchase and use, as it is not a universal remote.

2. Product Overview

The xingzhihua ZH/JT-01 remote control provides convenient access to various functions of your air conditioning unit.



Image 1: Front view of the xingzhihua ZH/JT-01 Air Conditioner Remote Control. This image displays the remote's ergonomic design, the LCD screen at the top, and all control buttons clearly labeled. Key buttons visible include MODE, ON/OFF, TEMP, FAN SPEED, SWING, AIR FLOW, TIMER, HOLD, SLEEP, TURBO, LAMP, and CLEAN. The LCD screen shows indicators for AUTO, COOL, DRY, HEAT, FAN, SLEEP, LAMP, TURBO, CLEAN, and HOLD modes.



Image 2: Rear view of the xingzhihua ZH/JT-01 Air Conditioner Remote Control. This image highlights the smooth back casing and the battery compartment cover located at the bottom, indicated by an arrow for easy opening.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control. Refer to Image 2.
2. Slide the battery compartment cover downwards in the direction of the arrow to open it.
3. Insert two new AAA batteries (not included) according to the polarity indicators (+ and -) inside the compartment.
4. Close the battery compartment by sliding the cover back into place until it clicks securely.

Note: Ensure batteries are inserted correctly. Incorrect polarity can damage the remote control. Do not mix old and new batteries, or different types of batteries.

4. Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating.

4.1 Power On/Off

Press the **ON/OFF** button to turn the air conditioner on or off.

4.2 Mode Selection

Press the **MODE** button repeatedly to cycle through available operating modes: AUTO, COOL, DRY, HEAT, and FAN.

- **AUTO**: The unit automatically selects the operating mode based on the room temperature.
- **COOL**: Provides cooling to lower the room temperature.
- **DRY**: Dehumidifies the room.
- **HEAT**: Provides heating to raise the room temperature.

- **FAN**: Circulates air without heating or cooling.

4.3 Temperature Adjustment

Use the **TEMP ▲** and **TEMP ▼** buttons to increase or decrease the desired temperature. The display shows temperature in Celsius.

4.4 Fan Speed

Press the **FAN SPEED** button to adjust the fan speed (e.g., Low, Medium, High, Auto).

4.5 Swing Function

Press the **SWING** button to activate or deactivate the automatic louver swing function, which distributes air evenly.

4.6 Air Flow

Press the **AIR FLOW** button to adjust the direction of the airflow manually or automatically.

4.7 Timer Function

Press the **TIMER** button to set a timer for the air conditioner to turn on or off automatically.

4.8 Sleep Mode

Press the **SLEEP** button to activate sleep mode, which adjusts temperature and fan speed for comfortable sleep and energy saving.

4.9 Turbo Mode

Press the **TURBO** button for rapid cooling or heating.

4.10 Lamp Function

Press the **LAMP** button to control the display light on the air conditioner unit.

4.11 Clean Function

Press the **CLEAN** button to activate the self-cleaning function of the air conditioner (if supported by the unit).

4.12 Hold Function

Press the **HOLD** button to maintain the current settings.

5. Maintenance

5.1 Cleaning the Remote Control

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.

5.2 Battery Replacement

Replace batteries when the remote control's range decreases or if the display becomes dim. Refer to the 'Battery Installation' section for instructions. Remove batteries if the remote will not be used for an extended period to prevent leakage.

6. Troubleshooting

- **Remote not responding:** Check battery polarity and replace with fresh batteries. Ensure there are no obstructions between the remote and the air conditioner's receiver. Confirm the remote is compatible with your specific AC unit model.

- **Limited range:** Replace batteries. Ensure the remote is pointed directly at the AC unit.
- **Display issues:** If the remote's display is dim or blank, replace the batteries.
- **Functions not working:** Verify that your air conditioner unit supports the specific function (e.g., CLEAN, LAMP). Some functions may be specific to certain AC models.

7. Specifications

- **Model:** ZH/JT-01
- **Brand:** xingzhihua
- **Compatible Devices:** Air Conditioner (Chigo, VOLTAS ZH/JT-03 compatible models)
- **Connectivity Technology:** Infrared
- **Display:** Celsius
- **Power Source:** 2 x AAA Batteries (not included)
- **Special Feature:** Replacement remote control

8. Warranty and Support

This product is a replacement remote control. For specific warranty information, please refer to the retailer or original manufacturer of the remote control. For technical support or inquiries, please contact the seller or refer to the support resources provided with your purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question