JustFine TISOU

JustFine Replacement Remote Control User Manual

Model: TISOU

1. Product Overview

This document provides instructions for the JustFine replacement remote control, designed for use with various Samsung Home Theater Sound Bar Systems. This remote is pre-programmed and requires no additional setup beyond battery installation.

1.1. Compatibility

This remote control is compatible with the following Samsung Home Theater Sound Bar System models:

- HW-FM35
- AH5902547B
- HW-FM45/ZA
- HW-FM55C
- HW-D450
- HW-H550/ZA
- HW-H551
- HW-H570/ZA
- HW-H600/ZA

2. Setup

2.1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the

markings inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.



This image shows the back of the JustFine replacement remote control. The rectangular cover for the battery compartment is clearly visible, indicating where to insert or replace batteries. The design is sleek and ergonomic.

3. Operating Instructions

Once batteries are installed, the remote control is ready for use. Point the remote directly at your Samsung Home Theater Sound Bar System.



This image displays the front of the JustFine replacement remote control. Key buttons visible include POWER, SOURCE, SPEAKER, TV POWER, TV VOL, TV CH, MUTE, VOL, S/W LEVEL, SOUND EFFECT, 3D SOUND PLUS, and SMART VOLUME. The layout is designed for intuitive control of Samsung Home Theater Sound Bar Systems.

3.1. Basic Functions

- **POWER:** Turns the sound bar system on or off.
- **TV POWER:** Controls the power of a connected television.
- **SOURCE:** Cycles through available input sources (e.g., HDMI, Optical, Bluetooth).
- **VOL (+/-):** Adjusts the main volume level of the sound bar.
- **MUTE:** Silences the audio output. Press again to unmute.
- **S/W LEVEL (+/-):** Adjusts the subwoofer volume level.
- **SOUND EFFECT:** Cycles through various sound modes or effects.
- **TV VOL (+/-):** Adjusts the volume of a connected television.
- **TV CH (+/-):** Changes channels on a connected television.

3.2. Advanced Functions

Refer to your Samsung Sound Bar System's original manual for specific functions related to buttons such as **3D SOUND PLUS**, **SMART VOLUME**, **AUDIO SYNC**, **DIMMER**, and **DRC**, as their functionality may vary by model.

4. Maintenance

4.1. Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

4.2. Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

5. Troubleshooting

5.1. Common Issues and Solutions

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old or depleted batteries with new ones.
  - Check for any obstructions between the remote and the sound bar's infrared receiver.
  - Ensure you are within the effective range of the sound bar.
- **Some buttons not working:**
  - Verify that the remote is pointed directly at the sound bar.
  - Clean the remote's surface, especially around the buttons, to remove any debris.
  - Some functions may be specific to certain Samsung sound bar models. Refer to your sound bar's original manual.

6. Specifications

Brand	JustFine
Model Number	TISOU
Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	1.76 ounces
Connectivity Technology	Infrared (IR)
Max Number of Supported Devices	1 (Samsung Home Theater Sound Bar System)
Power Source	2 x AAA Batteries (not included)

7. Warranty and Support

7.1. Warranty Information

This product is sold with a 30-day quality warranty and a money-back guarantee. For any issues within this period, please contact customer support.

7.2. Customer Support

For any problems or inquiries regarding your JustFine replacement remote control, please contact us via email. We are committed to providing hassle-free support.