Innsky IS-EE004

Innsky 5.5L 1700W Air Fryer Instruction Manual (Model IS-EE004)

Your guide to safe and efficient use of your Innsky Air Fryer.

1. Important Safety Instructions

Please read all instructions carefully before using the appliance and retain them for future reference. Incorrect operation may cause damage to the appliance or personal injury.

- Always place the appliance on a stable, heat-resistant surface.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep children and pets away from the appliance during operation.
- Do not block any ventilation openings.
- Unplug the appliance when not in use and before cleaning.
- Do not operate the appliance if the cord or plug is damaged.

2. Product Overview

The Innsky 5.5L 1700W Air Fryer utilizes 360° rapid hot air circulation technology to cook food with significantly less oil than traditional frying methods, resulting in healthier meals. It features a digital touch screen with preset programs and additional functions for convenience.



Figure 2.1: Front view of the Innsky Air Fryer with digital control panel.

Key features include:

- **Capacity:** 5.5 Liters, suitable for 3-6 people.
- **Power:** 1700W for rapid heating.
- **Control:** Digital touch screen with 11 preset cooking programs.
- **Functions:** Preheat, Defrost, Keep Warm, and Delayed Start.
- **Safety:** Automatic shut-off and cool-touch handle.
- **Cleaning:** Removable, dishwasher-safe basket with non-stick coating.

3. Setup and First Use

3.1 Unpacking

- Carefully remove all packaging materials from the air fryer.
- Check that all parts are present and undamaged.
- Retain packaging for future storage or disposal.

3.2 Initial Cleaning

- Wipe the exterior of the appliance with a damp cloth.
- Wash the removable basket and crisper plate with hot water, dish soap, and a non-abrasive sponge.
- Rinse thoroughly and dry all parts completely before use.

3.3 Placement

- Place the air fryer on a stable, level, and heat-resistant surface.
- Ensure there is at least 10 cm (4 inches) of free space around the back and sides of the appliance to allow for proper ventilation.
- Do not place the appliance near flammable materials or heat sources.

3.4 First Use (Burn-in)

- Plug the air fryer into a grounded wall outlet.
- Run the air fryer empty for approximately 10-15 minutes at 180°C (350°F) to eliminate any manufacturing odors. A slight smell or smoke may be present during this initial use; this is normal.
- Allow the appliance to cool down completely before cleaning it again.

4. Operating Instructions

4.1 Control Panel Overview

The digital touch screen allows for easy control of all functions. The display shows temperature, time, and selected programs.



Figure 4.1: Digital control panel highlighting updated functions: Delayed Start, Preheat, Keep Warm, and Defrost.

4.2 Basic Operation

1. **Power On:** Plug in the air fryer. The power button will illuminate. Press it to turn on the display.
2. **Preheat (Optional but Recommended):** For best results, use the Preheat function. Press the Preheat icon, adjust temperature and time if needed, then press Start.

3. **Load Food:** Carefully pull out the basket using the cool-touch handle. Place food on the crisper plate inside the basket. Do not overfill.
4. **Select Program:** Choose one of the 11 preset programs (e.g., Steak, Chicken, Shrimp, Fish, Fries, Vegetables, Bread) by pressing the corresponding icon. The air fryer will automatically set the recommended time and temperature.
5. **Manual Settings:** Alternatively, manually set the desired temperature and time using the temperature and time adjustment buttons.
6. **Start Cooking:** Press the Start/Pause button to begin cooking.
7. **Shake/Flip Food:** For even cooking, some foods may require shaking or flipping halfway through. The air fryer may beep to remind you. Pull out the basket, shake/flip, and reinsert. The cooking will resume automatically.
8. **End of Cooking:** The air fryer will beep when cooking is complete and automatically shut off (Power Off Protection).
9. **Remove Food:** Carefully pull out the basket and transfer food to a serving plate. Use heat-resistant tongs.

4.3 Special Functions

- **Preheat:** Improves food texture and cooking speed. Adjustable from 2-5 minutes.
- **Defrost:** Thaws frozen food before cooking.
- **Keep Warm:** Maintains food at an optimal serving temperature after cooking.
- **Delayed Start:** Allows you to set a delayed start time for cooking.



Figure 4.2: Overview of the 11 convenient one-touch cooking programs, including Steak, Chicken, Shrimp, Fish, Fries, Vegetables, and Bread, along with special functions.

4.4 Cooking Tips

- **Oil Usage:** Use significantly less oil (up to 85% less) compared to traditional frying. A light spray or toss with a small amount of oil is often sufficient.

- **Even Cooking:** The 360° hot air circulation ensures even cooking. The NTC sensor technology maintains temperature fluctuations below 5°C for consistent results.
- **Capacity:** The 5.5-liter square basket can accommodate a 2.3 kg whole chicken or a 21 cm pizza.



Figure 4.3: Visual representation of the 5.5-liter capacity, showing space for two steaks, a 2.3kg chicken, or a 21cm pizza.

5. Cleaning and Maintenance

5.1 Cleaning

- **Before Cleaning:** Always unplug the air fryer and allow it to cool down completely before cleaning.
- **Basket and Crisper Plate:** The removable basket and crisper plate are dishwasher-safe. For manual cleaning, wash with hot water, dish soap, and a non-abrasive sponge. The non-stick coating ensures easy cleaning.
- **Interior:** Wipe the interior with a damp cloth or non-abrasive sponge. For stubborn food residue, soak the basket in warm soapy water for a short period.
- **Exterior:** Clean the exterior with a damp cloth. Do not use abrasive cleaners or scouring pads.
- **Heating Element:** Use a cleaning brush to remove any food residue from the heating element.



Figure 5.1: Illustration of the air fryer basket designs, highlighting the removable and easy-to-clean components.

5.2 Storage

- Ensure the air fryer is clean and dry before storing.
- Store the appliance in a cool, dry place.
- Do not wrap the power cord tightly around the appliance.

6. Troubleshooting

If you encounter any issues with your Innsky Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; power outlet not working.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Food is not cooked evenly.	Basket is overloaded; food not shaken/flipped.	Do not overload the basket. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; fatty food being cooked.	Clean the basket and crisper plate thoroughly after each use. For fatty foods, add a small amount of water to the bottom of the outer pan to prevent smoke.
Food is not crispy.	Not enough oil; food too moist; temperature too low.	Lightly coat food with oil. Pat moist foods dry before air frying. Increase temperature or cooking time slightly.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Feature	Detail
Brand	Innsky
Model	IS-EE004
Color	Black
Dimensions (L x W x H)	31.4 x 37.77 x 32.28 cm
Capacity	5.5 Liters
Wattage	1700 watts
Voltage	220 Volt (AC)
Material	Stainless steel and BPA-free plastic
Automatic Shut-off	Yes
Noise Level	65 dB
Item Weight	5.75 Kilograms

8. Warranty and Support

8.1 Product Warranty

The Innsky Air Fryer (Model IS-EE004) comes with a**12-month warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

8.2 Customer Support

For any questions, concerns, or assistance with your Innsky Air Fryer, please contact our professional customer support team. We offer **24-hour professional customer support** and a **hassle-free replacement/return policy**.



Figure 8.1: Innsky customer support team ready to assist.

Please refer to the contact information provided in your product packaging or visit the official Innsky website for further details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question