Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

xingzhihua YKR-H/209E

xingzhihua YKR-H/209E A/C Remote Control User Manual

Model: YKR-H/209E

Introduction

This user manual provides detailed instructions for the proper setup, operation, and maintenance of your xingzhihua YKR-H/209E A/C Remote Control. This remote is designed for use with specific AUX air conditioning units. Please verify that this remote control model (YKR-H/209E) is compatible with your original remote control or A/C unit before use.

Product Overview



Figure 1: Back view of the YKR-H/209E A/C Remote Control. This image displays the rear of the remote, with the model number 'YKR-H/209E' clearly visible on a black label. Below this, the battery compartment cover is shown, indicating where batteries are inserted.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control. Refer to Figure 1 for assistance.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) new AAA batteries (not included), ensuring the positive (+) and negative (-) terminals match the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

Note: Always replace both batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

Operating Instructions

Point the remote control directly at the infrared receiver on your AUX air conditioning unit. Ensure there are no obstructions between the remote and the A/C unit.

- **Power Button:** Press to turn the A/C unit ON or OFF.
- **Mode Button:** Press repeatedly to cycle through available operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temperature Adjustment Buttons (▲/▼):** Use these buttons to increase or decrease the desired temperature setting.
- **Fan Speed Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Swing Button:** Activates or deactivates the louver swing function for air distribution.
- **Timer Button:** Sets the timer for automatic ON/OFF operations. Refer to your A/C unit's manual for specific timer programming.
- **Sleep Button:** Activates the sleep mode, which typically adjusts temperature and fan speed for comfortable sleep.

Important: Button functions may vary slightly depending on the specific AUX A/C model. Refer to your air conditioner's original manual for detailed function descriptions.

Maintenance

Battery Replacement

Replace batteries when the remote control's range decreases or if the display (if present) becomes dim or unresponsive. Follow the battery installation steps outlined in the 'Setup' section.

Cleaning the Remote

Wipe the remote control with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water and a mild detergent, then wipe dry immediately. Do not use abrasive cleaners, alcohol, or solvents, as these can damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote and the A/C unit's receiver.
  - Verify the remote is pointed directly at the A/C unit.
- **Short operating range:**
  - Replace batteries.
  - Ensure the remote's infrared emitter and the A/C unit's receiver are clean and unobstructed.
- **A/C unit does not respond to specific functions:**
  - Confirm that your A/C unit supports the specific function you are trying to use. Some functions may not be available on all models.
  - Ensure the remote is compatible with your specific AUX A/C model.

Specifications

Model Number	YKR-H/209E
Brand	xingzhihua
Connectivity Technology	Aux (Infrared)
Max Number of Supported Devices	1
Maximum Range	10 Meters
Power Source	2 x AAA Batteries (not included)
Parcel Dimensions	18.21 x 9.3 x 3.4 cm
Item Weight	82 g

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07WMS6PN3

More documents and user manuals: **https://manuals.plus/**