QAZAKY 15A-24500-00-00

QAZAKY Fuel Petcock Valve Instruction Manual

Model: 15A-24500-00-00 (and compatible Yamaha models)

Brand: QAZAKY

Contents Introduction Specifications Package Compatibility Setup Operating Maintenance Troubleshooting Warranty & Support

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your new QAZAKY Fuel Petcock Valve. The fuel petcock is a critical component in your motorcycle's fuel system, controlling the flow of fuel from the tank to the carburetor or fuel injection system. This replacement part is designed to meet or exceed OEM specifications, ensuring reliable performance.




Image 1: Overview of the QAZAKY Fuel Petcock Valve.

2. Specifications

The QAZAKY Fuel Petcock Valve is engineered for durability and precise fuel control. Key specifications are as follows:

- **Material:** High-quality metal alloy construction.
- **Color:** Silver finish.
- **Mounting Hole Distance:** 34 mm (center-to-center).
- **Switch Positions:** ON, OFF, RES (Reserve).
- **Weight:** Approximately 160 grams.



Image 2: Detailed dimensions of the fuel petcock valve, showing the 34mm mounting hole distance.

3. Package Contents

Please verify that all items listed below are included in your package:

- 1 x QAZAKY Fuel Petcock Valve
- 1 x Mounting Gasket
- 2 x O-rings
- 2 x Fuel Filters (internal)



Image 3: The fuel petcock valve along with the included gasket, O-rings, and fuel filters.

4. Compatibility

This QAZAKY Fuel Petcock Valve is a direct replacement for numerous Yamaha motorcycle models. It is compatible with the following Yamaha OEM part numbers:

- 15A-24500-00-00, 15A-24500-01-00, 15A-24500-02-00, 15A-24500-03-00
- 21V-24500-10-00, 21V-24500-11-00, 21V-24500-20-00
- 23F-24500-01-00, 23F-24500-10-00, 23F-24500-11-00, 23F-24500-20-00
- 2GU-24500-00-00, 2GU-24500-01-00
- 2HR-24500-00-00, 2HR-24500-01-00, 2HR-24500-02-00
- 2KF-24500-00-00
- 3FY-24500-00-00, 3FY-24500-01-00
- 3JN-24500-00-00, 3JN-24500-01-00, 3JN-24500-02-00, 3JN-24500-10-00
- 3RW-24500-00-00, 3RW-24500-01-00
- 3Y1-24500-10-00
- 43F-24500-00-00

- 4DP-24500-00-00, 4DP-24500-01-00, 4DP-24500-10-00
- 4WM-24500-00-00, 4WM-24500-01-00, 4WM-24500-02-00, 4WM-24500-10-00
- 4X8-24500-02-00, 4X8-24500-03-00
- 55X-24500-02-00
- 5GH-24500-00-00, 5GH-24500-01-00, 5GH-24500-10-00
- 5GT-24500-00-00, 5GT-24500-01-00
- 5KM-24500-00-00, 5KM-24500-01-00, 5KM-24500-10-00
- 5LP-24500-00-00, 5LP-24500-01-00
- 5TG-24500-00-00, 5TG-24500-01-00, 5TG-24500-10-00
- 5Y1-24500-10-00

Please cross-reference your motorcycle's existing part number to ensure proper fitment.

5. Setup (Installation)

Follow these steps for safe and correct installation of the fuel petcock valve:

1. **Safety First:** Ensure the motorcycle engine is off and cool. Disconnect the battery if necessary. Work in a well-ventilated area and have a fire extinguisher nearby.
2. **Drain Fuel:** If possible, drain the fuel tank into an approved container to minimize spills during removal of the old petcock.
3. **Remove Old Petcock:** Disconnect the fuel lines from the old petcock. Unscrew the mounting bolts and carefully remove the old petcock and gasket.
4. **Clean Mounting Surface:** Thoroughly clean the mounting surface on the fuel tank to ensure a proper seal with the new gasket.
5. **Install New Gasket:** Place the new mounting gasket onto the fuel tank's petcock mounting surface.
6. **Mount New Petcock:** Position the new QAZAKY Fuel Petcock Valve onto the gasket and align the mounting holes. Insert the mounting screws and tighten them evenly, but do not overtighten.
7. **Connect Fuel Lines:** Reconnect the fuel lines to the appropriate outlets on the new petcock. Ensure all clamps are secure.
8. **Check for Leaks:** Refill the fuel tank. Set the petcock to the 'ON' position and carefully inspect all connections for any fuel leaks. Address any leaks immediately before operating the motorcycle.



Image 4: The fuel petcock valve showing the internal fuel filters and the mounting gasket.

6. Operating Instructions

The QAZAKY Fuel Petcock Valve features a 3-position switch for controlling fuel flow:

- **ON:** This is the standard operating position. In this position, fuel flows from the main fuel supply in the tank to the engine. Use 'ON' for normal riding conditions.
- **OFF:** This position completely shuts off the fuel flow from the tank. Use 'OFF' when the motorcycle is parked for an extended period, during maintenance, or for transport to prevent fuel leaks and evaporation.
- **RES (Reserve):** This position allows access to a small reserve of fuel located at the bottom of the fuel tank. Use 'RES' only when your main fuel supply is depleted and you need to reach a fuel station. Switch back to 'ON' as soon as the tank is refilled.

Always ensure the petcock is in the correct position before starting or riding your motorcycle.

7. Maintenance

Regular maintenance helps ensure the longevity and proper function of your fuel petcock valve:

- **Inspect for Leaks:** Periodically check around the petcock and fuel lines for any signs of fuel leaks. Address any leaks immediately.
- **Clean Fuel Filters:** The internal fuel filters can become clogged over time. It is recommended to inspect and clean or replace these filters periodically, especially if you notice reduced fuel flow or engine performance issues.
- **Switch Operation:** Ensure the petcock switch moves smoothly between positions. If it becomes stiff or difficult to turn, it may require cleaning or replacement.
- **Gasket Condition:** Check the mounting gasket for signs of wear or cracking. Replace the gasket if it appears damaged to prevent leaks.

8. Troubleshooting

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Fuel Leak at Petcock	Improperly tightened mounting screws, damaged gasket, faulty petcock body.	Check and tighten mounting screws. Replace gasket. If leak persists, replace petcock.
No Fuel Flow to Engine	Petcock in 'OFF' position, clogged fuel filter, clogged fuel line.	Ensure petcock is in 'ON' or 'RES' position. Clean or replace fuel filters. Inspect and clear fuel lines.
Engine Stalls/Runs Poorly	Insufficient fuel supply due to partially clogged filter or incorrect petcock position.	Check petcock position. Clean or replace fuel filters.

9. Warranty & Support

QAZAKY provides a warranty for its products to ensure customer satisfaction.

- **Warranty:** Original QAZAKY parts come with a 180-day return guarantee. Please retain your proof of purchase for warranty claims.
- **Support:** For any questions, technical assistance, or warranty claims, please contact the seller directly through your purchase platform.

© 2026 QAZAKY. All rights reserved.