Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Noma B07WTN6KPL

Noma C9 LED Christmas Lights Instruction Manual

Model: B07WTN6KPL

Product Overview

Noma C9 LED Christmas Lights are designed for both indoor and outdoor use, providing a warm, inviting glow for various celebrations. This string light set features 25 energy-efficient green LED bulbs on a 16.8-foot strand.

Key Features:

- 25 C9 LED diamond cut faceted bulbs.
- 16.8-foot string length.
- UL-rated for indoor and outdoor applications.
- Energy-saving LED technology, cool to the touch.
- End-to-end connectivity, allowing up to 90 strands (2,250 lights) to be connected.
- Includes a spare fuse and 2 spare bulbs.



Image: Packaging for Noma C9 LED String Lights, highlighting indoor/outdoor use, 25 green C9 bulbs, and 16.8 ft length.

Setup Instructions

Unpacking

- Carefully remove the light strand from its packaging.
- Uncoil the string lights completely before plugging them in to prevent overheating.

Installation

1. Determine your desired display area, ensuring it is within reach of a power outlet.
2. For outdoor use, ensure the power outlet is a Ground Fault Circuit Interrupter (GFCI) protected receptacle.
3. Secure the lights using appropriate clips or fasteners. Avoid stapling or nailing through the wire insulation.
4. The C9 bulbs are 1.25 inches in diameter and 2.5 inches tall, spaced 8 inches apart.
5. For connecting multiple strands, align the male plug of one strand with the female receptacle of another. You can connect up to 90 strands (total 2,250 lights) end-to-end.



25 Energy Efficient LEDs

Go green with 25 long lasting energy efficient LED bulbs

Indoor & Outdoor

Simple to install on your Christmas tree, mantel, railing, and entryway

Connect 45 Strands

Plug-ins at both ends allow you to connect up to 45 sets

Image: A diagram illustrating key features: 25 energy-efficient LEDs, suitability for indoor and outdoor use, and the capability to connect multiple strands.



Image: Noma C9 green LED lights adorning an indoor Christmas tree, showcasing their decorative effect.



Image: Noma C9 green LED lights strung along the gutter of a house, covered in a light layer of snow, illustrating their outdoor application.

Operating Instructions

Once installed, plug the light strand into a suitable power outlet. The lights will illuminate immediately.

Safety Precautions

- Do not overload electrical circuits. Refer to the maximum connectable strands (90 sets) to avoid exceeding electrical limits.
- Always unplug the lights when not in use or before performing any maintenance.
- Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Do not let lamps rest on the supply cord or on any wire.
- Inspect the product carefully before each season's use. Discard any products that have cut, damaged, or frayed wire insulation or cords, cracks in the lampholders or enclosures, loose connections, or exposed copper wire.

Your browser does not support the video tag.

Video: This video demonstrates various Noma LED Christmas light types, including C9, C6, and Mini LEDs, showcasing their appearance and application in different settings.

Maintenance

Bulb Replacement

Your Noma C9 LED Christmas Lights come with 2 spare bulbs. If a bulb fails:

1. Unplug the light strand from the power source.
2. Carefully twist the faulty bulb counter-clockwise to remove it from its socket.
3. Insert a new spare bulb by twisting it clockwise until secure.
4. Ensure all bulbs are properly seated to maintain the weather-resistant seal.



Image: A detailed view of three Noma C9 green LED bulbs, highlighting their faceted texture and the base where they connect to the string.

Fuse Replacement

A spare fuse is included. If the entire strand does not light up:

1. Unplug the light strand.
2. Locate the fuse access cover on the plug.
3. Slide the cover open and carefully remove the old fuse.
4. Insert the new fuse and close the cover securely.

Storage

- Before storing, ensure the lights are completely dry.
- Coil the lights neatly to prevent tangling and damage to the wires or bulbs.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Lights Not Illuminating

- **Check Power Source:** Ensure the plug is securely inserted into a working electrical outlet. Test the outlet with another device.
- **Check Fuse:** If the entire strand is out, the fuse in the plug may have blown. Replace it with the spare fuse provided (refer to Maintenance section).
- **Check Bulbs:** If only a section or individual bulbs are out, check for loose or faulty bulbs. Replace any non-working bulbs (refer to Maintenance section).
- **Check Connections:** For connected strands, ensure all end-to-end connections are secure.

Flickering Lights

- **Loose Connections:** Check all bulb sockets and end-to-end connections for looseness.
- **Damaged Wire:** Inspect the entire length of the wire for any cuts, pinches, or damage. Discontinue use if significant damage is found.

Outdoor Use Issues

- **GFCI Tripping:** If using outdoors, ensure the GFCI outlet is not tripping. This could indicate a short circuit or moisture intrusion. Inspect lights for damage and ensure connections are dry.
- **Weather Exposure:** While weather-resistant, extreme conditions can affect performance. Ensure lights are properly secured to prevent wind damage.

Specifications

Feature	Detail
Brand	Noma
Model	B07WTN6KPL
Color	Green

Feature	Detail
Light Source Type	LED
Number of Light Sources	25
Bulb Shape Size	C9
String Length	16.8 feet
Wattage	6 watts
Indoor/Outdoor Usage	Indoor, Outdoor
Power Source	Corded Electric
Special Features	2 Replacement Bulbs Included, Connect up to 90 Strands, Spare Fuse Included
UPC	029944571414
Item Weight	1.43 pounds

Warranty and Support

Warranty Information

Noma C9 LED Christmas Lights are covered by a**3-year limited warranty**. This warranty covers manufacturing defects and ensures the product meets quality standards under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, technical support, or warranty claims, please contact Noma customer service. Refer to the product packaging or the Noma official website for current contact information.
You can also visit the Noma Store on Amazon for more product information and support resources.

© 2023 Noma. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07WTN6KPL

More documents and user manuals: **https://manuals.plus/**