Whirlpool 8MWTW-1995EI

Whirlpool 8MWTW-1995EI 19 KG Washing Machine User Manual

Model: 8MWTW-1995EI

1. Introduction

Thank you for choosing a Whirlpool washing machine. This manual provides essential information for the safe and efficient operation of your new **Whirlpool 8MWTW-1995EI 19 KG Top-Load Washing Machine**. Please read it thoroughly before using the appliance to ensure proper installation, operation, and maintenance. Keep this manual for future reference.



Figure 1: Front view of the Whirlpool 8MWTW-1995EI 19 KG Top-Load Washing Machine. This image shows the white exterior with a gray control panel at the top, featuring various knobs and indicators.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury to persons when using your appliance, follow basic precautions, including the following:

- Read all instructions before using the appliance.
- Do not wash articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances as they emit vapors that could ignite or explode.
- Do not allow children to play on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
- Do not reach into the appliance if the tub or agitator is moving.
- Do not install or store this appliance where it will be exposed to the weather.
- Do not tamper with controls.
- Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in this manual or in published user-repair instructions that you understand and have the skills to carry out.
- Always disconnect the appliance from the power supply before attempting any service.

3. Installation and Setup

3.1 Unpacking

Carefully remove all packaging materials, including the base packaging and any internal packing. Ensure no parts are left inside the tub.

3.2 Location Requirements

Choose a location for your washing machine that is:

- A level surface to prevent excessive vibration and noise.
- Near a grounded electrical outlet.
- Within reach of hot and cold water faucets.
- Equipped with a suitable drain for the drain hose.

3.3 Connecting Water Hoses

1. Connect the hot water supply hose to the hot water inlet on the back of the washer (marked with an 'H' or red).
2. Connect the cold water supply hose to the cold water inlet (marked with a 'C' or blue).
3. Connect the other ends of the hoses to the corresponding hot and cold water faucets.
4. Tighten all connections firmly by hand, then an additional two-thirds turn with pliers. Do not overtighten.

3.4 Drain Hose Installation

Securely attach the drain hose to the drain outlet on the back of the washer. Place the other end of the drain hose into a laundry tub or standpipe. Ensure the drain hose is not kinked or blocked.

3.5 Leveling the Machine

Use a level to check if the machine is perfectly level. Adjust the leveling feet at the bottom of the washer by turning them clockwise or counter-clockwise until the machine is stable and level on all sides.

3.6 Power Connection

Plug the power cord into a grounded 3-prong outlet. Do not use an extension cord or adapter.

4. Operating Instructions

4.1 Control Panel Overview

The control panel features push-button controls and rotary knobs for cycle selection, water temperature, and water level. Refer to the markings on your specific model for detailed functions.

4.2 Loading Laundry

Load dry, unsorted items loosely into the wash basket. Do not overload the machine. For best results, distribute items evenly around the agitator.

4.3 Adding Detergent and Additives

Add the recommended amount of high-efficiency (HE) detergent directly into the wash basket before adding clothes, or into the dispenser if your model has one. For fabric softener, add it to the designated dispenser at the beginning of the cycle.

4.4 Selecting a Cycle

Turn the cycle selector knob to choose the desired wash cycle. This model offers **Normal** and **Heavy Duty** cycles. Select the cycle appropriate for the fabric type and soil level.

4.5 Starting a Wash

Close the lid. Press the 'Start' button. The machine will begin to fill with water and agitate. The lid will lock during the wash and spin cycles.

4.6 End of Cycle

Once the cycle is complete, the machine will stop, and the lid will unlock. Remove laundry promptly to prevent wrinkles and mildew.

5. Maintenance and Care

5.1 Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.

5.2 Cleaning the Dispenser (if applicable)

If your model has a detergent or fabric softener dispenser, remove and clean it regularly with warm water to prevent buildup.

5.3 Cleaning the Wash Tub

Periodically run a 'Clean Washer' cycle (if available) or a regular cycle with hot water and a cup of white vinegar or a washing machine cleaner to remove detergent residue and odors.

5.4 Water Inlet Filters

Check the screens in the water inlet hoses periodically for debris. If clogged, turn off water supply, disconnect hoses, and clean the screens.

6. Troubleshooting

Before calling for service, try the following solutions for common issues:

Problem	Possible Cause	Solution
Washer does not start	Power cord unplugged; Lid not closed; Circuit breaker tripped.	Ensure power cord is plugged in; Close lid completely; Reset circuit breaker.
No water fill or slow fill	Water supply turned off; Inlet hoses kinked; Inlet screens clogged.	Turn on water supply; Straighten hoses; Clean inlet screens.
Washer vibrates excessively	Washer not level; Load unbalanced.	Level the washer using the adjustable feet; Redistribute laundry evenly.
Water not draining	Drain hose kinked or clogged; Drain pump filter clogged.	Check and clear drain hose; Refer to manual for drain pump filter cleaning (if applicable).
Clothes not clean	Overloading; Incorrect detergent amount; Wrong cycle selected.	Reduce load size; Use correct detergent amount; Select appropriate cycle.

7. Specifications

Feature	Detail
Manufacturer	Whirlpool
Model Name	8MWTW-1995EI
Capacity	19 KG
Dimensions (L x W x H)	75 x 75 x 120 cm (approximate)
Weight	75 kg
Access Type	Top-Load
Color	White
Cycle Options	Normal, Heavy Duty
Control Type	Push button
Operation Mode	Semi-automatic
Max Spin Speed	670 RPM
Standard Cycles	2

8. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Whirlpool website. You can also contact Whirlpool customer service directly for assistance with product registration, service requests, or technical inquiries.
Whirlpool Official Website: www.whirlpool.com

© 2023 Whirlpool Corporation. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question