Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RM-Series X40474Y40474-LC-32A47E-BK

RM-Series Replacement Remote Control User Manual

Model: X40474Y40474-LC-32A47E-BK

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your RM-Series Replacement Remote Control, model X40474Y40474-LC-32A47E-BK. This remote is designed as a direct replacement for Sharp LC-32A47E-BK televisions, offering seamless functionality without the need for complex programming.

Product Overview





Figure 1: Front view of the RM-Series replacement remote control. This image shows the full layout of buttons, including number keys, navigation pad, volume, channel, and special function buttons.



Figure 2: Angled view of the RM-Series replacement remote control, highlighting its ergonomic design and button placement from a side perspective.





Figure 3: Back view of the RM-Series replacement remote control, showing the smooth casing and the battery compartment cover.





Figure 4: Back view of the RM-Series replacement remote control with the battery compartment open, revealing the battery slots.

Setup

1. Installing Batteries

1. Locate the battery compartment on the back of the remote control. Refer to *Figure 3* for the closed compartment and *Figure 4* for the open compartment.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: This remote control does not require any programming. It is pre-programmed to work with Sharp LC-32A47E-BK televisions immediately after battery installation.

Operating Instructions

The RM-Series Replacement Remote Control functions identically to your original Sharp LC-32A47E-BK television remote. Point the remote control directly at the television's infrared (IR) receiver for optimal performance. The maximum effective range is approximately 10 meters.

Key Functions:

- **POWER:** Turns the television on or off.
- **INPUT:** Selects the input source (e.g., HDMI, AV, Component).
- **MUTE:** Mutes or unmutes the television sound.
- **Number Buttons (0-9):** Directly selects channels or enters numerical values.
- **VOL +/-:** Adjusts the volume level.
- **CH +/- (or P +/-):** Changes the television channel.
- **MENU:** Opens the television's main menu.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **RETURN/BACK:** Returns to the previous screen or menu.
- **EXIT/END:** Exits the current menu or function.
- **EPG:** Accesses the Electronic Program Guide.
- **RADIO:** Switches to radio mode (if supported by TV).
- **AV MODE:** Cycles through audio/video modes.
- **SURROUND:** Activates or deactivates surround sound.
- *Other buttons as labeled on the remote control perform their corresponding functions on the television.*

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. For stubborn dirt, slightly dampen the cloth with water. Do not use abrasive cleaners, alcohol, or solvents.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new alkaline batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote control, expose it to extreme temperatures, direct sunlight, or moisture.

Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	• Dead or incorrectly inserted batteries. • Obstruction between remote and TV. • TV's IR receiver is blocked or faulty.	• Replace batteries with new ones, ensuring correct polarity. • Remove any objects blocking the line of sight to the TV. • Ensure the TV is powered on. Test with original remote if available to confirm TV receiver functionality.
Remote works intermittently.	• Low battery power. • Weak IR signal due to distance or angle.	• Replace batteries. • Ensure you are within the 10-meter range and pointing directly at the TV.
Certain buttons not responding.	• Button stuck or damaged. • TV model incompatibility (unlikely for this specific replacement).	• Gently press the button multiple times. If still unresponsive, the button may be faulty. • Verify your TV model is Sharp LC-32A47E-BK.

Specifications

- **Model:** X40474Y40474-LC-32A47E-BK
- **Brand:** RM-Series
- **Compatible Devices:** Sharp LC-32A47E-BK Television
- **Connectivity Technology:** Infrared (IR)
- **Controller Type:** Button Control
- **Special Feature:** Pre-programmed, no setup required
- **Maximum Range:** Approximately 10 Metres
- **Power Source:** 2 x AAA Alkaline Batteries (not included)
- **Product Dimensions:** 22.7 x 5 x 2.4 cm
- **Item Weight:** 87 Grams (without batteries)

Warranty and Support

For warranty information or technical support, please refer to the retailer or manufacturer's website where the product was

purchased. Keep your proof of purchase for any warranty claims.
This product is designed to be a direct replacement and typically does not require extensive technical support beyond basic troubleshooting outlined in this manual.

© 2024 RM-Series. All rights reserved.
Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07X1FYMR1

More documents and user manuals: **https://manuals.plus/**