Comimark LY431

Comimark GP2Y0A21YK0F Sharp IR Analog Distance Sensor User Manual

Model: LY431

1. Product Overview

The Comimark GP2Y0A21YK0F is a Sharp IR Analog Distance Sensor designed for precise distance measurement. This unit integrates a PSD (position sensitive detector), an IRED (infrared emitting diode), and a signal processing circuit to provide reliable distance detection.
It operates on the triangulation method, which minimizes the influence of object reflectivity, environmental temperature, and operating duration on distance readings. The sensor outputs an analog voltage directly corresponding to the detected distance, making it suitable for various applications, including use as a proximity sensor.

Key Features:

- Distance measuring range: 10 to 80 cm
- Analog output type
- Typical consumption current: 30 mA
- Supply voltage: 4.5 to 5.5 V
- Integrated PSD, IRED, and signal processing circuit
- Utilizes triangulation method for stable detection



Figure 1: Front view of the GP2Y0A21YK0F Sharp IR Analog Distance Sensor with its three-wire cable (red, yellow, black).

2. Specifications

Parameter	Value
Model Number	LY431
Distance Measuring Range	10 to 80 cm
Output Type	Analog
Supply Voltage	4.5 to 5.5 V

Consumption Current (Typ.)	30 mA
Item Material	Polymer
Item Dimensions (L x W x H)	29.5 × 13 × 13.5 mm
Hardware Platform	Arduino
Item Weight	0.634 ounces

3. Setup and Connection

This section outlines the steps for connecting the GP2Y0A21YK0F sensor to a compatible microcontroller, such as an Arduino board.

3.1 Wiring Diagram

The sensor comes with a three-wire cable for connection:

- **Red Wire:** VCC (Power Supply)
- **Black Wire:** GND (Ground)
- **Yellow Wire:** Vo (Analog Output)

3.2 Connection Steps (Example with Arduino)

1. Connect the **Red Wire (VCC)** of the sensor to the 5V pin on your Arduino board.
2. Connect the **Black Wire (GND)** of the sensor to a GND pin on your Arduino board.
3. Connect the **Yellow Wire (Vo)** of the sensor to an Analog Input pin (e.g., A0) on your Arduino board.



Figure 2: Top view of the sensor, highlighting the connection points for the cable.



Figure 3: Side view of the sensor, illustrating its compact size and cable attachment.

4. Operating Instructions

Once connected, the sensor outputs an analog voltage that varies with the distance to an object. This voltage can be read by an analog-to-digital converter (ADC) on your microcontroller.

4.1 Reading Sensor Data (Arduino Example)

To read the analog output from the sensor, use theanalogRead() function in Arduino. The raw analog value will range from 0 to 1023 (for a 10-bit ADC).

Example Arduino Sketch:

```
const int sensorPin = A0; // Analog input pin connected to the sensor's Vo (Yellow wire)

void setup() {
  Serial.begin(9600); // Initialize serial communication for debugging
}

void loop() {
  int analogValue = analogRead(sensorPin); // Read the analog value from the sensor
  Serial.print("Raw Analog Value: ");
  Serial.println(analogValue);

  // Convert analog value to voltage (optional, for understanding)
  // float voltage = analogValue * (5.0 / 1023.0);
  // Serial.print("Voltage: ");
  // Serial.print(voltage);
  // Serial.println(" V");

  // Note: Converting analog value to distance requires calibration.
  // The relationship between voltage and distance is non-linear.
  // Refer to the sensor's datasheet for a voltage-distance curve or
  // use empirical calibration for best results.

  delay(100); // Small delay before next reading
}
```

4.2 Distance Calculation

The relationship between the sensor's output voltage and the distance is inverse and non-linear. Typically, a higher voltage corresponds to a shorter distance. For accurate distance measurements, it is recommended to:

- Consult the official datasheet for the GP2Y0A21YK0F sensor, which provides a voltage vs. distance characteristic curve.
- Perform empirical calibration by measuring known distances and recording the corresponding analog output values. This data can then be used to create a lookup table or a mathematical function for conversion.



Figure 4: Another perspective of the sensor, showing the infrared emitter and detector lenses.

5. Maintenance

The Comimark GP2Y0A21YK0F sensor is a robust electronic component that requires minimal maintenance. Following these guidelines will help ensure its longevity and accurate performance:

- **Keep Lenses Clean:** Ensure the infrared emitter and detector lenses are free from dust, dirt, or obstructions. Use a soft, dry, lint-free cloth to gently wipe the lenses if necessary. Avoid abrasive materials or harsh chemicals.
- **Avoid Physical Damage:** Protect the sensor from impacts, excessive force, or bending of the wires. The sensor's housing and internal components are delicate.
- **Environmental Conditions:** Operate and store the sensor within its specified temperature and humidity ranges. Avoid exposure to extreme temperatures, direct sunlight for prolonged periods, or high moisture environments.

- **Secure Connections:** Periodically check that the wiring connections are secure and free from corrosion. Loose connections can lead to intermittent readings or sensor malfunction.



Figure 5: Bottom view of the sensor, revealing the circuit board and components.

6. Troubleshooting

If you encounter issues with your GP2Y0A21YK0F sensor, consider the following troubleshooting steps:

Problem	Possible Cause	Solution

No output or constant low/high reading	Incorrect wiring, insufficient power, faulty sensor, or obstructed lenses.	◦ Verify all connections (VCC, GND, Vo) are correct and secure. ◦ Ensure the power supply is within the 4.5V to 5.5V range. ◦ Check for any physical obstructions or dirt on the sensor lenses. ◦ Test with a different analog input pin on your microcontroller.
Inaccurate or fluctuating readings	Ambient light interference, reflective surfaces, object outside range, or electrical noise.	◦ Minimize strong ambient light sources (especially IR) near the sensor. ◦ Be aware that highly reflective or absorbent surfaces can affect accuracy. ◦ Ensure the object is within the 10-80 cm detection range. ◦ Add a small capacitor (e.g., 0.1uF) between VCC and GND near the sensor to smooth power.
Sensor gets warm	Normal operation (IRED generates some heat) or excessive current.	◦ Slight warmth is normal. If it's excessively hot, recheck supply voltage and wiring for shorts. ◦ Ensure current consumption is within typical limits (30mA).




Figure 6: Detailed view of the sensor's internal circuitry, visible from the bottom.

7. Warranty and Support

For specific warranty information and technical support regarding your Comimark GP2Y0A21YK0F Sharp IR Analog Distance Sensor, please refer to the documentation provided at the time of purchase or contact the vendor directly. General support for integration with platforms like Arduino can often be found through online communities and forums dedicated to electronics and microcontrollers.

Always ensure you are using the product within its specified operating parameters to avoid voiding any potential warranty.

© 2024 Comimark. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question