Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sjpzwcrl 2*Black

Sjpzwcrl Electric Salt and Pepper Mill Grinder Instruction Manual

Model: 2*Black

Product Overview

The Sjpzwcrl Electric Salt and Pepper Mill Grinder offers an efficient and convenient way to grind your favorite spices. Designed for ease of use, this battery-operated grinder features automatic activation and adjustable coarseness settings, making it suitable for various culinary needs. Its durable construction and transparent design ensure both functionality and a clear view of your spices.

- **High Quality and Large Capacity:** Constructed from high-quality acrylic, non-corrosive and antioxidative materials, ensuring fresh and healthy spices. Features a large capacity for less frequent refilling.
- **Easy to Use:** Operates with a simple tilt, automatically activating the grinding mechanism. No buttons to press, allowing for convenient one-handed operation. A blue LED light illuminates during use.
- **Adjustable Coarseness:** Easily adjust the grinding coarseness from fine to coarse by rotating the top adjuster. Clockwise rotation yields finer particles, while counter-clockwise rotation produces coarser particles.
- **Battery Powered:** Each grinder requires 6 AAA batteries (not included) for operation. The automatic sense induction ensures effortless use.

Setup and Assembly

Follow these steps to set up your Sjpzwcrl Electric Salt and Pepper Mill Grinder for first use.

1. **Unscrew Bottom Compartment:** Gently twist and remove the transparent lower compartment from the main body of the grinder.
2. **Install Batteries:** Open the battery compartment located in the upper section. Insert 6 AAA batteries into the designated slots, ensuring correct polarity. (Batteries are not included).
3. **Fill with Seasoning:** Fill the transparent lower compartment with your desired whole spices, such as peppercorns or coarse salt. Do not overfill.
4. **Reassemble:** Screw the lower compartment back onto the main body until securely fastened.



Image: Visual guide for battery installation and spice refilling.

Operating Instructions

The Sjpzwcrl Electric Salt and Pepper Mill Grinder is designed for simple, one-handed operation.

- **Automatic Grinding:** To operate, simply tilt the grinder upside down over your food. The internal sensor will automatically activate the grinding mechanism, and a blue LED light will illuminate.
- **Adjusting Coarseness:** To change the grind size, locate the adjuster at the top of the grinder. Rotate it clockwise for a finer grind or counter-clockwise for a coarser grind.
- **Stopping Grinding:** Return the grinder to an upright position to stop the grinding process.



Image: Demonstrates tilting the grinder to activate grinding.



Image: Illustrates how to adjust the coarseness of the grind.

Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your grinder.

- **Cleaning:** To clean the exterior, wipe with a damp cloth. Do not immerse the grinder in water or wash it under running water, as this can damage the electronic components.
- **Grinding Mechanism:** For internal cleaning, especially if residue builds up, use the included brush to gently clear any spice particles from the ceramic grinding core.
- **Storage:** Store the grinder in a dry place away from direct sunlight and excessive humidity.
- **Battery Replacement:** Replace all 6 AAA batteries when the grinding power diminishes or the LED light becomes dim. Always replace with new batteries of the same type.



Image: Exploded view of the grinder components for maintenance reference.

Troubleshooting

Problem	Possible Cause	Solution
Grinder not operating or weak grinding.	Low or dead batteries; incorrect battery installation; spice jam.	Replace all 6 AAA batteries with new ones, ensuring correct polarity. Check for any spice blockages in the grinding mechanism and clear with the brush.
Inconsistent grind size.	Coarseness adjuster not set correctly; spice residue affecting mechanism.	Adjust the coarseness setting as desired. Clean the grinding core to remove any accumulated spice particles.
Blue LED light not illuminating.	Batteries are low or dead; internal connection issue.	Replace batteries. If the issue persists after battery replacement, contact customer support.

Specifications

- **Brand:** Sjpzwcrl

- **Model Number:** 2*Black
- **Material:** Acrylic
- **Color:** Black Set
- **Product Dimensions:** 6W x 20.5H centimetres
- **Item Weight:** 599 g
- **Capacity:** 198 g
- **Number of Items:** 2 (Set)
- **Operation Mode:** Automatic (Gravity Sensor)
- **Power Source:** 6 x AAA Batteries (per grinder, not included)
- **Included Components:** Brushes

Warranty and Support

Your Sjpzwcrl Electric Salt and Pepper Mill Grinder comes with a manufacturer's warranty.

- **Manufacturer Warranty:** 1 year.
- **Manufacturer Contact Information:** Sjpzwcrl. For support or warranty claims, please refer to the contact information provided with your purchase or visit the official Sjpzwcrl brand store.
- **Online Support:** You can find additional information and support resources by visiting theSjpzwcrl Brand Store.

© 2023 Sjpzwcrl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07X54548R

More documents and user manuals: **https://manuals.plus/**