Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit ONC18TV001

ZdalaMit Replacement Remote Control User Manual

Model: ONC18TV001

1. Introduction

This manual provides instructions for the ZdalaMit Replacement Remote Control, designed for use with ONN FHD LED TV models, specifically ONC18TV001. This remote control requires no programming or pairing; simply insert batteries, and it is ready for operation.



Image 1.1: Front view of the ZdalaMit Replacement Remote Control. This image displays the full layout of the remote's buttons, including the red power button at the top left, input button, navigation pad with OK button, volume and channel controls, and a numeric keypad.

2. Setup

2.1 Battery Installation

The remote control requires two (2) 1.5V AAA alkaline batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Once batteries are installed, the remote is ready for immediate use with compatible ONN TV models.



Image 2.1: Battery compartment of the remote control. This image shows the rear of the remote with the battery cover removed, illustrating the correct orientation for inserting two AAA batteries.

3. Operating Instructions

This section outlines the primary functions of the remote control buttons.

Button	Function
Power ( )	Turns the TV on or off.
INPUT	Cycles through available input sources (HDMI, AV, etc.).
SAP/MTS	Selects Secondary Audio Program/Multi-channel Television Sound.
CC	Activates or deactivates Closed Captions.
TTS	Activates or deactivates Text-to-Speech function.
SLEEP TIMER	Sets a timer for the TV to automatically turn off.
MENU	Opens the TV's main menu.
INFO	Displays current program information.
Navigation Arrows (▲ ▼ ◄ ►)	Navigates through menu options.
OK	Confirms selections in menus.
BACK	Returns to the previous screen or menu.
EXIT	Exits the current menu or function.
VOL +/-	Adjusts the volume level.
MUTE	Mutes or unmutes the TV sound.
CH +/-	Changes the TV channel.
Number Pad (0-9)	Directly enters channel numbers.
ENTER	Confirms channel entry or other numeric inputs.

4. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's performance degrades or if it stops responding. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

5. Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

- **Remote is not responding:**

- Check if the batteries are inserted correctly with the correct polarity (+/-).
- Replace old batteries with new 1.5V AAA alkaline batteries.
- Ensure there are no obstructions between the remote control and the TV's infrared sensor.
- Point the remote directly at the TV's sensor.

- **Remote functions are intermittent:**
  - This often indicates low battery power. Replace the batteries.
  - Ensure the remote is clean and free of debris that might obstruct button presses.
- **Remote does not control my TV:**
  - Verify that your TV model is compatible with this remote control (specifically ONN TV model ONC18TV001).
  - This remote is pre-programmed and does not require manual pairing or code entry. If it's not working, double-check battery installation and compatibility.

6. Specifications

Feature	Detail
Brand	ZdalaMit
Model Number	ONC18TV001
Compatible Devices	ONN FHD LED Television (Model ONC18TV001)
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Product Dimensions	5.2 x 1.3 x 0.5 inches (13.2 x 3.3 x 1.3 cm)
Item Weight	1.41 ounces (40 grams)
Color	Black
Special Feature	Pre-Programmed (No programming or pairing needed)
Max Number of Supported Devices	1

7. Warranty and Support

This ZdalaMit replacement remote control is designed for reliable performance. While specific warranty details are not provided in this manual, please retain your purchase receipt as proof of purchase.

For any queries or assistance regarding this product, please contact the seller or manufacturer through the platform where the purchase was made. They will be able to provide further support and information.

Please note: Batteries and additional manuals are not included with the remote control.

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XD7JDNQ

More documents and user manuals: **https://manuals.plus/**