Vaillant OUTSIDE MAG 15-8/1-5 GPL RT LOW NOX

Vaillant OUTSIDE MAG 15-8/1-5 GPL RT LOW NOX User Manual

Model: OUTSIDE MAG 15-8/1-5 GPL RT LOW NOX

1. Introduction and Safety Information

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Vaillant OUTSIDE MAG 15-8/1-5 GPL RT LOW NOX water heater. Please read this manual thoroughly before installation or operation and keep it for future reference.

1.1 Safety Warnings

- **DANGER:** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
- **WARNING:** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
- **CAUTION:** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
- **NOTICE:** Indicates information considered important, but not hazard-related (e.g., property damage).

Always ensure installation and servicing are performed by a qualified professional.

2. Setup and Installation

The Vaillant OUTSIDE MAG 15-8/1-5 GPL RT LOW NOX is designed for outdoor installation. Proper setup is crucial for safety and performance.

2.1 Pre-Installation Checks

- Verify that the installation site meets local regulations for gas appliances.
- Ensure adequate ventilation and clearance around the unit.
- Confirm the gas supply type (GPL) matches the appliance requirements.
- Check water supply pressure and flow rate.

2.2 Mounting the Unit

Mount the unit vertically on a sturdy, non-combustible wall using appropriate fasteners. Ensure it is level to prevent operational issues.

2.3 Connecting Gas and Water

Connect the gas supply line to the appliance's gas inlet. Connect the cold water inlet and hot water outlet pipes. Use appropriate sealing materials and check for leaks after connections are made.
Note: *All gas and water connections must be performed by a certified technician.*

3. Operating Instructions

This section describes the basic operation of your Vaillant water heater.

3.1 Initial Start-up

1. Ensure all gas and water connections are secure and leak-free.
2. Open the main gas supply valve.
3. Open the cold water inlet valve to the water heater.
4. Open a hot water tap in your home to purge air from the system. Close the tap once water flows steadily.
5. Turn the appliance's control knob to the desired temperature setting. The unit will ignite automatically when hot water is demanded.

3.2 Temperature Adjustment

The water temperature can be adjusted using the control knob on the front panel. Rotate clockwise to increase temperature, counter-clockwise to decrease. Refer to the markings on the knob for specific temperature ranges (e.g., Min, Eco, Max).

3.3 Shutting Down the Unit

For temporary shutdown, simply turn the control knob to the "OFF" position. For extended periods of inactivity (e.g., vacation), it is recommended to:

- Turn the control knob to "OFF".
- Close the main gas supply valve to the unit.
- Close the cold water inlet valve to the unit.
- If there is a risk of freezing, drain the unit completely.

4. Maintenance

Regular maintenance ensures the longevity and efficient operation of your water heater. Always disconnect power and gas supply before performing any maintenance.

4.1 Annual Professional Service

It is highly recommended to have your Vaillant water heater inspected and serviced by a qualified technician annually. This includes checking gas connections, burner efficiency, heat exchanger condition, and safety devices.

4.2 Cleaning the Exterior

Clean the exterior casing with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.

4.3 Draining the Unit (If Applicable)

If the unit is to be left unused in freezing conditions, it must be completely drained to prevent damage. Consult a professional for this procedure if unsure.

5. Troubleshooting

This section provides solutions to common issues you might encounter. For problems not listed here, or if solutions do not resolve the issue, contact a qualified service technician.

Problem	Possible Cause	Solution
No hot water	No gas supply; low water flow; ignition failure.	Check gas valve; ensure adequate water pressure; verify unit is on.
Water not hot enough	Temperature setting too low; excessive hot water demand.	Increase temperature setting; reduce simultaneous hot water usage.
Unit cycles on/off frequently	Insufficient water flow; scaling in heat exchanger.	Check water flow rate; professional descaling may be required.

6. Technical Specifications

Below are the general technical specifications for the Vaillant OUTSIDE MAG 15-8/1-5 GPL RT LOW NOX water heater. Specific values may vary slightly.

- **Model:** OUTSIDE MAG 15-8/1-5 GPL RT LOW NOX
- **Fuel Type:** GPL (Liquefied Petroleum Gas)
- **Nominal Heat Output:** 15 kW (approx.)
- **Hot Water Flow Rate (ΔT 25°C):** 8-10 liters/minute (approx.)
- **Ignition:** Electronic, automatic
- **NOx Emissions:** Low NOx compliant
- **Dimensions (H x W x D):** 600 x 350 x 200 mm (approx.)
- **Weight (empty):** 12 kg (approx.)
- **Water Pressure Range:** 0.15 - 10 bar

7. Warranty and Support

Vaillant products are manufactured to the highest standards and come with a manufacturer's warranty. Please refer to the separate warranty card included with your product for specific terms and conditions.
For technical support, spare parts, or to schedule a service appointment, please contact your local authorized Vaillant service center or visit the official Vaillant website.
Website: *www.vaillant.com*

© 2023 Vaillant Group. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question