Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Woox R4130

Woox LED Ceiling Light R4130 User Manual

Model: R4130

1. Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Woox LED Ceiling Light, Model R4130. This product is designed to provide efficient and versatile lighting for your home, featuring dimming, color temperature adjustment, and smart home integration capabilities with Amazon Alexa and Google Home.
Please read this manual thoroughly before using the product to ensure safe and optimal performance.

2. Safety Information

- Always disconnect power before installation, cleaning, or maintenance.
- Installation should be performed by a qualified electrician if you are unsure.
- Do not use this product in wet or damp environments.
- Do not attempt to disassemble or modify the product. This will void the warranty.
- Keep the remote control and batteries out of reach of children.
- Dispose of batteries properly according to local regulations.

3. Package Contents

Verify that all items listed below are included in your package:

- LED Ceiling Light Main Unit
- LED Ceiling Light Cover
- Dedicated Adapter
- Remote Control
- AAA Batteries (x2)
- Instruction Manual (this document)



Figure 3.1: Package Contents. This image displays the various components included in the product box, such as the main light unit, its cover, the power adapter, the remote control, two AAA batteries, and the instruction manual.

4. Specifications

Model Number	R4130
Brand	Woox
Rated Power Consumption	Approx. 40W
Rated Voltage	AC100V (50/60Hz)
Total Luminous Flux	4000lm
Rated Life	40,000 hours
Light Color Options	Daylight White (6500K), Neutral White (4300K), Warm White (2700K)

Dimming Levels	3 levels (100%, 60%, 20%)
Night Light Levels	2 levels (100%, 30% adjustable)
Timer Function	30 minutes, 60 minutes
External Dimensions	Diameter approx. 47.5 cm × Height approx. 8.6 cm
Weight	1.32 kg
Material	Acrylic (PMMA)
Compatibility	Works with Alexa, Google Home



Figure 4.1: Product Dimensions and Key Specifications. This image visually represents the physical dimensions of the ceiling light and highlights its main technical specifications.

5. Setup and Installation

5.1 Physical Installation

Before starting, ensure the power supply to the installation area is turned off at the circuit breaker.

1. Carefully unpack all components and verify against the package contents list.
2. Attach the dedicated adapter to the ceiling wiring according to standard electrical practices. Ensure a secure connection.
3. Mount the main unit of the LED ceiling light to the adapter, twisting or securing it until it clicks into place.
4. Attach the LED ceiling light cover to the main unit.
5. Insert the two AAA batteries into the remote control, observing polarity.
6. Restore power to the circuit.

5.2 Initial Pairing with Remote Control

The remote control should be pre-paired. If not, or if you need to re-pair:

- Ensure the light is powered on.
- Within 5 seconds of turning on the light, press and hold the "ON/OFF" button on the remote control until the light flashes, indicating successful pairing.

5.3 Smart Home Integration (Alexa/Google Home)

This product is compatible with Amazon Alexa and Google Home for voice control and smart automation. You will need the Woox Home app (or Smart Life app, as they often share platforms) installed on your smartphone and a compatible smart speaker (e.g., Amazon Echo, Google Home device).

For Google Home Integration:

Prerequisites:

- Ensure your smart device is added to the Woox Home app and is online.
- Ensure the Google Home app is installed on your smartphone.

Method 1 (Via Woox Home App - if available):

1. Open the Woox Home app.
2. Tap "Me" (usually located at the bottom right).
3. Select "Google Assistant".
4. Tap "Link with Google Assistant". This should prompt the Google Home app to open.
5. In the Google Home app, tap "Link".
6. Tap "Agree and Link".
7. Wait for the synchronization to complete. Your smart device will then be synced to Google Assistant. You can then assign the device to a room within the Google Home app.

Method 2 (Via Google Home App - recommended if Method 1 fails):

1. Open the Google Home app.
2. Tap the "+" icon in the top left corner.
3. Select "Set up device".
4. Choose "Works with Google".
5. Search for "Smart Life" (Woox Home often uses the Smart Life platform).

6. Tap "Smart Life". This will open the login page for the Smart Life/Woox Home app.
7. Enter your Woox Home app account credentials (username and password) and complete the authorization.
8. Once authorized, your Woox devices will be imported into Google Home.

After successful integration, you can use voice commands like "Hey Google, turn on the living room light" or "Hey Google, set the living room light to warm white."



Figure 5.1: Smart Home Compatibility. This image illustrates the light's integration with various control methods, including a mobile application, remote control, Amazon Alexa, and Google Assistant.

6. Operating Instructions

6.1 Remote Control Functions

The included remote control allows for easy adjustment of the light's settings:

- **ON/OFF:** Turns the light on or off.

- **Dimming ( ):** Adjusts brightness through 3 levels (100%, 60%, 20%).
- **Color Temperature ( ):** Changes the light color through 3 levels (6500K Daylight White, 4300K Neutral White, 2700K Warm White).
- **Night Light ( ):** Activates a low-brightness night light mode. Pressing again cycles between 100% and 30% brightness within night light mode.
- **Full Light ( ):** Sets the light to 100% brightness.
- **Timer (30 / 60):** Sets the light to automatically turn off after 30 or 60 minutes. A beep sound confirms timer activation.



Figure 6.1: Remote Control Functions. This diagram clearly labels each button on the remote and describes its corresponding function for controlling the light.



Figure 6.2: Timer Function. This image demonstrates the practical application of the timer feature, allowing the light to automatically turn off after a set duration, ideal for bedtime.

6.2 App Control

Once integrated with the Woox Home app (or Smart Life app), you can control the light from your smartphone or tablet. Functions typically include:

- Turning the light on/off.
- Adjusting brightness (dimming).
- Changing color temperature.
- Setting schedules and timers.
- Creating scenes and automations.

6.3 Voice Control (Alexa/Google Home)

After successful smart home integration, use voice commands to control your light. Examples:

- "Alexa, turn on the [Light Name]."
- "Hey Google, turn off the [Light Name]."
- "Alexa, dim the [Light Name] to 50%."
- "Hey Google, change [Light Name] to warm white."
- "Alexa, set [Light Name] to daylight."

Replace *[Light Name]* with the name you assigned to your light in the Alexa or Google Home app (e.g., "living room light", "ceiling light").

7. Maintenance

Regular maintenance ensures the longevity and optimal performance of your LED Ceiling Light.

- **Cleaning:** Before cleaning, ensure the light is turned off and cool. Use a soft, dry cloth to wipe the surface of the light and cover. For stubborn marks, a slightly damp cloth with mild detergent can be used, followed by drying with a clean, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** If the remote control's response becomes sluggish or stops working, replace the two AAA batteries. Ensure correct polarity when inserting new batteries.
- **Light Source:** The LED light source is integrated and not user-replaceable. Do not attempt to open the main unit.

8. Troubleshooting

If you encounter issues with your Woox LED Ceiling Light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power supply; Loose wiring; Remote control battery dead or un-paired.	Check circuit breaker. Ensure wiring is secure. Replace remote batteries. Re-pair remote control (see Section 5.2).
Remote control not responding.	Dead batteries; Remote not paired; Obstruction between remote and light.	Replace batteries. Re-pair remote control (see Section 5.2). Ensure clear line of sight.
Cannot connect to Wi-Fi or smart home app.	Incorrect Wi-Fi password; Router too far; 5GHz Wi-Fi network (product only supports 2.4GHz); App/device not properly linked.	Verify Wi-Fi password. Move router closer or use a Wi-Fi extender. Ensure your phone is connected to a 2.4GHz Wi-Fi network during setup. Follow smart home integration steps carefully (Section 5.3). Try resetting the light (turn off/on 3 times quickly).
Night light function stopped working.	Possible internal component failure.	If other functions work, this may indicate a specific component issue. Contact customer support for assistance.

If the problem persists after trying these solutions, please contact customer support.

9. Warranty and Support

9.1 Warranty Information

The Woox LED Ceiling Light R4130 comes with a **1-year warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or improper installation.
Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For technical support, warranty claims, or any questions regarding your Woox LED Ceiling Light, please contact the seller or Woox customer service through their official website or contact channels. Refer to the product packaging or the seller's information for specific contact details.

© 2024 Woox. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XF2HB5C

More documents and user manuals: **https://manuals.plus/**