Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CUSIMAX B07XQYT61V

CUSIMAX Toaster 2 Slice Long Slot with Glass Window User Manual

Model: B07XQYT61V | Brand: CUSIMAX

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the toaster.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use appliance for other than intended use.
- Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may create a fire or risk of electric shock.
- A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not attempt to dislodge food when toaster is plugged in.
- Do not operate unattended.

2. Product Overview

The CUSIMAX Toaster is designed for efficient and versatile toasting, featuring a unique glass window for visibility and an

automatic lifting mechanism.



Figure 2.1: CUSIMAX Toaster with toast inside, showcasing the glass viewing window.

Key Features:

- **Visible Glass Window:** Monitor toast shade in real-time. Made with food-grade tempered glass and brushed stainless steel.
- **Automatic Lifting Lever:** Bread is automatically lowered and raised, eliminating manual operation and preventing accidental burns.
- **7 Shade Levels:** Offers a range of browning options from light to dark, catering to individual preferences.
- **Extra-Wide Long Slot:** 1.5-inch wide and 10.5-inch long slot accommodates various bread types, including artisan bread, bagels, and waffles.
- **Easy to Clean:** Features slide-out glass panels and a removable crumb tray for convenient cleaning.

3. Setup

1. **Unpacking:** Carefully remove the toaster and all packaging materials from the box. Retain packaging for future storage or transport if needed.
2. **Placement:** Place the toaster on a stable, flat, heat-resistant surface, away from flammable materials such as curtains or walls. Ensure adequate ventilation around the appliance.
3. **First Use (Burn-Off):** Before first use, operate the toaster without bread on the highest setting (Level 7) for one cycle. This will burn off any manufacturing residues and eliminate initial odors. It is normal for a slight odor or smoke to be present during this process. Ensure the area is well-ventilated.
4. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet.

4. Operating Instructions

4.1 Basic Toasting

1. **Power On:** Press the **ON/OFF** button to turn on the toaster. The indicator light will illuminate.
2. **Insert Bread:** Place up to two slices of bread into the long slot. The 1.5-inch wide slot accommodates various bread types.
3. **Select Shade Level:** Rotate the browning control knob to select your desired shade level from 1 (lightest) to 7 (darkest).



Figure 4.1: Control panel with browning knob and function buttons.



Figure 4.2: The extra-wide long slot accommodates various bread types.



Figure 4.3: Visual guide to the 7 shade levels.

4. **Start Toasting:** Press the **CANCEL/START** button. The toaster will automatically lower the bread into the toasting chamber. You can observe the toasting process through the glass window.
5. **Completion:** Once the toasting cycle is complete, the toaster will emit an audible beep, and the bread will automatically lift.



Figure 4.4: Automatic lifting mechanism in action.

6. **Cancel Function:** To stop the toasting process at any time, press the **CANCEL/START** button again. The bread will immediately lift.

4.2 Special Functions

- **Defrost Function:** For toasting frozen bread, insert the bread, select your desired shade level, and then press the **DEFROST** button before pressing **CANCEL/START**. The defrost indicator light will illuminate. This function adds extra time to the toasting cycle to thaw and then toast the bread.
- **Bagel Function:** For toasting bagels, insert the bagel halves with the cut side facing inwards. Select your desired shade level, and then press the **BAGEL** button before pressing **CANCEL/START**. The bagel indicator light will illuminate. This function toasts the cut side while gently warming the outer side.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your toaster.

1. **Unplug and Cool:** Always unplug the toaster from the power outlet and allow it to cool completely before cleaning.
2. **Empty Crumb Tray:** The crumb tray is located at the bottom of the toaster. Gently pull it out to remove accumulated crumbs. Dispose of crumbs and wipe the tray clean with a damp cloth. Reinsert the tray securely.



Figure 5.1: Removable crumb tray and slide-out glass panel for easy cleaning.

3. **Clean Glass Panels:** The glass panels can slide out for thorough cleaning. Carefully slide them out and wipe them with a soft, damp cloth. For stubborn stains, a mild detergent can be used. Ensure panels are completely dry before reinserting.
4. **Exterior Cleaning:** Wipe the exterior of the toaster with a soft, damp cloth. Do not use abrasive cleaners or metal scouring pads, as they may scratch the surface.
5. **Do Not Immerse:** Never immerse the toaster body, cord, or plug in water or any other liquid.

6. Troubleshooting

Problem	Possible Cause	Solution
Toaster does not turn on.	Not plugged in; power button not pressed; power outage.	Ensure the toaster is securely plugged into a working outlet. Press the **ON/OFF** button. Check your household's circuit breaker.
Bread is not toasting evenly.	Uneven bread thickness; heating elements obstructed by crumbs.	Ensure bread slices are of uniform thickness. Clean the crumb tray and glass panels regularly to prevent crumb buildup.

Problem	Possible Cause	Solution
Toaster emits a loud beep.	This is the normal end-of-cycle alert.	This is an intended feature. If desired, you can press the **CANCEL/START** button just before the cycle finishes to avoid the beep.
Bread gets stuck or does not lift automatically.	Food too large; mechanism obstructed.	Ensure bread fits within the slot without forcing. Unplug the toaster and carefully remove any obstructions once cooled.

If the problem persists after attempting these solutions, please contact CUSIMAX customer support.

7. Specifications

Brand: CUSIMAX

Model: B07XQYT61V

Color: Stainless Steel 1 (Black)

Material: Glass, Stainless Steel

Product Dimensions: 15.23"D x 5.79"W x 7.87"H

Wattage: 1200 watts

Voltage: 120V

Number of Slices: 2 (Long Slot)

Shade Settings: 7 Levels

Special Features: Visible Glass Window, Automatic Lifting Lever, Cancel Function, Defrost Mode, Bagel Mode, Removable Crumb Tray, Slide-out Glass Panels

Item Weight: 8.89 pounds

First Available: September 10, 2019

8. Warranty and Support

CUSIMAX stands behind the quality of its products.

- **18-Month Free Replacement:** Your CUSIMAX Toaster comes with an 18-month free return or replacement policy for any quality issues.
- **Customer Support:** For any questions, concerns, or warranty claims, please contact CUSIMAX customer support. Refer to the product packaging or the official CUSIMAX website for the most current contact information.
- **Online Resources:** Visit the official CUSIMAX store on Amazon for additional product information and support: CUSIMAX Amazon Store.

© 2025 CUSIMAX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XQYT61V

More documents and user manuals: **https://manuals.plus/**