Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Neufday EZ LRL Watch 0131 244

Neufday Automatic Mobile Phone Shaker Wiggler Device

Model: EZ LRL Watch 0131 244

Product Overview

The Neufday Automatic Mobile Phone Shaker Wiggler Device is designed to simulate natural walking motion for your mobile phone. This allows applications that track physical activity, such as step counters or fitness apps, to continue accumulating progress without requiring actual physical movement from the user. It is particularly useful for maintaining activity records in applications like WeChat Run Count.

Safety Information

- Ensure the device is placed on a stable, flat surface to prevent tipping during operation.
- Keep the device away from water or other liquids.
- Do not attempt to disassemble or modify the device. This may void the warranty and pose a safety risk.
- Use only the provided USB cable or a compatible power source.
- Keep out of reach of children and pets.
- Avoid placing excessively heavy or large phones on the device, as this may affect performance or stability.

Package Contents



This image displays all the components included with the device: two black Y-shaped phone holders, a round black base unit, a white USB power cable, and a chrome-plated metal frame with a yellow elastic band and three metal balls.

Please check the package carefully to ensure all items are present:

1. 1 x Main Base Unit (round, black)
2. 1 x Metal Shaking Frame (chrome-plated, with elastic band and balls)
3. 2 x Y-shaped Phone Holders (black plastic)
4. 1 x USB Power Cable (white)

Setup Instructions

1. **Assemble the Frame:** Insert the bottom part of the metal shaking frame into the designated slot on the main base unit. Ensure it is securely seated.
2. **Attach Phone Holders:** Place the two Y-shaped phone holders onto the horizontal bars of the metal shaking frame. These holders will cradle your mobile phone.
3. **Connect Power:** Plug the small end of the USB power cable into the port on the main base unit. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a USB port on a computer.
4. **Placement:** Place the assembled device on a flat, stable surface.

Operating Instructions

1. **Power On:** Once connected to power, the device should automatically begin to shake the metal frame. There is typically no on/off switch; operation begins upon power connection.
2. **Place Phone:** Carefully place your mobile phone into the Y-shaped holders on the shaking frame. Ensure the phone is balanced and securely held by the elastic band or the holders themselves. The phone's screen should face upwards or towards the user.
3. **Monitor Progress:** Open your desired activity tracking application (e.g., WeChat Run Count) on your phone. The device will simulate steps by gently swinging the phone back and forth.
4. **Power Off:** To stop the device, simply disconnect the USB power cable from the base unit or the power source.

Note: The effectiveness of step counting may vary depending on the phone model, application sensitivity, and device placement. Experiment with different phone orientations if needed.

Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** When not in use, store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the USB cable excessively.

Troubleshooting

Problem	Possible Cause	Solution
Device does not shake.	No power or loose connection.	Ensure the USB cable is securely connected to both the device and a working power source. Try a different USB port or power adapter.
Phone falls off the device.	Phone not properly secured or device unstable.	Ensure the phone is correctly placed within the Y-shaped holders and secured by the elastic band. Place the device on a completely flat and stable surface.

Problem	Possible Cause	Solution
Step count is not increasing.	App sensitivity or phone orientation.	Check your phone's app settings. Try adjusting the phone's position or orientation within the shaker. Some apps may require specific phone movements to register steps.
Device makes unusual noise.	Obstruction or internal issue.	Ensure there are no obstructions around the shaking mechanism. If the noise persists, discontinue use and contact support.

Specifications

Brand: Neufday

Model: EZ LRL Watch 0131 244

Dimensions (L x W x H): Approximately 12 x 11 x 1 cm (4.7 x 4.3 x 0.4 inches)

Weight: Approximately 340 g (0.75 lbs)

Material: Plastic, Metal

Compatible Devices: Mobile Phones

Mounting Type: Table Mount

Power Source: USB (5V DC, via USB cable)

Batteries Required: No

Warranty and Support

This product comes with a standard manufacturer's warranty. For specific warranty details, returns, or technical support, please refer to the purchase platform or contact Neufday customer service directly. Please retain your proof of purchase for warranty claims.
For further assistance, you may visit the official Neufday website or contact their support channels as listed on your product packaging or purchase documentation.

© 2024 Neufday. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XSJH8MM

More documents and user manuals: **https://manuals.plus/**