Clatronic HBB 3734

Clatronic HBB 3734 Automatic Shirt and Trouser Press Instruction Manual

Model: HBB 3734

1. Introduction

Thank you for choosing the Clatronic HBB 3734 Automatic Shirt and Trouser Press. This innovative appliance is designed to simplify your garment care routine by combining drying and ironing functions into one efficient process. It is suitable for shirts, blouses, t-shirts, and trousers, delivering wrinkle-free results with minimal effort. Please read this manual carefully before first use to ensure safe and optimal operation.



Image 1.1: The Clatronic HBB 3734 Automatic Shirt and Trouser Press. This image shows the main unit with a pink shirt mounted on the balloon body, ready for drying and ironing.



Image 1.2: A man observing a light blue shirt being dried and ironed on the Clatronic HBB 3734. This illustrates the convenience of combining drying and ironing to save time.

2. Safety Instructions

Please observe the following safety precautions to prevent injury or damage to the appliance:

- Read all instructions before using the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Always unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Ensure the appliance is placed on a stable, level surface.

- Do not block the air vents during operation.
- The appliance is equipped with overheat protection and an anti-tilt safety feature for maximum safety.
- Use the appliance only for its intended purpose as described in this manual.

3. Product Components

The Clatronic HBB 3734 includes the following main components:

- **Main Unit:** Contains the motor, heating element, and control panel.
- **Adjustable Balloon Body:** For drying and ironing shirts, blouses, and t-shirts (sizes XS-XXL).
- **Trouser Attachment:** For drying and ironing trousers.
- **Telescopic Rod:** Height-adjustable and removable for compact storage.



Image 3.1: This image displays the adjustable balloon body for shirts (left) and the specialized trouser attachment (right). Both attachments

offer maximum flexibility for various garment types and sizes.

4. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Assemble Telescopic Rod:** Insert the telescopic rod into the main unit. Adjust its height as needed for your garment.
3. **Attach Balloon Body/Trouser Attachment:** Depending on the garment you wish to process, securely attach either the adjustable balloon body or the trouser attachment to the top of the telescopic rod.
4. **Placement:** Place the assembled unit on a stable, heat-resistant surface. Ensure there is adequate space around the appliance for air circulation.
5. **Power Connection:** Plug the power cord into a suitable 220-240V, 50/60Hz electrical outlet.

5. Operating Instructions

Follow these steps for effective drying and ironing:

1. **Prepare Garment:** Ensure the garment is damp, ideally directly after washing and light spinning. If the garment is dry, lightly spray it with water.
2. **Mount Garment:**
    - **For Shirts/Blouses:** Carefully pull the shirt or blouse over the balloon body. Fasten buttons or zippers as appropriate. Smooth out any major wrinkles.
    - **For Trousers:** Attach the trouser attachment. Pull the trousers over the attachment, ensuring they are evenly distributed and smoothed.
3. **Set Timer:** Use the rotary knob on the main unit to set the desired operating time (up to 180 minutes). The LED indicator will illuminate. The appliance will begin to inflate the balloon body and generate warm air.
4. **Drying and Ironing Process:** The warm air will dry the garment while simultaneously smoothing out wrinkles. The duration depends on the garment material, thickness, and dampness.
5. **Remove Garment:** Once the timer finishes or the garment is dry and wrinkle-free, the appliance will automatically shut off. Carefully remove the garment from the balloon body or trouser attachment.



Image 5.1: A visual guide to the three main operating steps: 1. Mounting the garment onto the press, 2. Setting the timer on the control panel, and 3. Removing the perfectly smoothed garment after the cycle.

Tips for Best Results:

- For heavily wrinkled garments, ensure they are sufficiently damp.
- Adjust the balloon body size to match your garment for optimal tension.
- The appliance can also be used to refresh garments and neutralize odors.

6. Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your appliance.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Cool Down:** Allow the appliance to cool down completely before handling.

3. **Wipe Surfaces:** Wipe the main unit and attachments with a soft, damp cloth. Do not use abrasive cleaners or solvents.
4. **Air Vents:** Ensure the air vents are free from dust and lint. Use a soft brush or vacuum cleaner if necessary.
5. **Storage:** For compact storage, the telescopic rod can be removed. Store the appliance in a dry, safe place.

7. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; timer not set.	Check power connection; verify power supply; set the timer.
Garments are not wrinkle-free.	Garment too dry; incorrect balloon size; insufficient operating time.	Lightly dampen garment; adjust balloon size; increase timer duration.
Appliance stops unexpectedly.	Overheat protection activated; anti-tilt safety activated.	Unplug and allow to cool; ensure appliance is on a stable surface.
Unusual noise during operation.	Air vents blocked; internal component issue.	Check and clear air vents. If noise persists, contact customer support.

8. Technical Specifications

Feature	Specification
Model Number	HBB 3734
Power	1200 Watts
Voltage	220-240 V, 50/60 Hz
Dimensions (L x W x H)	26.6 x 32.7 x 20.2 cm (main unit)
Weight	3 Kilograms
Timer	Up to 180 minutes (automatic shut-off)
Material	Plastic
Noise Level	44 dB
Safety Features	Overheat protection, Anti-tilt safety



Image 8.1: Key features of the Clatronic HBB 3734, highlighting the stepless timer up to 180 minutes, 1200 Watts of power for fast results, and safety through automatic shut-off.



Image 8.2: This image shows the compact dimensions of the main unit (32 cm length, 27.5 cm height, 18 cm width) and illustrates how the telescopic rod and attachments can be stored to save space.

9. Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or contact your retailer. Keep your proof of purchase for any warranty claims.
For technical support or inquiries, please contact Clatronic customer service. Contact details can typically be found on the manufacturer's website or on your product packaging.

© 2023 Clatronic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question