Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NEUFDAY Neufdayyygyziho23cf

NEUFDAY Portable Protective Case for B&O BeoPlay A1 Bluetooth Speaker

Model: Neufdayyygyziho23cf
Brand: NEUFDAY

Introduction

This manual provides instructions for the NEUFDAY Portable Protective Case, designed specifically for the B&O BeoPlay A1 Bluetooth Speaker. This case offers robust protection and convenient portability for your speaker.



Image: The NEUFDAY protective case, designed for the B&O BeoPlay A1 Bluetooth speaker, shown in an outdoor setting, highlighting its wear-resistant, dirt-resistant, shock-resistant, and anti-fall properties.

Setup

The NEUFDAY Portable Protective Case requires minimal setup. Follow these steps to prepare your case for use:

1. **Unpacking:** Carefully remove the protective case and any accessories (such as the carabiner) from its packaging.
2. **Initial Inspection:** Inspect the case for any signs of damage or manufacturing defects. Ensure the zipper operates smoothly.
3. **Attachment of Carabiner:** If desired, attach the provided carabiner to the designated loop on the case for enhanced portability.



Image: The NEUFDAY protective case in its closed state, featuring the attached carabiner for easy carrying.

Operating Instructions

To effectively use your NEUFDAY Protective Case with your B&O BeoPlay A1 speaker, follow these instructions:

1. **Opening the Case:** Unzip the case completely to reveal the interior compartments.
2. **Inserting the Speaker:** Gently place your B&O BeoPlay A1 speaker into the main compartment of the case. Ensure it fits snugly without forcing.
3. **Storing Accessories:** Utilize the mesh pocket inside the case for storing small accessories such as charging cables or adapters.
4. **Closing the Case:** Zip the case securely to ensure the speaker is fully enclosed and protected.
5. **Carrying the Case:** Use the integrated handle or the attached carabiner to carry the case. The carabiner allows for attachment to bags or belts for hands-free transport.



Image: The interior of the open NEUFDAY protective case, showing the main compartment for the speaker.



Image: The interior of the open NEUFDAY protective case, highlighting the mesh pocket for accessory storage.



Image: A close-up of the NEUFDAY protective case, illustrating the carabiner design for convenient and easy carrying.

Maintenance

Proper maintenance ensures the longevity and protective qualities of your case:

- **Cleaning:** Wipe the exterior of the case with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by wiping with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Allow the case to air dry completely before storing your speaker inside or zipping it closed. Do not expose to direct sunlight or high heat.
- **Storage:** Store the case in a cool, dry place when not in use.
- **Zipper Care:** Periodically check the zipper for debris. If the zipper becomes stiff, a small amount of zipper lubricant can be applied.

Troubleshooting

If you encounter any issues with your protective case, refer to the following common solutions:

- **Zipper is Stuck:**
  - Check for any fabric or debris caught in the zipper teeth. Gently remove it.
  - Apply a small amount of graphite (from a pencil) or zipper lubricant to the teeth and try to move the zipper slowly.
- **Case Does Not Close Properly:**
  - Ensure the speaker is correctly positioned within the main compartment and not obstructing the zipper path.
  - Verify that no accessories are bulging out and preventing the case from closing.
- **Case Appears Damaged:**
  - For minor scuffs or dirt, refer to the "Maintenance" section for cleaning instructions.
  - For significant damage (e.g., tears, broken zipper), the case may need replacement.

Specifications

Feature	Detail
Product Type	Bluetooth Speaker Protective Case
Brand	NEUFDAY
Model Compatibility	B&O BeoPlay A1
Material	High-quality Nylon
Color	Black
Dimensions (Approx.)	15 cm (Diameter) × 5.5 cm (Height) / 5.9 inches (Diameter) × 2.2 inches (Height)
Weight (Approx.)	98 g
Features	Wear-resistant, Dirt-resistant, Shock-resistant, Anti-fall, Carabiner for easy carrying
Manufacturer Reference	Neufdayyygyziho23cf
Country of Origin	China



Image: The NEUFDAY protective case with its approximate dimensions labeled: 15 cm (5.9 inches) in diameter and 5.5 cm (2.2 inches) in height.

Warranty and Support

For information regarding warranty coverage or technical support, please refer to the seller's policies or contact the manufacturer directly. Specific warranty details are not provided in this manual.
Manufacturer: NEUFDAY
Seller: Wenruil (as per product listing)
For further assistance, please visit the product page on Amazon.com.be or contact customer service.

© 2024 NEUFDAY. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XYC2QZQ

More documents and user manuals: **https://manuals.plus/**