Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RM-C3090

ALLIMITY RM-C3090 Remote Control User Manual

Your guide to operating and maintaining your replacement remote control for JVC 4K UHD TVs.

1. Introduction

This user manual provides comprehensive instructions for the ALLIMITY RM-C3090 replacement remote control. Designed to be compatible with various JVC 4K UHD TV models, this remote offers a straightforward, ready-to-use solution for your television control needs. Please read this manual carefully to ensure proper use and longevity of your device.

2. Product Overview

The ALLIMITY RM-C3090 is a direct replacement remote control, eliminating the need for complex programming. It is designed to replicate the functionality of original JVC TV remotes for a seamless user experience.

2.1 Key Features

- **Direct Compatibility:** Specifically designed for JVC 4K UHD TV models including LT-24VH30K, LT-24VH42J, LT-24VH42K, LT-32V4200, LT-32V4201, LT-32VF43I, LT-32VH30K, LT-32VH42K, LT-39VF42K, LT-40V4200, LT-40VF42I, LT-40VF42K, LT-40VF43A, LT-43V2100, LT-43V44JF, LT-49V4200, LT-50VF30K.
- **No Setup Required:** Operates immediately upon battery insertion.
- **Standard Functionality:** Provides full control over TV functions such as power, volume, channel selection, menu navigation, and input switching.
- **Durable Design:** Constructed for reliable daily use.

2.2 Product Images



Figure 1: Front view of the ALLIMITY RM-C3090 remote control, showing all buttons including power, number pad, volume, channel, menu, and navigation keys.



Figure 2: Angled view of the remote control, highlighting its ergonomic shape and button layout.



Figure 3: Rear view of the remote control with the battery cover removed, showing the battery compartment.

3. Setup

Setting up your ALLIMITY RM-C3090 remote control is quick and easy. No programming or pairing is required.

1. **Open the Battery Compartment:** Locate the battery cover on the back of the remote control. Slide the cover downwards or press the latch to open it.
2. **Insert Batteries:** Insert two (2) AAA batteries (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
3. **Close the Battery Compartment:** Replace the battery cover by sliding it back into place until it clicks securely.
4. **Ready to Use:** The remote control is now ready to operate your compatible JVC 4K UHD TV.

4. Operating Instructions

The ALLIMITY RM-C3090 remote control functions identically to your original JVC TV remote. Below are common operations:

- **Power On/Off:** Press the **Power** button (usually red, top left) to turn the TV on or off.
- **Channel Selection:** Use the **CH+/-** buttons to change channels sequentially, or the number pad (0-9) to enter a specific channel number.
- **Volume Control:** Press the **VOL+/-** buttons to adjust the volume level.
- **Mute:** Press the **Mute** button to temporarily silence the TV audio.
- **Menu Navigation:** Use the **MENU** button to access the TV's on-screen menu. Use the directional arrow buttons (Up, Down, Left, Right) and the **OK** button to navigate and select options.
- **Input/Source:** Press the **Input** or **Source** button to switch between different video inputs (e.g., HDMI, AV).
- **Smart TV/App Access:** If your TV supports it, dedicated buttons for smart features or streaming apps may be present and functional.

5. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

6. Troubleshooting

If you encounter issues with your remote control, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Remote is not working.	Dead or incorrectly inserted batteries. Obstruction between remote and TV. TV's IR sensor is blocked.	Replace batteries, ensuring correct polarity. Remove any obstructions. Ensure a clear line of sight to the TV's IR sensor.
Buttons are unresponsive or sticky.	Dirt or debris under buttons. Worn-out internal contacts.	Clean the remote surface. If cleaning doesn't help, the remote may need replacement.
Remote only works sometimes.	Low battery power. Intermittent signal interference.	Replace batteries. Ensure no strong light sources (like direct sunlight) are interfering with the TV's IR sensor.

If the issue persists after trying these steps, please refer to the Warranty and Support section.

7. Specifications

Feature	Detail
Model Number	RM-C3090
Brand	ALLIMITY
Compatible Devices	JVC 4K UHD Televisions (Specific models listed in Section 2.1)
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	4 x 0.9 x 19 cm
Item Weight	50 Grams
Color	Black

8. Warranty and Support

ALLIMITY provides a 90-day warranty for this product, ensuring excellent return service.

- **Warranty Period:** 90 days from the date of purchase.
- **Return Service:** Contact the seller for any issues or return inquiries within the warranty period.
- **Customer Support:** If you require further assistance or have questions not covered in this manual, please contact the seller directly.

For contact information, please refer to your purchase documentation or the seller's page on the platform where the product was acquired.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Y12WKVH

More documents and user manuals: **https://manuals.plus/**