Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RC4862

ALLIMITY RC4862 Replacement Remote Control User Manual

Model: RC4862 | Brand: ALLIMITY

1. Introduction

This user manual provides essential information for the operation and maintenance of your ALLIMITY RC4862 Replacement Remote Control. This remote is designed as a direct replacement for various Hitachi TV models, offering seamless functionality without the need for complex setup or programming.





Figure 1: Front view of the ALLIMITY RC4862 Replacement Remote Control.

2. Setup

2.1 Battery Installation

The ALLIMITY RC4862 remote control requires two AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.







Figure 2: Rear view of the remote control showing the open battery compartment.

2.2 Initial Use

No programming or pairing is required. Once batteries are installed, the remote control is ready for immediate use with compatible Hitachi TV models.

3. Operating Instructions

The ALLIMITY RC4862 remote control provides full functionality for your Hitachi TV. Below are common button functions:

- **Power Button (●):** Turns the TV on or off.
- **Number Buttons (0-9):** Direct channel selection.
- **Volume Up/Down (V+/V-):** Adjusts the volume level.
- **Channel Up/Down (P+/P-):** Changes the TV channel.
- **Mute Button ( ):** Mutes or unmutes the TV sound.
- **Menu Button:** Accesses the TV's main menu.
- **OK Button:** Confirms selections within menus.
- **Navigation Buttons (Up, Down, Left, Right):** Navigates through menus and options.
- **Back Button:** Returns to the previous screen or menu.
- **Exit Button:** Exits the current menu or application.
- **Input/Source Button ( ):** Selects input sources (HDMI, AV, etc.).
- **Colored Buttons (Red, Green, Yellow, Blue):** Functionality varies by TV model and application.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback.

3.1 Compatible Hitachi TV Models

This remote control is compatible with the following Hitachi TV models:

- HBC06
- 22HYC06
- 24HBC05A
- 24HXC05
- 24HYC05
- 28HYC05
- 32HB6T41
- 32HBC01
- 32HBC01A
- 32HBC01B
- 32HBT01
- 32HBT01A
- 32HXC41
- 32HYC01
- 32HYC41
- 32HZT65

- 32HZT66
- 40HXC46
- 40HYC42
- 42HZT66
- 50HXC46
- 50HYC42

4. Maintenance

4.1 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or immerse the remote in water.

4.2 Battery Replacement

Replace batteries when the remote control becomes unresponsive or its range decreases. Always replace both batteries at the same time with new ones of the same type (AAA). Dispose of used batteries responsibly according to local regulations.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	• Batteries are dead or incorrectly inserted. • Obstruction between remote and TV. • Remote control sensor on TV is blocked.	• Replace batteries with new ones, ensuring correct polarity. • Remove any objects blocking the line of sight to the TV. • Ensure the TV's infrared sensor is clear.
Buttons are unresponsive or sticky.	• Dirt or debris under buttons. • Worn out internal contacts.	• Clean the remote control as described in Section 4.1. • If cleaning doesn't help, the remote may need replacement.
Remote works intermittently.	• Low battery power. • Interference from other electronic devices.	• Replace batteries. • Move other electronic devices away from the TV or remote.

6. Specifications

Brand	ALLIMITY
Model Number	RC4862
Connectivity Technology	Infrared (IR)

Compatible Devices	Hitachi TVs (HBC06, 22HYC06, 24HBC05A, 24HXC05, 24HYC05, 28HYC05, 32HB6T41, 32HBC01, 32HBC01A, 32HBC01B, 32HBT01, 32HBT01A, 32HXC41, 32HYC01, 32HYC41, 32HZT65, 32HZT66, 40HXC46, 40HYC42, 42HZT66, 50HXC46, 50HYC42)
Power Source	2 x AAA Batteries (not included)
Maximum Range	10 Meters
Number of Buttons	40

7. Warranty and Support

This product comes with a 90-day warranty, ensuring excellent return service. If you encounter any issues or require assistance, please do not hesitate to contact the seller for support.
For further inquiries, please refer to the seller's contact information provided at the point of purchase.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Y19ZMBX

More documents and user manuals: **https://manuals.plus/**