Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tosuny T1

Tosuny T1 MP3/MP4 Player Instruction Manual

Model: T1 (Tosuny2fm0v95nwy-02)

1. Product Overview

The Tosuny T1 is a portable digital media player designed for music, video, image, and e-book playback. It features Bluetooth connectivity, an FM radio, and a voice recording function. The device supports a 32GB memory card for expanded storage.



Figure 1: Front view of the Tosuny T1 MP3/MP4 Player showing the display and control buttons.

2. Package Contents

Ensure all items are present in the package:

- 1 x Tosuny T1 MP3/MP4 Player
- 1 x Data Cable (USB)
- 1 x Headphone Cable (Earphones)

- 1 x User Manual



Figure 2: The MP3/MP4 player along with its USB data cable and earphones.

3. Setup

3.1 Charging the Device

Before first use, fully charge the player. Connect the provided USB data cable to the player's charging port and to a USB power source (e.g., computer, USB wall adapter). The built-in 250mAh lithium-polymer battery requires approximately 90 minutes for a full charge. A full charge provides 4-6 hours of continuous use.



Figure 3: The player's screen showing a battery indicator, signifying its built-in 250mAh polymer lithium battery.

3.2 Inserting a Memory Card

The player supports memory cards up to 32GB. Locate the memory card slot on the side of the device. Gently insert the memory card until it clicks into place. The player is plug-and-play, meaning it will recognize the card automatically.

3.3 Powering On/Off

Locate the ON/OFF switch on the side of the device. Slide the switch to the "ON" position to power on the player. Slide it to the "OFF" position to power off.



Figure 4: The bottom edge of the player, highlighting the headphone jack, ON/OFF switch, and USB port.

3.4 Language Settings

The player comes with English as the default language and supports 13 other languages. To change the language, navigate to the "Set" menu icon on the main screen and select "Language" to choose your preferred option.

4. Operating Instructions

4.1 Button Functions

- **M (Menu) Button (Top Left):** Tap to display the menu interface.
- **Back Button (Top Right):** Short press to exit the current menu or volume setting. Long press to exit to the main menu mode.
- **LAST Button (Left):** Short press to go to the previous file/track. Long press to rewind.
- **NEXT Button (Right):** Short press to go to the next file/track. Long press for fast forward.
- **+ Button (Above):** Increase volume or move menu selection upwards.
- **- Button (Below):** Decrease volume or move menu selection downwards.
- **Middle Button (Play/Pause):** Short press to play or pause. Long press to stop playback.



Figure 5: Detailed view of the player's buttons and their layout.

4.2 Media Playback

The player supports various media types:

- **Music:** Supports MP3 format. Navigate to the "Music" icon and select your desired audio file.
- **Video:** Supports AMV format. Navigate to the "Video" icon and select your desired video file.
- **Images:** Supports JPG and JPEG formats. Navigate to the "PIC" (Picture) icon to view images.
- **E-books:** Supports TXT format. Navigate to the "EBook" icon to read text files.



Figure 6: The player's screen showing icons for various functions, confirming support for MP3 music and AMV video formats.



Figure 7: The player supports multiple functions including music, radio, recording, video, e-book, and a built-in stopwatch.

4.3 Bluetooth Connectivity

The player supports Bluetooth 4.2, compatible with most Bluetooth devices. To pair with a Bluetooth headphone or speaker:

1. Turn on your Bluetooth audio device and set it to pairing mode.
2. On the player, navigate to the "Bluetooth" menu icon.
3. Select "Search Device" or similar option.
4. Choose your device from the list and confirm pairing.

4.4 Additional Functions

- **Radio:** Access the "Radio" icon to listen to FM radio.
- **Recording:** Use the "REC" (Record) icon to access the voice recording function.
- **Stopwatch:** The player includes a built-in stopwatch function, accessible via its icon.
- **Timed Shutdown:** This feature allows you to set a timer for the device to automatically power off.
- **Power Saving Mode:** Adjust settings for power saving and sleep mode to optimize battery life.

5. Maintenance

To ensure the longevity and optimal performance of your Tosuny T1 player:

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid liquid cleaners.
- **Handling:** The player features a matte, anti-slip body. Handle with care to prevent drops or impacts.
- **Battery Care:** Avoid extreme temperatures. Charge the battery regularly, even if not in frequent use, to maintain battery health.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and moisture.



Figure 8: The player's matte non-slip body and power-saving features make it suitable for various uses, including relaxation.

6. Troubleshooting

If you encounter issues with your Tosuny T1 player, refer to the following common solutions:

- **Device not powering on:** Ensure the battery is charged. Connect the player to a power source and try again. Check the ON/OFF switch is in the "ON" position.
- **Player not recognized by computer:** Ensure the USB cable is securely connected to both the player and the computer. Try a different USB port or cable. Restart both the player and the computer.
- **Cannot transfer files:** Verify the memory card is properly inserted. Ensure the player is connected to the computer in data transfer mode (if prompted).
- **Bluetooth pairing issues:** Ensure the Bluetooth device is in pairing mode and within range. Restart both the player and the Bluetooth device.
- **Unresponsive buttons:** Power off the device and then power it back on. If the issue persists, ensure the device is not in a locked mode.
- **Poor sound quality:** Check headphone connection. Ensure volume is adjusted correctly. Test with different headphones.

7. Specifications

Feature	Specification
Model Name	T1
Brand	Tosuny
Display Size	1.8 Inch
Display Technology	LCD

Feature	Specification
Battery Capacity	250mAh Lithium Polymer
Continuous Use Time	4-6 hours (Music playback)
Charging Time	Approx. 90 minutes
Max. Supported Memory Card	32GB (Micro SD)
Music Format Support	MP3
Video Format Support	AMV
Image Format Support	JPG, JPEG
E-book Format Support	TXT
Bluetooth Version	4.2
Dimensions	Approx. 9 x 4 x 1 cm
Special Features	Portable, FM Radio, Voice Recording, Stopwatch, Timed Shutdown, Power Saving Mode
Languages	Chinese, English, German, French, Spanish, Portuguese, Japanese, Turkish, Russian, Indonesian, Thai, Vietnamese, Hebrew

8. Warranty and Support

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. For technical support or further assistance, please contact the manufacturer, Tosuny, or your point of purchase.

© 2023 Tosuny. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Y36QKZD

More documents and user manuals: **https://manuals.plus/**