Nikai NWM1010T5D

Nikai NWM1010T5D Fully Automatic Top Load Washing Machine User Manual

Model: NWM1010T5D

1. Introduction

This manual provides essential information for the safe and efficient operation of your Nikai NWM1010T5D Fully Automatic Top Load Washing Machine. Please read it thoroughly before using the appliance and retain it for future reference.

1.1 Safety Information

- Ensure the washing machine is installed on a stable, level surface to prevent vibration and noise.
- Connect the appliance to a grounded power outlet with the correct voltage (240V).
- Do not allow children to operate or play near the washing machine.
- Do not wash items that are soiled with flammable substances.
- Always unplug the machine before cleaning or performing any maintenance.
- Do not open the lid during a wash or spin cycle.

2. Product Overview

2.1 Components

Familiarize yourself with the main components of your washing machine.



Image: Front view of the Nikai NWM1010T5D Fully Automatic Top Load Washing Machine, showing the control panel on top, the main body, and the feet. A label indicating '2 Year' warranty is visible on the upper left, and an energy efficiency label on the upper right. A graphic on the lower front depicts the washing action inside the drum.

2.2 Control Panel

The control panel, located on the top of the machine, allows you to select wash programs, adjust settings, and start/pause cycles. Refer to the labels on your specific unit for detailed button functions.

3. Setup

3.1 Unpacking

- Carefully remove all packaging materials, including the base packaging.
- Inspect the machine for any damage incurred during transit. Contact your retailer immediately if damage is found.
- Remove any protective films or tapes from the appliance.

3.2 Installation

- Place the washing machine on a firm, level floor.
- Adjust the leveling feet at the bottom of the machine to ensure it is perfectly stable and does not wobble. Use a spirit level for accuracy.
- Ensure there is adequate space around the machine for ventilation and access.

3.3 Water and Power Connection

- Connect the water inlet hose to the cold water tap and the corresponding inlet on the back of the machine. Ensure connections are tight to prevent leaks.
- Position the drain hose into a suitable drain pipe or sink, ensuring it is securely fixed and at the correct height to prevent siphoning.

- Plug the power cord into a grounded 240V electrical outlet.

4. Operating Instructions

4.1 Loading Laundry

- Sort laundry by fabric type, color, and degree of soiling.
- Open the top lid and place items loosely into the drum, avoiding overloading. The maximum wash capacity is 9 kg.
- Close the lid securely.

4.2 Adding Detergent

- Add the appropriate amount of detergent to the detergent dispenser according to the detergent manufacturer's instructions and the load size.
- For fabric softener, add it to the designated compartment in the dispenser.

4.3 Program Selection

- Turn on the washing machine.
- Select the desired wash program using the control panel. Available programs may include options for different fabric types or soil levels.
- Adjust additional settings such as water level, rinse cycles, or spin speed if available and desired.

4.4 Starting a Wash Cycle

- Press the 'Start/Pause' button to begin the selected wash cycle.
- The machine will automatically fill with water, wash, rinse, and spin.
- Once the cycle is complete, the machine will signal, and the lid will unlock.
- For drying, the machine offers 100% drying capability for loads up to 3 kg. Select the appropriate drying function after the wash cycle, if available.

5. Maintenance

5.1 Cleaning the Exterior

- Wipe the exterior of the machine with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.

5.2 Filter Care

- Regularly clean the lint filters to ensure efficient operation. Refer to your machine's specific design for filter location and removal instructions.
- The machine features double filters for improved lint collection.

6. Troubleshooting

Before contacting service, check the following common issues:

Problem	Possible Cause	Solution
Machine does not start	Power cord unplugged; Lid not closed properly; No water supply.	Check power connection; Ensure lid is fully closed; Check water tap and hose.
Excessive vibration/noise	Machine not level; Load unbalanced.	Adjust leveling feet; Redistribute laundry evenly in the drum.
Water leakage	Hoses loose; Drain hose improperly positioned.	Tighten hose connections; Secure drain hose.
Clothes not drying properly	Overloaded dryer; Lint filter clogged.	Reduce load size (max 3kg for drying); Clean lint filters.

This model features a self-diagnostic system with a pump. If an error code appears on the display, consult the full service manual or contact customer support.

7. Specifications

Feature	Value
Brand	Nikai
Model Number	NWM1010T5D
Type	Fully Automatic Top Load Washing Machine with Dryer
Wash Capacity	9 kg
Drying Capacity	Up to 3 kg (100% Dryer)
Color	Grey
Material	Mixed
Voltage	240 Volts
Installation Type	Freestanding
Product Dimensions (W x D x H)	62 x 66 x 104 cm
Item Weight	Approx. 40 kg (Shipping weight provided as 40 kg, item weight listed as 50g which is likely a typo)
Special Features	Air Dry & Hot Dry Functions, Double Filters, Anti-Wrinkle, Anti-Rust, Self-Diagnostic with Pump
Date First Available	September 19, 2019

8. Warranty and Support

Your Nikai NWM1010T5D washing machine comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical assistance, service requests, or to purchase genuine spare parts, please contact Nikai customer support through their official website or the contact information provided in your warranty documentation.

Always ensure that any repairs or maintenance are performed by authorized service personnel to maintain the validity of your warranty.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question