Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LASIKA W-F 77

LASIKA W-F 77 Digital Sport Watch User Manual

Model: W-F 77

Introduction Product Overview Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides comprehensive instructions for the proper use and maintenance of your LASIKA W-F 77 Digital Sport Watch. Please read this manual thoroughly before operating the watch to ensure optimal performance and longevity. Keep this manual for future reference.

2. Product Overview

The LASIKA W-F 77 is a versatile digital sport watch designed for unisex use. It features a durable resin band and case, a clear digital display, and multiple functions suitable for daily wear and sports activities.



Figure 1: Front view of the LASIKA W-F 77 Digital Sport Watch. This image displays the front view of the Lasika W-F 77 digital sport watch. It features a black resin case and band with yellow accents. The digital display shows the time, day of the week, and icons for alarm and chime. Compass directions (N, S, E, W, NE, NW, SE, SW) are marked around the bezel. Buttons are visible on the sides, labeled 'MODE', 'LIGHT', 'START/RESET', and 'CHIME'.

Key Features:

- Digital Time Display
- Alarm Function
- Stopwatch
- Backlight for low-light conditions
- Hourly Chime
- Durable Resin Construction

Button Functions:

- **MODE Button:** Cycles through display modes (Time, Alarm, Stopwatch).
- **LIGHT Button:** Activates the backlight.
- **START/RESET Button:** Used for starting/stopping stopwatch, adjusting settings, or resetting values.
- **CHIME Button:** Used for setting or activating/deactivating alarm and hourly chime.

3. Setup

Initial Power-On:

Your watch comes with a pre-installed battery. If the display is blank, press any button to activate it. If it remains blank, the battery may need replacement (refer to Maintenance section).

Setting the Time and Date:

1. From the normal time display, press the **MODE** button three times to enter Time Setting mode. The seconds digits will begin to flash.
2. Press the **START/RESET** button to reset the seconds to 00.
3. Press the **CHIME** button to move the flashing selection to the hour digits.
4. Press the **START/RESET** button to adjust the hour. Pay attention to AM/PM indicators if present.
5. Press the **CHIME** button to move the flashing selection to the minute digits.
6. Press the **START/RESET** button to adjust the minutes.
7. Continue pressing the **CHIME** button to cycle through and set the month, date, and day of the week using the **START/RESET** button.
8. Once all settings are correct, press the **MODE** button to exit Time Setting mode and return to the normal time display.

4. Operating Instructions

4.1 Using the Backlight

Press the **LIGHT** button to illuminate the display for a few seconds. This feature is useful in low-light conditions.

4.2 Alarm Function

1. From the normal time display, press the **MODE** button once to enter Alarm mode. The alarm time will be displayed.
2. Press the **CHIME** button to toggle the alarm ON/OFF. An alarm icon will appear/disappear on the display.

3. To set the alarm time, press the **START/RESET** button. The hour digits will flash.
4. Press the **CHIME** button to adjust the hour.
5. Press the **START/RESET** button to move to the minute digits.
6. Press the **CHIME** button to adjust the minutes.
7. Press the **START/RESET** button to confirm and exit alarm time setting.
8. Press the **MODE** button to return to the normal time display.
9. When the alarm sounds, press any button to stop it.

4.3 Stopwatch Function

1. From the normal time display, press the **MODE** button twice to enter Stopwatch mode. The display will show 00:00:00.
2. Press the **START/RESET** button to start the stopwatch.
3. Press the **START/RESET** button again to pause the stopwatch.
4. To resume, press the **START/RESET** button.
5. To reset the stopwatch to zero, ensure it is paused, then press the **CHIME** button.
6. Press the **MODE** button to exit Stopwatch mode and return to the normal time display.

4.4 Hourly Chime (Hourly Signal)

To activate or deactivate the hourly chime:

1. From the normal time display, press the **MODE** button once to enter Alarm mode.
2. Press the **START/RESET** button to toggle the hourly chime ON/OFF. A small icon (often a bell or speaker) will appear/disappear to indicate its status.
3. Press the **MODE** button to return to the normal time display.

5. Maintenance

Cleaning:

Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.

Water Resistance:

The LASIKA W-F 77 is designed for daily use and can withstand splashes or brief immersion. However, it is not suitable for swimming, diving, or hot water activities. Avoid pressing buttons underwater.

Battery Replacement:

When the display becomes dim or functions irregularly, the battery may need replacement. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and water resistance. Opening the watch yourself may void any potential warranty.

6. Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low or depleted battery.	Replace the battery.

Problem	Possible Cause	Solution
Time is incorrect.	Time not set correctly or accidental adjustment.	Refer to "Setting the Time and Date" section to reset.
Buttons are unresponsive.	Watch may be in a locked mode (unlikely for this model) or battery is very low.	Try pressing all buttons firmly. If issue persists, replace battery.
Alarm does not sound.	Alarm is not activated or alarm time is incorrect.	Ensure alarm is set and activated (alarm icon visible). Refer to "Alarm Function" section.

If the problem persists after attempting these solutions, please contact customer support.

7. Specifications

- **Model Number:** W-F 77
- **Display Type:** Digital
- **Targeted Group:** Unisex
- **Brand:** LASIKA
- **Band Material:** Resin
- **Watch Shape:** Round
- **Type:** Sport Watch
- **Case Material:** Resin
- **Package Dimensions:** 4.17 x 3.46 x 2.29 cm
- **Item Weight:** Approximately 0.32 g (watch only)

8. Warranty and Support

Specific warranty information for your LASIKA W-F 77 watch may vary depending on your region and point of purchase. Please refer to the warranty card included with your product or contact your retailer for details.
For technical support or inquiries, please contact the LASIKA customer service department or your authorized dealer. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Y78W4HF

More documents and user manuals: **https://manuals.plus/**