ALLIMITY AMT-AMZ-CV98LM

Allimity CV98LM Replacement Remote Control User Manual

Model: CV98LM / AMT-AMZ-CV98LM

Introduction

This manual provides comprehensive instructions for the Allimity CV98LM Replacement Remote Control. This remote is designed as a direct replacement for specific Amazon TV Stick and Amazon TV Box models. Please read this manual carefully before use to ensure proper operation and compatibility.

Important Note: This remote control does NOT include a microphone and does NOT support voice-operated functions.

Product Overview

Remote Control Layout



This image illustrates the layout of the Allimity CV98LM remote control, highlighting key buttons such as Navigation, Select, Back, Home, Menu, Fast Forward, Play/Pause, and Rewind. The remote measures approximately 4.6 inches in length and 1.7 inches in width.

Front View





A clear front view of the Allimity CV98LM remote control, showcasing its ergonomic design and button placement. The remote features a matte black finish.

Compatibility

The Allimity CV98LM Replacement Remote Control is compatible with the following Amazon TV Stick and Amazon TV Box models:

- **Amazon TV Stick and Amazon TV Box (1st Generation):**Models W87CUN, CL1130
- **Amazon TV Stick and Amazon TV Box (2nd Generation):**Models DV83YW, PE59CV

If your device model is not listed, please contact customer support for assistance.

Setup: Pairing Instructions

Follow these steps to pair your new Allimity CV98LM remote control with your Amazon TV Stick or Amazon TV Box:

1. **Power Cycle Your Device:** Unplug the power supply from your Amazon TV Stick or Amazon TV Box. Wait for a few seconds, then plug it back in.
2. **Initiate Pairing:** Once your device has restarted, hold down the⌂ (Home button) on your new Allimity remote control. Continue holding the button for up to 60 seconds or more. You may need to attempt this step multiple times.
   The Home button is typically marked with a house or arrow symbol.
3. **Confirmation:** The remote should pair with your device. If pairing is successful, you will be able to navigate your Amazon TV interface.
4. **Troubleshooting Pairing Issues:** If the remote fails to pair after several attempts, try unplugging and replugging your Amazon TV Stick/Box power supply multiple times before repeating step 2. All remotes are tested before shipping to ensure functionality.

If you continue to experience difficulties pairing the remote after many tries, please refer to the "Troubleshooting" section or contact customer support.

Operating the Remote Control

The Allimity CV98LM remote control provides essential functions for navigating your Amazon TV device. Familiarize yourself with the button layout for optimal use.

- **Navigation Ring:** Use the circular ring to move up, down, left, and right within menus and content.
- **Select Button:** The central button within the navigation ring is used to confirm selections or play content.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button (⌂):** Takes you directly to the home screen of your Amazon TV device.
- **Menu Button (≡):** Accesses contextual menus or options within applications.
- **Rewind (◀◀):** Rewinds video playback.
- **Play/Pause ( ):** Plays or pauses video content.
- **Fast Forward (▶▶):** Fast forwards video playback.

Note: This remote does not have dedicated volume buttons or a voice control button.

Maintenance

Battery Installation and Replacement

The Allimity CV98LM remote control requires two AAA batteries (not included).

1. **Open Battery Compartment:** Locate the battery cover on the back of the remote control. Slide the cover downwards to open it.



This image shows the back of the Allimity CV98LM remote control with the battery cover removed, revealing the two AAA battery slots.

2. **Insert Batteries:** Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. **Close Battery Compartment:** Slide the battery cover back into place until it clicks securely.

Important:

- Always use new batteries of the same type.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

Troubleshooting

If you encounter issues with your Allimity CV98LM remote control, please consult the following common problems and solutions:

Problem	Possible Cause / Solution
Remote not responding / Not pairing	**Batteries:** Ensure batteries are correctly inserted and have sufficient charge. Replace with new AAA batteries if necessary. **Power Cycle:** Unplug your Amazon TV Stick/Box from power for a few seconds, then plug it back in. **Re-pairing:** Follow the "Setup: Pairing Instructions" carefully, holding the Home button for an extended period (up to 60 seconds or more) and trying multiple times. **Interference:** Ensure there are no obstructions between the remote and your Amazon TV device.
Buttons are sticky or unresponsive	**Cleanliness:** Dust or debris might be under the buttons. Gently clean around the buttons with a soft, dry cloth. **Battery Leakage:** Check the battery compartment for any signs of leakage. If present, clean thoroughly and replace batteries.
Remote works intermittently	**Low Batteries:** Replace batteries with fresh ones. **Distance:** Ensure you are within effective range of your Amazon TV device. **Re-pairing:** Attempt to re-pair the remote as described in the "Setup" section.

If the problem persists after trying these solutions, please contact Allimity customer service for further assistance.

Specifications

Feature	Detail
Model Number	CV98LM / AMT-AMZ-CV98LM
Product Material	Plastic
Dimensions (L x W x H)	5 x 2 x 0.7 inches (approximately)
Item Weight	1 ounce (approximately)
Batteries Required	2 x AAA batteries (not included)
Special Feature	Ergonomic design
Color	Black
Voice Function	Not supported (No MIC)

Warranty and Support

Allimity products are designed for reliability and performance. If you experience any issues or have questions regarding your CV98LM Replacement Remote Control, please do not hesitate to contact our customer service team.

Customer Service: Please contact us directly via the Amazon message box. Our customer service team aims to respond within 24 hours to assist you with any concerns or troubleshooting needs.

We only list the model numbers we have known. If you cannot find your specific model listed under compatibility, please contact us via email, and we will help you find the correct remote control you need.

© 2024 ALLIMITY. All rights reserved.

Amazon, Amazon TV Stick, and Amazon TV Box are trademarks of Amazon.com, Inc. or its affiliates.