Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

maXpeedingrods ZY1020 / 3002038412

maXpeedingrods 500W 24V DC Electric Motor User Manual

Model: ZY1020 / 3002038412

INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your maXpeedingrods 500W 24V DC Electric Motor. Please read this manual thoroughly before use to ensure proper function and longevity of the product.



Figure 1: maXpeedingrods 500W 24V DC Electric Motor with included sprocket and mounting bracket.

The maXpeedingrods 500W 24V DC Electric Motor (Model ZY1020/MY1020) is a high-speed, brushed motor designed for various electric vehicle applications, including scooters, mini bikes, and go-karts. It delivers reliable performance with a rated power of 500W and a speed of 2500 RPM.



Figure 2: The 500W 24V DC electric motor is suitable for a wide range of applications, including electric scooters and other small electric vehicles.

Safety Information

Always observe the following safety precautions to prevent injury or damage to the motor:

- Ensure the power supply matches the motor's voltage (24V DC) and current requirements.
- Disconnect power before performing any installation, maintenance, or troubleshooting.
- Avoid touching moving parts, especially the sprocket, during operation.
- Install the motor in a well-ventilated area to prevent overheating.
- Securely mount the motor using the provided bracket to prevent vibration and movement.
- Keep children and pets away from the motor during operation.
- Do not expose the motor to water or excessive moisture.

Product Features

The maXpeedingrods 500W 24V DC Electric Motor boasts several key features designed for optimal performance:

- **High Power Output:** Rated at 500 Watts for robust performance.
- **Optimal Speed:** Achieves a nominal speed of 2500 RPM.
- **Standard Sprocket:** Equipped with an 11-tooth sprocket, 6.35mm pitch, compatible with #25 chain.
- **Versatile Application:** Suitable for electric scooters, mini bikes, electric skateboards, and small electric cars.
- **Durable Construction:** Designed for reliability and long service life.



Figure 3: The motor features a high-speed design and a durable, high-hardness sprocket for reliable power transmission.

Specifications

Detailed technical specifications for the maXpeedingrods 500W 24V DC Electric Motor:

Parameter	Value
Model	ZY1020, MY1020
Input Voltage	24V DC
Rated Power	500 W
Rated Speed	2500 RPM
Rated Current	26.7 A
Number of Teeth (Sprocket)	11 teeth
Sprocket Pitch	6.35 mm
Compatible Chain	#25 Chain
Motor Type	DC, Brush
Product Dimensions (L x W x H)	22 x 16 x 16 cm (approx. 8.66 x 6.3 x 6.3 inches)
Item Weight	4.2 kg (approx. 9.26 lbs)




Figure 4: Detailed dimensions of the motor, crucial for proper fitment and installation.



Valtage:	24V DC
Rated Current:	26.7 A
Sprocket Type:	25
Power:	Max 500 W
Type of Motor:	DC, Brush
Chain Drive:	11 Teeth Sprocket, #25 Chain

Figure 5: Summary of key electrical and mechanical specifications.

Setup & Installation

Proper installation is crucial for the motor's performance and safety. Follow these general guidelines:

1. **Mounting:** Securely attach the motor using its integrated mounting bracket to a stable and rigid surface. Ensure all mounting bolts are tightened to prevent vibration.
2. **Sprocket Installation:** The motor comes with an 11-tooth sprocket. Ensure it is properly aligned with the driven sprocket on your application (e.g., wheel, axle) and that the chain tension is correct.
3. **Wiring:** Connect the motor to a 24V DC power source. Pay close attention to polarity (red wire typically positive, black wire negative). Incorrect wiring can damage the motor or power supply. It is recommended to use appropriate gauge wires and connectors for the rated current.
4. **Controller Integration:** If using a motor controller, follow the controller's specific wiring diagram and instructions for connecting it to the motor and power source.



Figure 6: Various views of the motor components, including the sprocket, mounting bracket, and wiring connections, aiding in installation.



Figure 7: Detail of the motor's output shaft and sprocket, showing the secure nut and washer assembly.



Figure 8: Detail of the motor's power wiring, showing the red and black wires for connection to the DC power source.

Operating Instructions

Once installed, operating the motor is straightforward:

- Ensure all connections are secure and the motor is properly mounted.
- Apply 24V DC power to the motor. The motor will begin to rotate.
- If using a speed controller, adjust the input signal to control the motor's speed.
- Monitor the motor for any unusual noises, excessive heat, or vibrations during initial operation.

Maintenance

Regular maintenance helps ensure the longevity and optimal performance of your motor:

- **Cleaning:** Keep the motor clean and free from dust, dirt, and debris. Use a dry cloth or compressed air.

- **Inspection:** Periodically inspect the motor for any signs of wear, damage, or loose connections. Check the sprocket and chain for proper alignment and tension.
- **Lubrication:** The motor's internal bearings are typically sealed and do not require lubrication. However, ensure any external moving parts connected to the motor (e.g., chain, bearings in the driven system) are properly lubricated according to their respective manuals.
- **Brush Replacement:** As a brushed DC motor, the carbon brushes will wear over time. If motor performance degrades significantly, brush replacement may be necessary. Consult a qualified technician or the manufacturer for brush replacement procedures.

Troubleshooting

Refer to the following table for common issues and their potential solutions:

Problem	Possible Cause	Solution
Motor does not run	No power, incorrect wiring, faulty switch/controller, worn brushes.	Check power supply, verify wiring polarity, test switch/controller, inspect brushes.
Motor runs slowly or weakly	Low voltage, excessive load, worn brushes, internal damage.	Ensure correct 24V supply, reduce load, replace brushes, consult technician.
Motor makes unusual noise	Loose mounting, worn bearings, foreign object, chain/sprocket misalignment.	Tighten mounting bolts, inspect bearings, remove obstructions, adjust chain/sprocket.
Motor overheats	Excessive load, insufficient ventilation, prolonged operation.	Reduce load, ensure proper airflow, allow motor to cool down periodically.

If the problem persists after attempting these solutions, please contact customer support.

Warranty and Support

maXpeedingrods products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official maXpeedingrods website.
For technical support, spare parts, or any inquiries not covered in this manual, please contact maXpeedingrods customer service through their official channels. When contacting support, please have your product model number (ZY1020 or 3002038412) and purchase details ready.
You can find more information and contact details on the official maXpeedingrods website:www.maxpeedingrods.com

© 2025 maXpeedingrods. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Y9ND43K

More documents and user manuals: **https://manuals.plus/**