Taylor Swoden Smartheat

Taylor Swoden 8-Liter Dual Blaze Air Fryer XXL 2000W Instruction Manual

Model: Smartheat

1. Important Safety Instructions

Please read this manual thoroughly before using the appliance and save it for future reference. Incorrect operation due to disregard of instructions may cause harm or damage.

- Always ensure the appliance is plugged into a grounded outlet.
- Do not immerse the cord, plug, or the appliance housing in water or other liquids to prevent electric shock.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use accessories not recommended by the appliance manufacturer, as this may cause injuries.
- Do not place the appliance against a wall or against other appliances. Leave at least 10 cm free space on the back and sides and 10 cm free space above the appliance.
- Do not place anything on top of the appliance.
- Do not use the appliance for any purpose other than described in this manual.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not touch hot surfaces. Use handles or knobs.
- The appliance is not intended to be operated by means of an external timer or separate remote-control system.

2. Product Overview

The Taylor Swoden Dual Blaze Air Fryer is designed for healthy cooking with minimal oil, utilizing advanced heating technology for efficient and even results.

Key Features:

- **Dual Blaze Heating Technology:** Features top and bottom heating elements for 360° crispy cooking, reducing the need for shaking or flipping.
- **High Power & Fast Cooking:** 2000W power cooks food up to 30% faster than traditional methods.
- **Large Capacity:** 8-liter capacity, suitable for cooking a whole chicken or meals for 7-9 people.
- **LED Touch Screen:** Intuitive color touch screen with 10 preset cooking programs and 3 modes (Sauté, Crispy Roast, Bake).
- **Dishwasher Safe Components:** Non-stick cooking basket and detachable parts are easy to clean.
- **All-Metal Inner Chamber:** Made from food-grade stainless steel, resistant to high temperatures and odor-free.
- **Customizable Preheating:** Flexible preheating program adjusts time based on temperature.
- **Transparent Window:** Allows monitoring of food without interrupting the cooking process.

Product Components:

- Main Unit (Air Fryer)
- Removable Cooking Basket
- Crisper Plate (inside the basket)
- Power Cord
- User Manual



Image: Taylor Swoden Air Fryer with transparent window and touch screen, showing its 8L capacity and intuitive controls.



Image: Diagram illustrating the Dual Blaze heating technology with top and bottom heating elements for 360° crispy cooking.

3. Setup and First Use

Unpacking:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Remove the cooking basket and crisper plate from the air fryer.

Initial Cleaning:

1. Wash the cooking basket and crisper plate thoroughly with hot water, dish soap, and a non-abrasive sponge. These parts are dishwasher safe.
2. Wipe the inside and outside of the appliance with a damp cloth.
3. Ensure all parts are completely dry before use.

Placement:

- Place the air fryer on a stable, horizontal, and heat-resistant surface.
- Ensure there is adequate ventilation around the appliance (at least 10 cm clearance on all sides).
- Do not place the air fryer near flammable materials or heat sources.

4. Operating Instructions

Powering On/Off:

- Plug the power cord into a grounded electrical outlet. The display will illuminate briefly.
- Press the power button to turn the appliance on or off.

Using Preset Programs:

The air fryer features 10 preset programs for common foods and 3 cooking modes (Sauté, Crispy Roast, Bake).



Image: The LED touch screen displaying 10 preset cooking functions with recommended temperatures and times.

1. Place ingredients into the cooking basket.
2. Select the desired preset icon on the touch screen. The default temperature and time for that program will appear.
3. Adjust the temperature and time using the '+' and '-' buttons if needed.
4. Press the start/pause button to begin cooking.

Manual Mode:

1. Press the temperature or time adjustment buttons directly to set your desired cooking parameters.
2. Press the start/pause button to begin cooking.

Preheating Function:

The air fryer includes a customizable preheating program. You can choose to preheat or not, and the system will adjust the time based on the target temperature.

- To use preheating, select the preheat option (if available on the display) or manually set a short preheat time (e.g., 3-5 minutes) at the desired cooking temperature.

Monitoring Cooking Progress:

- Use the transparent viewing window to check on your food without opening the basket.
- Opening the cooking basket will automatically pause the cooking cycle. The appliance will resume once the basket is reinserted.

Your browser does not support the video tag.

Video: Demonstrates the Taylor Swoden air fryer in use, showing the cooking process and the transparent window for monitoring food.

Your browser does not support the video tag.

Video: Shows various dishes being prepared in the Taylor Swoden air fryer, highlighting its versatility and ease of use.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

Cleaning the Cooking Basket and Crisper Plate:

- After each use, unplug the air fryer and allow it to cool completely.
- Remove the cooking basket and crisper plate.
- These parts are dishwasher safe. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge.
- For stubborn food residue, soak the basket and plate in warm, soapy water for about 10 minutes before cleaning.

Cleaning the Interior:

- Wipe the interior of the air fryer with a damp cloth. The all-metal inner chamber is designed to be easy to clean and odor-free.
- Do not use abrasive cleaners or scouring pads, as they can damage the non-stick coating and metal surfaces.

Cleaning the Exterior:

- Wipe the exterior of the air fryer with a soft, damp cloth.
- Never immerse the main unit in water or any other liquid.

Storage:

- Ensure all parts are clean and dry before storing.
- Store the air fryer in a cool, dry place.

6. Troubleshooting

If you encounter issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in or power outlet is faulty.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Food is not cooked evenly.	Basket is overloaded or food is not shaken/flipped.	Do not overload the basket. Shake or flip food halfway through cooking for even results.
White smoke comes from the appliance.	Fat residue from previous use or high-fat food.	Clean the basket and crisper plate thoroughly. For high-fat foods, drain excess fat during cooking.
Food is not crispy.	Insufficient cooking time/temperature or too much moisture.	Increase cooking time or temperature. Pat food dry before air frying. Use a light coating of oil for extra crispiness.
Unusual odors during first use.	Normal for new appliances.	The odor will dissipate after a few uses. Ensure good ventilation during initial operation.

7. Specifications

Feature	Specification
Brand	Taylor Swoden
Model	Smartheat
Color	Black
Product Dimensions	37.8 x 32.5 x 35.7 cm
Capacity	8 Liters
Volume	6 Liters
Wattage	2000 Watts (Corrected from 1800W in specs to 2000W in title/feature bullets for consistency)
Voltage	240 Volts
Material	Stainless Steel
Special Features	Temperature Control, Timer, Automatic Shut-off, Transparent Window, Dual Heating Elements
Item Weight	6.46 Kilograms

8. Warranty and Support

Taylor Swoden products are manufactured to the highest quality standards. In the unlikely event of any issues, please refer to the following information:

Warranty Information:

This product comes with a standard manufacturer's warranty. Please retain your proof of purchase for any warranty claims. The warranty typically covers defects in materials and workmanship under normal use.

Customer Support:

For technical assistance, troubleshooting, or warranty inquiries, please contact Taylor Swoden customer support through the retailer where the product was purchased or visit the official Taylor Swoden website for contact details.

Please have your model number (Smartheat) and purchase date available when contacting support.