Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit NH503UP

ZdalaMit NH503UP Replacement Remote Control User Manual

For Philips LCD LED Smart TVs

1. Introduction

This manual provides instructions for the ZdalaMit NH503UP replacement remote control. This remote is designed to function as a direct replacement for your original Philips TV remote, requiring no programming or pairing. Simply install batteries, and it is ready for use.

1.1. Compatibility

The NH503UP remote control is compatible with a wide range of Philips LCD LED Smart TV models, including but not limited to:

- 65PFL6902/F7, 55PFL6902/F7, 50PFL6902/F7, 50PFL6602/F7
- 55PFL5402/F7, 50PFL5601/F7, 55PFL5602/F7, 43PFL5602/F7
- 32PFL4902/F7, 40PFL4901/F7, 43PFL4901/F7, 50PFL4901/F7
- 43PFL4902/F7, 50PFL5602/F7, 65PFL5602/F7
- 49PFL4609/F7, 49PFL4909/F7, 65PFL5903/F7
- And many other Philips LCD LED Smart TV models.

2. Setup

2.1. Battery Installation

To begin using your remote control, you must install two AAA alkaline batteries. Batteries are not included with the remote control.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 2.1: Angled view of the NH503UP remote control. The battery compartment is located on the back.

Once batteries are installed, the remote control is ready for immediate use with compatible Philips TVs. No programming or pairing is required.

3. Operating Instructions

This section provides an overview of the main buttons and their functions on your NH503UP remote control.



Figure 3.1: Front view of the NH503UP remote control with labeled buttons.

3.1. Button Functions Overview

Button	Function
POWER	Turns the TV on or off.
NETFLIX	Direct access to the Netflix application.
VUDU	Direct access to the Vudu application.
Navigation Pad (Up/Down/Left/Right/OK)	Navigates menus and confirms selections.
BACK	Returns to the previous menu or screen.
OPTIONS	Displays context-sensitive options.
VOL +/-	Adjusts the volume level.
CH +/-	Changes TV channels.
SOURCE	Selects input sources (HDMI, AV, etc.).
MUTE	Mutes or unmutes the TV audio.
Number Buttons (0-9)	Direct channel selection.
PREV.CH	Switches to the previously viewed channel.
Media Playback Controls	Play, Pause, Stop, Fast Forward, Rewind, Skip.
Colored Buttons (Red, Green, Yellow, Blue)	Functions vary depending on the TV menu or application.

4. Maintenance

4.1. Cleaning

To maintain the remote control's functionality and appearance:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.
- Ensure no liquid enters the remote control.

4.2. Storage

When not in use for extended periods:

- Remove the batteries to prevent leakage, which can damage the remote.
- Store the remote in a cool, dry place, away from direct sunlight and extreme temperatures.

5. Troubleshooting

If you encounter issues with your remote control, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Remote not working.	Dead or incorrectly installed batteries.	Replace with new AAA alkaline batteries, ensuring correct polarity.
Remote's infrared (IR) signal is blocked.	Obstruction between remote and TV's IR sensor.	Ensure a clear line of sight between the remote and the TV.
Remote is out of range.	Operating the remote too far from the TV.	Move closer to the TV (within 33 feet / 10 meters).
Specific buttons are unresponsive.	Dirt or debris under the button.	Clean the remote control as described in the Maintenance section.
Remote works intermittently.	Low battery power.	Replace batteries.

6. Specifications

Feature	Detail
Brand	ZdalaMit
Model Name	NH503UP
Connectivity Technology	Infrared (IR)
Compatible Devices	Philips LCD LED Smart Televisions
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Maximum Range	Approximately 33 feet (10 meters)
Button Quantity	43
Color	Black
Item Weight	40 Grams
Item Dimensions (L x W x H)	7.34" x 1.99" x 0.55" (18.64 cm x 5.05 cm x 1.4 cm)

7. Warranty and Support

7.1. Warranty Information

This ZdalaMit NH503UP replacement remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or battery leakage.

7.2. Customer Support

If you have any questions, concerns, or require assistance with your ZdalaMit NH503UP remote control, please contact our customer support team. Refer to your purchase documentation or the retailer's website for specific contact details.
We are committed to providing reliable products and support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YHNRXHS

More documents and user manuals: **https://manuals.plus/**