Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Holiday Living 14201853

Holiday Living 100-Count Multi Mini Christmas Lights Instruction Manual

Model: 14201853

Introduction

This manual provides essential instructions for the safe and effective use of your Holiday Living 100-Count Multi Mini Christmas Lights. Please read this manual thoroughly before installation and operation, and retain it for future reference.

Safety Information

WARNING: To reduce the risk of fire and electric shock:

- Do not install on trees having needles, leaves, or branch coverings of metal or materials that look like metal.
- Do not mount or support strings in a manner that can cut or damage wire insulation.
- This product is designed for indoor and outdoor use. Ensure all connections are secure and protected from moisture when used outdoors.
- Always unplug the lights from the power source before performing any maintenance or bulb replacement.
- Do not overload electrical outlets. Connect up to a maximum of five (5) sets of these lights end-to-end.
- Inspect the light set for any damage before each use. Do not use if wires are frayed or insulation is damaged.
- This product employs overload protection (fuse). Do not replace the attachment plug as it contains a safety device that should not be removed. Discard product if the attachment plug is damaged.

Image Description: A close-up view of the green fused plug for the Holiday Living Christmas lights. The plug clearly shows "USE ONLY", "TS-66", "3A MAX", "OPEN", and "125V FUSE" markings, indicating its safety features and specifications. This plug is designed for overload protection.

Package Contents

- 100-Count Multi Mini Christmas Light Set (1)
- Extra Replacement Bulbs (Several)
- Extra Replacement Fuse (1)

Image Description: The front of the product packaging for Holiday Living 100-Count Multicolored Mini Lights. The box is red with white text, indicating "100 ct", "Multicolored Mini Lights", "21.9 ft Total Length", and "Indoor and Outdoor Use". A visual of the multi-colored mini bulbs is also present, along with the product number #0165142.

Setup Instructions

1. **Unpack:** Carefully remove the light set from its packaging. Untangle the string of lights gently to avoid damage to the wires or bulbs.
2. **Inspect:** Before plugging in, visually inspect the entire light string for any signs of damage, such as frayed wires, cracked bulb casings, or loose connections. Do not use if damaged.
3. **Placement:**
    - For indoor use, drape lights on Christmas trees, wreaths, or other decorative items. Ensure lights are not pinched by doors or windows.
    - For outdoor use, ensure the location is suitable for electrical products. Avoid placing lights in standing water or areas prone to heavy moisture accumulation. Secure lights to prevent wind damage.
4. **Connecting Multiple Sets:** These lights are designed to connect up to five (5) sets end-to-end. To connect, insert the male plug of one set into the female receptacle at the end of another set. Ensure connections are tight.
5. **Power Connection:** Plug the light set into a standard 120V AC electrical outlet. For outdoor use, always use a Ground Fault Circuit Interrupter (GFCI) protected outlet.



Image Description: A close-up of the female end connector of the Holiday Living Christmas light string. This connector allows multiple light sets to be linked together end-to-end. A UL certification label is visible near the connector, indicating safety compliance.

Operating Instructions

Once properly set up and plugged into a power source, the Holiday Living 100-Count Multi Mini Christmas Lights will illuminate. There are no additional controls or settings for this basic light set.

- To turn the lights ON/OFF, plug or unplug the set from the electrical outlet.
- For automated operation, consider using an external timer (sold separately).

Maintenance

Bulb Replacement

If a bulb burns out, the remaining bulbs on the string will generally remain lit. Replace burned-out bulbs promptly to maintain the aesthetic and ensure proper circuit function.

1. **Unplug:** Always unplug the light set from the power source before replacing any bulbs.
2. **Remove Old Bulb:** Gently pull the burned-out bulb straight out from its socket. If the bulb is difficult to remove, you may need to wiggle it slightly.
3. **Insert New Bulb:** Take a new replacement bulb (provided in the package) and align its two wires with the holes in the socket. Push the new bulb firmly into the socket until it is seated properly.
4. **Test:** Plug the light set back in to ensure the new bulb illuminates.

Fuse Replacement

The plug contains a fuse designed to protect against electrical overloads. If the entire string of lights does not illuminate, the fuse may need replacement.

1. **Unplug:** Always unplug the light set from the power source before replacing the fuse.
2. **Open Fuse Compartment:** Slide open the fuse access cover located on the side of the plug (refer to the image in the Safety Information section).
3. **Remove Old Fuse:** Carefully remove the old fuse.
4. **Insert New Fuse:** Insert a new 3 Amp, 125 Volt fuse (provided in the package) into the compartment.
5. **Close Compartment:** Slide the fuse access cover back into place until it clicks shut.
6. **Test:** Plug the light set back in to ensure the lights illuminate. If the fuse blows again, there may be a short circuit or overload, and the light set should be inspected by a qualified professional or discarded.

Storage

When not in use, store the light set in a cool, dry place, away from direct sunlight and extreme temperatures. Carefully coil the string to prevent tangling and damage to wires and bulbs.

Troubleshooting

Problem	Possible Cause	Solution
Lights do not turn on.	No power to the outlet.	Check the wall outlet with another device. Ensure the outlet is active.
Lights do not turn on.	Blown fuse in the plug.	Replace the fuse as per the "Fuse Replacement" instructions.
Lights do not turn on.	Loose connection.	Ensure the plug is fully inserted into the outlet and any end-to-end connections are secure.
Part of the light string is out.	One or more bulbs are loose or burned out in that section.	Check and replace any loose or burned-out bulbs in the affected section.
Lights flicker.	Loose bulb or connection.	Gently press each bulb into its socket. Check all connections.

Specifications

- **Model:** 14201853 (Also known as W11A0741 LW057001-072016)
- **Brand:** Holiday Living
- **Light Count:** 100 Mini Lights
- **Light Colors:** Red, Green, Blue, Pink, Gold (Multi-color)
- **Wire Color:** Green
- **Total Length:** Approximately 20.62 feet (6.28 meters)
- **Lead Wire Length:** 12 inches
- **Power Source:** Corded Electric
- **Voltage:** 120V~, 60Hz
- **Current:** 0.34 A
- **Wattage:** 40.8 W
- **Indoor/Outdoor Use:** Yes
- **Connectable:** Up to 5 sets end-to-end
- **Safety Certification:** UL Listed and Certified
- **UPC:** 030539027124

- **Manufacturer:** LG Sourcing, Inc.

Image Description: The back of the Holiday Living Christmas lights packaging. It displays detailed specifications including voltage (120V~ 60Hz), current (0.34A), wattage (40.8W), and UL listing. The UPC barcode (030539027124) and manufacturer information (L G Sourcing, Inc.) are also visible, along with model numbers W11A0741 and LW057001-072016.

Warranty and Support

This product is manufactured by LG Sourcing, Inc. For support or warranty inquiries, please contact the manufacturer directly. Specific warranty details may be provided on the product packaging or through the retailer at the time of purchase.

- **Manufacturer:** LG Sourcing, Inc.
- **Contact Number:** 1-800-643-0067 (as seen on packaging)
- **Website:** www.lgsourcing.com (as seen on packaging)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YLX6TBF

More documents and user manuals: **https://manuals.plus/**