Pelican HHA25P205-00

Pelican MONACO DLX ANGLER Pedal Boat User Manual

Model: HHA25P205-00

Introduction

This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your Pelican MONACO DLX ANGLER Pedal Boat. Please read this manual thoroughly before operating the boat.
The MONACO DLX ANGLER pedal boat is designed for recreational use on calm waters, offering a stable and comfortable experience for up to five individuals. It features adjustable backrests, flush mount rod holders, a built-in cooler, a two-branch canopy, drink holders, and a storage platform.

Safety Information

Always wear a U.S. Coast Guard approved personal flotation device (PFD) when operating this pedal boat. Do not exceed the maximum weight capacity of 695 lb (315 kg). Avoid operating in strong currents, high winds, or during thunderstorms. Always inform someone of your float plan, including your destination and estimated return time.
Ensure all occupants are seated properly and weight is distributed evenly to maintain stability. Do not stand up in the boat while on the water. Keep hands and feet clear of the pedal and rudder mechanisms.

Setup

The Pelican MONACO DLX ANGLER pedal boat comes largely pre-assembled. Follow these steps for initial setup:

1. **Unpacking:** Carefully remove all packaging materials. Inspect the boat for any signs of damage from shipping.
2. **Canopy Assembly:** Attach the two-branch canopy to the designated mounting points on the boat. Ensure it is securely fastened to provide shade.
3. **Seat Adjustment:** Adjust the backrests of the molded seats to a comfortable position.
4. **Rudder and Pedal Check:** Verify that the rudder system operates smoothly and the pedals turn freely.
5. **Storage Compartments:** Ensure the covers for the built-in cooler/storage compartment are securely in place.



Image: The Pelican MONACO DLX ANGLER pedal boat, showcasing its green and white hull, blue seats, and deployed blue canopy.

Operating Instructions

Operating your MONACO DLX ANGLER is straightforward. Here are key points for effective use:

- **Launching:** Use the bow and stern carrying handles to transport the boat to the water. Gently push the boat into the water until it floats freely.
- **Boarding:** Board the boat one person at a time, distributing weight evenly. Sit down before pushing off from the shore.
- **Pedaling:** Use the pedals to propel the boat forward. The pedal system is designed for smooth and efficient movement.
- **Steering:** Use the steering handle to control the rudder and direct the boat. Turn the handle left to go left, and right to go right.
- **Canopy Use:** Deploy the canopy for sun protection. Fold it down when not needed or in windy conditions.
- **Storage:** Utilize the built-in cooler and storage platform for personal items, food, and beverages. The flush mount rod holders are convenient for fishing.



Image: An overhead view of the pedal boat's interior, showing the pedal mechanisms, blue molded seats, and the central storage area.



Image: A family enjoying the Pelican MONACO DLX ANGLER pedal boat on a body of water, demonstrating its use in a natural setting.

Maintenance

Regular maintenance will ensure the longevity and performance of your pedal boat:

- **Cleaning:** After each use, rinse the boat with fresh water to remove salt, sand, or dirt. Use mild soap and a soft brush for stubborn stains.
- **Inspection:** Periodically inspect the hull for cracks or damage. Check the pedal system, rudder, and canopy frame for wear or loose components.
- **Lubrication:** Apply marine-grade lubricant to moving parts of the pedal and rudder mechanisms as needed to ensure smooth operation.
- **Storage:** Store the boat in a shaded area or cover it to protect it from prolonged UV exposure when not in use. If storing outdoors, ensure it is drained of water to prevent freezing damage.

Troubleshooting

Here are some common issues and their solutions:

Problem	Possible Cause	Solution
Difficulty pedaling	Debris in propeller, stiff mechanism	Clear debris from propeller. Lubricate pedal mechanism.
Poor steering response	Rudder obstruction, loose steering cable	Check rudder for obstructions. Inspect and tighten steering cable connections.

Problem	Possible Cause	Solution
Water accumulation inside boat	Drain plug not secured, hull damage	Ensure drain plug is tightly closed. Inspect hull for leaks and repair if necessary.

If problems persist, contact Pelican customer support.

Specifications

Feature	Detail
Model Name	MONACO DLX ANGLER Green/White
Part Number	HHA25P205-00
Brand	Pelican
Material	RAM-X™ Impact-Resistant Plastic
Color	Green/White
Dimensions (L x W x H)	90 x 62.5 x 19.25 inches (228.6 x 158.75 x 48.9 cm)
Weight	Approx. 113 lbs (51.26 kg)
Maximum Capacity	5 individuals / 695 lb (315 kg)
Included Components	Boat, Adjustable Backrests, Flush Mount Rod Holders, Solid Built-in Cooler, Easy to Deploy Canopy, Drink Holders, Storage Platform
Model Year	2019

Warranty

The Pelican MONACO DLX ANGLER Pedal Boat comes with a**4-YEAR LIMITED WARRANTY**. For detailed information regarding warranty coverage, terms, and conditions, please refer to the official warranty document included with your purchase or visit the Pelican website.

Support

For further assistance, technical support, or to order replacement parts, please contact Pelican customer service:

- **Official User Manual (PDF):** For a comprehensive guide, you can download the official PDF user manualhere.
- **Pelican Website:** Visit the official Pelican website for product information and support resources.
- **Contact Information:** Refer to the Pelican website or your purchase documentation for current customer service contact details.

© 2024 Pelican. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question