Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Disney 17016

OLAF Story Teller Interactive Plush Instruction Manual

Model: 17016 | Brand: Disney

Introduction

The Disney Olaf Story Teller is an interactive plush toy designed to bring joy and entertainment. This soft and glittery Olaf plush can be played with, interacted with, and even cuddled at bedtime. It features the ability to tell 8 different stories and sing the iconic song "In Summer" with Olaf's original voice.
This manual provides essential information on setting up, operating, maintaining, and troubleshooting your Olaf Story Teller to ensure a delightful experience.

Important Safety Information

WARNING:

- Not suitable for children under 18 months due to small parts and potential choking hazards.
- Always supervise children during play.
- Keep away from open flames and direct heat sources.
- Do not immerse the product in water. Clean only as instructed in the Maintenance section.
- Ensure batteries are inserted correctly and dispose of used batteries responsibly.

Setup

Battery Installation

Your Olaf Story Teller requires 3 x LR63 AA 1.5V batteries. These batteries are included with the product.

1. Locate the battery compartment on the back or bottom of the Olaf plush.
2. Using a small Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert the 3 LR63 AA 1.5V batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.
5. The product is now ready for use.



Image: Front view of the Olaf Story Teller plush, highlighting the interactive buttons for stories and songs. The plush is white with brown stick arms and hair, and an orange carrot nose.

Operating Instructions

The Olaf Story Teller is designed for simple and intuitive interaction.

Main Functions

- **Storytelling:** Locate the button on Olaf's body with the **book icon**. Press this button to hear Olaf tell one of 8 different stories. Pressing it again will cycle to the next story.
- **Singing:** Locate the button on Olaf's body with the **music note icon**. Press this button to hear Olaf sing the legendary song "In Summer" from the Frozen movie.

- **Interactive Movement:** As Olaf tells stories or sings, his head and mouth will move, enhancing the interactive experience.



Image: A child interacting with the Olaf Story Teller, demonstrating its size and how it can be held.



Image: A child observing the Olaf Story Teller, illustrating the engaging nature of the toy.

Note on Language: The stories and songs are in French, as indicated in the product specifications.

Maintenance

Cleaning Instructions

- To clean the Olaf plush, gently wipe the surface with a damp cloth.
- Do not use harsh chemicals or abrasive cleaners.
- Do not machine wash or tumble dry.
- Allow the plush to air dry completely before storing or further use.

Storage

- Store the Olaf Story Teller in a cool, dry place away from direct sunlight.
- If storing for an extended period, it is recommended to remove the batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Olaf is not responding or making sounds.	Batteries are low or depleted. Batteries are inserted incorrectly. Product is in sleep mode.	Replace with new LR63 AA 1.5V batteries. Check battery polarity and reinsert correctly. Press any button to wake Olaf from sleep mode.
Sound is distorted or too quiet.	Low batteries. Speaker obstruction.	Replace batteries. Ensure nothing is covering the speaker area.
Olaf's movements are erratic or non-existent.	Low batteries. Internal mechanism obstruction.	Replace batteries. If the issue persists after battery replacement, contact customer support.

Specifications

- **Model Name:** Olaf Story Teller
- **Model Number:** 17016
- **Brand:** Disney
- **Dimensions (L x W x H):** 12 x 15 x 35 cm (approximately 4.7 x 5.9 x 13.8 inches)
- **Weight:** 45.36 grams (approximately 1.6 ounces)
- **Material:** Plush
- **Color:** White
- **Recommended Age:** 18 months and up
- **Power Source:** 3 x LR63 AA 1.5V Batteries (included)
- **Language:** French (for stories and songs)
- **ASIN:** B07YNSZJ19

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Disney Toys website. Keep your purchase receipt as proof of purchase for any warranty claims.
For further assistance, please contact your local Disney product distributor or retailer.

© 2024 Disney. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YNSZJ19

More documents and user manuals: **https://manuals.plus/**