Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Contixo V8

Contixo V8 7-inch Kids Tablet Instruction Manual

Model: V8

1. Introduction

This manual provides essential information for setting up, operating, and maintaining your Contixo V8 7-inch Kids Tablet. Please read it thoroughly to ensure proper usage and to maximize your child's learning and entertainment experience.



Image: Contixo V8 7-inch Kids Tablet in its blue protective case, showcasing the device's design.

2. What's in the Box

Your Contixo V8 Kids Tablet package includes the following items:

- Contixo V8 7-inch Kids Tablet
- Kid-Proof Case
- 50+ Disney Storybooks & Stickers (pre-loaded)
- 1-year manufacturer defect warranty information
- Charging Cable (USB 2.0)
- Power Adapter

3. Product Overview

Familiarize yourself with the physical components and features of your Contixo V8 Kids Tablet.



Image: A detailed diagram illustrating the various ports, buttons, and camera locations on the Contixo V8 Kids Tablet, including the Power Button, Type C Charging Port, Reset Pinhole, Mic, 3.5mm Headphone Jack, Volume Up/Down, MicroSD Card Slot, Front Camera, Rear Camera, and Speaker.

Key Components:

- **Power Button:** Located on the top edge, used to power on/off or wake/sleep the device.
- **Type C Charging Port:** For connecting the charging cable.
- **Reset Pinhole:** Use a thin object to reset the device if unresponsive.
- **Mic:** Integrated microphone for audio input.
- **3.5mm Headphone Jack:** For connecting headphones.

- **Volume Up/Down:** Buttons on the side for adjusting audio levels.
- **MicroSD Card Slot:** Expand storage up to 32GB.
- **Front Camera:** 0.3 MP for video calls and selfies.
- **Rear Camera:** 2 MP for capturing photos and videos.
- **Speaker:** For audio output.

4. Setup

4.1 Attaching the Protective Case

The tablet comes with a durable kid-proof silicone case. Carefully fit the tablet into the case, ensuring all ports and buttons align with the case cutouts.

4.2 Initial Power On and Charging

To power on the tablet, press and hold the Power Button until the Contixo logo appears. For optimal performance, ensure the tablet is fully charged before first use. Connect the provided charging cable to the Type C port and the power adapter to a wall outlet.

4.3 Installing Educational Apps

Your tablet comes with pre-loaded educational content. To ensure all apps are fully installed and updated, follow these steps:

1. Power on the tablet.
2. Navigate to the Settings menu.
3. Select "Accessibility".
4. Locate the option "Install apps" and turn on its switch.
5. Confirm by selecting "YES" when prompted. The tablet will restart, and all learning and game apps will be installed. This process may take up to 10 minutes.

If the tablet's power is less than 20% during this process, please connect the charger. If the tablet shuts down during restarting, it may not be able to install all applications correctly.

Your browser does not support the video tag.

Video: This video demonstrates the process of installing pre-loaded educational and game applications on the Contixo V8-2 7-inch Android Kids Tablet, including how to navigate through settings and confirm the installation.

5. Operating Instructions

5.1 Parental Controls

The Contixo V8 tablet features robust parental controls, including integration with Google Family Link, allowing you to manage your child's digital experience.

- **Manage Permissions & Apps:** Control which applications your child can access.
- **Control Screen Time:** Set daily limits for tablet usage.

- **Block Unsafe Internet Content:** Filter inappropriate websites and content.
- **Set Educational Goals:** Customize learning objectives and app usage.



Image: Two children are shown happily using Contixo V8 tablets, with an overlay highlighting features like 'Manage Permissions & Apps', 'Control Screen Time', 'Block from Unsafe Internet Content', and 'Set Educational Goals', along with the Google Family Link logo.

5.2 Pre-loaded Educational Content

The tablet comes with Contixo Academy content, including over 15 storybook apps and various educational games for preschoolers to 5th graders, covering subjects like math, language arts, and science.



Image: The screen of a Contixo V8 tablet displays a selection of educational games categorized by grade level, such as 'Pre-K Lessons', '1st Grade', '2nd Grade', '3rd Grade', '4th Grade', and '5th Grade', featuring an owl mascot.

5.3 Media Playback and Camera Usage

The tablet supports up to 5 hours of offline video playback, 3.5 hours of video streaming, and 10 hours of reading. It features dual cameras (0.3 MP front, 2 MP rear) for capturing moments.



Image: Three toddlers are shown playing with a Contixo V8 tablet on a rug, with logos for YouTube Kids, Netflix, Nick Jr. Channel, Disney+, and Hulu displayed at the bottom, indicating media streaming capabilities.

6. Maintenance

6.1 Cleaning the Durable Case

The tablet's silicone case is designed for durability and protection against drops and bumps. It can be removed for cleaning. Use a soft, damp cloth to wipe down the case and the tablet screen. Avoid harsh chemicals.



Image: A young boy gives a thumbs-up gesture next to a Contixo V8 tablet in its durable silicone case. Highlighted features include 'Kid-friendly design', 'Reinforced Corners', and 'Precise Cut-outs', emphasizing its protective qualities.

6.2 Battery Care

The tablet is equipped with a 3100 mAh Lithium-ion battery. To prolong battery life, avoid fully discharging the battery frequently and store the tablet in a cool, dry place when not in use for extended periods.

7. Troubleshooting

If you encounter issues with your Contixo V8 tablet, try the following basic troubleshooting steps:

- **Device Unresponsive:** Press and hold the Power Button for 10-15 seconds to force a restart. If this doesn't work,

use a thin object to press the Reset Pinhole.

- **Charging Issues:** Ensure the charging cable and adapter are securely connected. Try a different outlet or USB port.
- **Wi-Fi Connectivity:** Check if Wi-Fi is enabled in settings. Restart your router and the tablet.
- **App Malfunction:** Close and reopen the app. If the issue persists, clear the app's cache or reinstall it from the Play Store.

8. Specifications

Feature	Specification
Brand	Contixo
Model Name	V8
Screen Size	7 Inches
Display Resolution	1024 x 600 Pixels
Operating System	Android 11
Memory Storage Capacity	32 GB
RAM Size	2 GB
Expandable Storage	microSD, up to 32 GB
Processor	Quad-Core Cortex-A100 (1.5 GHz)
Front Camera	0.3 MP
Rear Camera	2 MP
Battery Capacity	3100 Milliamp Hours (Lithium-ion)
Connectivity	Wi-Fi, Bluetooth, 4G
Item Weight	1.5 Ounces
Dimensions (L x W x Thickness)	7.17"L x 4.8"W x 0.4"Th
Age Range	Age 3+

9. Warranty and Support

Your Contixo V8 Kids Tablet comes with a 1-year manufacturer defect warranty. For any support inquiries or warranty claims, please refer to the contact information provided in your product packaging or visit the official Contixo website.

© 2026 Contixo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Z492NQ7

More documents and user manuals: **https://manuals.plus/**