Nespresso EN80CW

Nespresso Inissia Original Espresso Machine EN80CW User Manual

Model: EN80CW | Brand: Nespresso

Introduction

This manual provides essential instructions for the safe and efficient use of your Nespresso Inissia Original Espresso Machine. Please read all instructions before operating the appliance.

Setup

1. Unpacking and Initial Placement

Carefully remove the machine from its packaging. Place the machine on a clean, stable, and level surface. Ensure the power cord is accessible and not obstructed.

2. Filling the Water Tank

Lift the water tank lid and fill the tank with fresh drinking water. Do not exceed the 'MAX' fill line. Ensure the water tank is securely placed back on the machine.





Image: Top-down view of the Nespresso Inissia Original Espresso Machine. This image highlights the transparent water tank at the rear of the machine and the power cord extending from the base, illustrating how to access and fill the water reservoir.

3. First Use and Rinsing

Before first use, or after a long period of inactivity, rinse the machine. Fill the water tank. Place a container under the coffee outlet.

Press either the Espresso or Lungo button to run water through the system without a capsule. Repeat this process 2-3 times to clean the internal components.

Operating Instructions

1. Powering On

Plug the machine into a grounded power outlet. Press either the Espresso or Lungo button to turn on the machine. The buttons will flash while the machine heats up. The machine is ready when the buttons illuminate steadily (approximately 25 seconds).

2. Inserting a Nespresso Capsule

Lift the lever completely. Insert a Nespresso Original capsule into the capsule compartment. Close the lever firmly.



Image: Close-up view of the Nespresso Inissia machine's top. The lever is shown in the open position, ready for a coffee capsule to be inserted into the brewing chamber. This illustrates the simple mechanism for loading coffee.

3. Brewing Coffee

Place a cup under the coffee outlet. Press the Espresso button for a 40 ml shot or the Lungo button for a 110 ml shot. The machine will automatically stop when the selected volume is dispensed. You can stop the flow at any time by pressing the button again.

4. Ejecting the Used Capsule

After brewing, lift the lever to automatically eject the used capsule into the internal container. Close the lever.

5. Official Product Video: Nespresso Original Espresso Machine

Video: This official product video demonstrates the Nespresso Inissia Original Espresso Machine in operation, showcasing its compact design, quick heat-up time, and the process of brewing an espresso. It highlights the ease of use and the quality of the coffee produced.

Maintenance

1. Emptying the Used Capsule Container

The used capsule container can hold up to 11 capsules. Empty and rinse the container regularly to prevent overflow and maintain hygiene.



Image: Front view of the Nespresso Inissia Original Espresso Machine. The image shows the drip tray and the used capsule container pulled out from the machine's base, illustrating how to access and empty these components for cleaning.

2. Cleaning the Drip Tray and Water Tank

Remove the drip tray and water tank. Wash them with warm water and a mild detergent. Rinse thoroughly and dry before reassembling. Do not use abrasive cleaning agents or scourers.

3. Descaling

Regular descaling is crucial for maintaining machine performance and coffee quality. Refer to the full Nespresso descaling instructions, typically found in the comprehensive manual or on the Nespresso website, for the correct procedure and recommended descaling solution.

Troubleshooting

- **No water flow:** Check if the water tank is filled and correctly positioned. Ensure no air bubbles are trapped in the system (run a few cycles of water without a capsule).
- **Coffee is cold:** Preheat your cup by running a Lungo cycle without a capsule. Ensure the machine has fully heated up (steady lights).
- **Machine not turning on:** Verify the power cord is securely plugged into a working outlet.
- **Capsule not ejecting:** Ensure the lever is lifted completely and then closed firmly.

Specifications

Brand	Nespresso
Model Number	EN80CW
Color	Creamy White
Product Dimensions	4.72"D x 12.63"W x 9.05"H
Item Weight	3.99 pounds
Water Tank Capacity	680 Milliliters
Pressure	19 bars
Heat-up Time	25 seconds
Cup Sizes	Espresso (40 ml), Lungo (110 ml)
Energy Saving Mode	Automatic switch-off after 9 minutes

Warranty and Support

Your Nespresso Inissia Original Espresso Machine is covered by a manufacturer's warranty. For detailed warranty information, product registration, or technical support, please refer to the documentation included with your purchase or visit the official Nespresso website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question