Dyson 969154-02

Dyson Remote Control User Manual

Model: 969154-02

Introduction

This manual provides comprehensive instructions for the Dyson Remote Control (White), Part No. 969154-02, designed specifically for use with the Dyson TP04 Pure Cool Purifying Fan. This genuine Dyson replacement remote allows for convenient control of your fan's functions, including power, airflow settings, oscillation, and sleep timer.

Setup

Battery Installation

The Dyson Remote Control requires a CR2032 coin cell battery for operation. If the remote is unresponsive, the battery may need to be replaced.

1. Locate the battery compartment on the back of the remote control.
2. Using a small coin or screwdriver, gently twist the battery cover counter-clockwise to open.
3. Remove the old battery (if present) and insert a new CR2032 battery with the positive (+) side facing upwards.
4. Align the battery cover and twist clockwise to secure it.



Image: Front view of the Dyson Remote Control (White), displaying its array of control buttons.

Pairing (If Required)

Most Dyson remote controls are pre-paired with their corresponding fan models. If your remote does not respond after battery installation, refer to your Dyson TP04 Pure Cool Purifying Fan's main user manual for specific pairing instructions. Typically, ensuring a clear line of sight between the remote and the fan is sufficient for operation.

Operating Instructions

Familiarize yourself with the buttons on your Dyson Remote Control:

- **Power Button** ( ): Press to turn the Dyson fan on or off.
- **Information Button** (ℹ): Displays current air quality information, temperature, and filter life on the fan's LCD screen.
- **Airflow Control Buttons** (Vertical Oval with two circles):
  - Top Circle: Increases airflow speed.
  - Bottom Circle: Decreases airflow speed.
- **Auto Mode Button** (AUTO): Activates or deactivates Auto mode, allowing the fan to automatically adjust airflow based on detected air quality.
- **Oscillation Control Button** (↷ with arcs): Toggles the fan's oscillation feature on or off, distributing purified air across the room.
- **Sleep Timer / Night Mode Button** ( ): Activates Night mode, which dims the display and reduces airflow speed for quieter operation during sleep. Repeated presses may cycle through sleep timer settings.
- **Airflow Direction Buttons** (Horizontal Oval with arrows): Adjusts the direction of the airflow.
  - Left Arrow: Directs airflow to the left.
  - Right Arrow: Directs airflow to the right.

Maintenance

Cleaning the Remote

To maintain the remote's appearance and functionality:

- Wipe the surface with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or spray directly onto the remote.
- Avoid exposing the remote to excessive moisture.

Storage

When not in use, the remote control can be magnetically stored on top of your Dyson TP04 Pure Cool Purifying Fan for convenient access and to prevent misplacement.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Low or dead battery.	Replace the CR2032 battery (refer to "Battery Installation" section).
Remote not responding.	No clear line of sight to the fan.	Ensure the remote is pointed directly at the fan's display or sensor area without obstructions.
Remote not responding.	Remote is not paired (unlikely for genuine Dyson remotes).	Consult your Dyson TP04 fan's main user manual for pairing instructions, if applicable.
Buttons feel sticky or unresponsive.	Dirt or debris under buttons.	Clean the remote surface (refer to "Cleaning the Remote" section). Avoid liquid entering button crevices.

Specifications

- **Part Number:** 969154-02
- **Compatibility:** Dyson TP04 Pure Cool Purifying Fan
- **Color:** White
- **Dimensions:** 4 x 3.4 x 0.06 inches (Package Dimensions, actual remote dimensions may vary slightly)
- **Weight:** 0.81 ounces
- **Battery Type:** CR2032 Coin Cell (1x)

Warranty and Support

This Dyson Remote Control is a genuine Dyson part. For information regarding warranty coverage, returns, or technical support, please refer to the documentation provided with your original Dyson TP04 Pure Cool Purifying Fan or visit the official Dyson support website. Keep your purchase receipt for warranty claims.
For direct assistance, you may contact Dyson Customer Service through their official channels.

© 2024 Dyson. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I pair a new replacement remote control with my Dyson Pure Hot + Cool fan?

Most genuine Dyson replacement remote controls are pre-paired and should work immediately after you install a fresh battery. If your new remote is not responding, please follow these steps:Check the Battery: Ensure a new...

Read full answer