Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Proscenic M7 Pro

Proscenic M7 Pro Robot Vacuum Cleaner User Manual

Model: **M7 Pro** | Brand: **Proscenic**

1. Introduction

The Proscenic M7 Pro Robot Vacuum Cleaner is an advanced cleaning device designed to efficiently maintain your home's cleanliness. Featuring laser navigation, powerful suction, and smart app control, it offers a convenient solution for various floor types.

Key Features:

- **Advanced Laser Technology:** Intelligently navigates and maps your home for optimal cleaning paths.
- **Super Powerful Suction (2700Pa):** Effectively picks up pet hair, dirt, and fine dust.
- **Selective Cleaning:** Control cleaning modes, schedules, and virtual off-limit zones via the Proscenic app.
- **Multi-Floor Mapping:** Capability to save maps for different levels of your home.
- **Long Battery Life:** Up to 150 minutes of cleaning time with a 5200mAh Lithium-Ion Battery.
- **Auto Carpet Boost:** Automatically increases suction on carpets.
- **Low Noise Level:** Operates between 65-73dB.

2. Product Overview



Figure 1: Proscenic M7 Pro Robot Vacuum Cleaner with its self-emptying station and mobile app interface.



Figure 2: The Proscenic M7 Pro Robot Vacuum Cleaner automatically empties its dustbin into the intelligent dust collector (sold separately).



Figure 3: Control your robot vacuum with the Proscenic Home app, offering multi-floor mapping, recharge & resume, cleaning history, and remote control.

3. Setup

Before first use, ensure the robot vacuum is fully charged and properly set up.

Initial Charging:

1. Place the charging base against a wall in an open area, ensuring no obstacles within 1 meter to the sides and 2 meters in front.
2. Connect the power adapter to the charging base and plug it into a wall outlet.
3. Place the robot vacuum on the charging base. Ensure the charging contacts align. The indicator lights on the robot

will illuminate during charging.
4. Allow the robot to fully charge before its first cleaning cycle (approximately 4-5 hours).

App Connection:

1. Download the "Proscenic Home" app from your smartphone's app store.
2. Register an account and log in.
3. Follow the in-app instructions to add your M7 Pro robot vacuum. This typically involves connecting the robot to your home Wi-Fi network.

Your browser does not support the video tag.

Video 1: Overview of Proscenic M7 Pro features, including setup and initial operation.

4. Operating Instructions

Starting a Cleaning Cycle:

- **From Robot:** Press the power button on the robot to start a cleaning cycle.
- **From App:** Open the Proscenic Home app and select "Clean" to start. You can choose various cleaning modes (Auto, Spot, Edge, Zoned) and adjust suction power.
- **From Remote Control:** Use the included remote control to start/pause cleaning, send the robot back to the charging base, or manually control its movement.

Mapping and Navigation:

The M7 Pro uses advanced laser navigation to create a real-time map of your home. During the first few runs, it will learn your floor plan. Ensure all doors are open to allow complete mapping.

- **Multi-Floor Maps:** The robot can save multiple floor maps, allowing you to use it on different levels of your home without re-mapping.
- **Virtual No-Go Zones:** Use the app to set virtual boundaries or "no-go zones" to prevent the robot from entering specific areas.
- **Zoned Cleaning:** Select specific rooms or areas on the map for targeted cleaning.

Your browser does not support the video tag.

Video 2: Demonstration of the Proscenic M7 Pro Robot Vacuum Cleaner's navigation and cleaning capabilities.

Your browser does not support the video tag.

Video 3: Instructions on how to connect and control the Proscenic M7 Pro with Alexa.

Your browser does not support the video tag.

Video 4: Instructions on how to connect and control the Proscenic M7 Pro with Google Home.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your robot vacuum.

- **HEPA Filter and Dust Bin:** Clean after each use to prevent blockages.
- **Main Brush:** Remove and clean regularly to prevent hair and debris entanglement.
- **Side Brushes:** Check for wear and tear, and replace if necessary.
- **Sensors:** Wipe all sensors (cliff, anti-collision, recharging) with a clean, dry cloth to ensure proper navigation.
- **Water Tank:** The water tank is not electronically-controlled. Clean it regularly. Note that the water speed level is not adjustable.

6. Troubleshooting

If you encounter issues with your Proscenic M7 Pro, refer to the following common solutions:

- **Robot loses map or re-generates new map:** Avoid moving the machine manually during operation. If the map is lost, the robot will re-generate a new one, which may be incomplete.
- **Wi-Fi connection problems:** Log out and then log in again to the Proscenic Home app. If issues persist, contact customer support.
- **Reduced suction power:** Clean the dust bin and HEPA filter. Check the main brush for any tangled hair or debris.
- **Robot gets stuck frequently:** Ensure the floor is clear of small obstacles like cables or toys. Check the overstepping ability (climbs up to 20mm thick rugs easily).

7. Specifications

Attribute	Value
Brand	Proscenic
Model Name	M7 Pro LDS
Special Feature	HEPA
Color	Black
Battery Life	150 minutes
Suction Power	Max 2700Pa
Battery Capacity	5200mAh Lithium-Ion
Noise Level	65-73dB
Product Dimensions	13.78 x 13.78 x 3.86 inches
Item Weight	9.59 pounds

8. Warranty & Support

The Proscenic M7 Pro Robot Vacuum Cleaner comes with a**12-month warranty** for quality-related problems.

For further assistance or inquiries, please refer to the official user guide or contact Proscenic customer support through Amazon.

You can also find the full User Guide (PDF)here.

© 2023 Proscenic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Z9YWWKD

More documents and user manuals: **https://manuals.plus/**