Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cartrend 10636

Cartrend 10636 LED Warning Light Instruction Manual

Model: 10636

Introduction

Welcome to your new Cartrend 10636 LED Warning Light. This versatile device is designed to enhance visibility and safety in various situations, featuring multiple light programs and a durable construction. Please read this manual carefully before use to ensure proper operation, maximize its lifespan, and understand all safety precautions.

Safety Information

Please observe the following safety guidelines to prevent injury or damage to the device:

- This warning light is intended to increase visibility and does not replace proper safety precautions or official warning triangles where required by law.
- Do not look directly into the LED lights, as this may cause temporary vision impairment.
- Keep out of reach of children.
- Ensure batteries are inserted correctly according to polarity markings. Incorrect insertion can damage the device or cause battery leakage.
- Remove batteries if the device will not be used for an extended period to prevent battery leakage and corrosion.
- Dispose of used batteries responsibly according to local regulations.
- Do not attempt to open or modify the device. There are no user-serviceable parts inside.

Package Contents

Verify that all items are present in your package:

- 1 x Cartrend 10636 LED Warning Light
- 3 x AAA Batteries
- 1 x Carabiner clip (integrated)

Product Features

The Cartrend 10636 LED Warning Light offers a range of features for enhanced safety and utility:

- **Versatile Lighting:** Equipped with 16 ultra-bright LEDs (12 red for warning, 4 white for illumination).
- **Multiple Warning Modes:** Features 9 distinct red flashing warning functions, including rotation, triple flash, alternating light, SOS (Morse code), and permanent light (2 or 4 LEDs).

- **Flashlight Function:** Includes 1 continuous bright white light mode for use as a conventional flashlight.
- **Convenient Attachment:** An integrated carabiner allows for easy hanging or attachment to various objects.
- **Power Source:** Operates efficiently on 3 AAA batteries (included).
- **Durable Design:** Constructed for reliability and to withstand various conditions.

Setup

Battery Installation

To prepare your LED Warning Light for use, install the included AAA batteries:

1. Locate the battery compartment cover on the back of the LED warning light.
2. Twist or slide the cover to open it, following any indicated arrows or markings.
3. Insert 3 AAA batteries, ensuring correct polarity (+/-) as clearly indicated inside the compartment.
4. Replace the battery compartment cover securely, ensuring it is fully closed to maintain water resistance.



Image: The Cartrend 10636 LED Warning Light, showcasing its compact design and integrated carabiner clip, ready for battery installation.

Operating Instructions

Turning On/Off and Mode Selection

The Cartrend 10636 LED Warning Light features a single button for power control and cycling through its various light modes.

1. **To Turn On:** Press the power button once. The light will activate in the first warning mode.
2. **To Change Mode:** Press the power button repeatedly to cycle through the 9 red warning modes and the white flashlight mode.
3. **To Turn Off:** Press and hold the power button for approximately 2-3 seconds until the light turns off. Alternatively, cycling through all modes will eventually turn the light off after the last mode.

Warning Light Modes (Red LEDs)

The 9 red warning modes are designed for various emergency and signaling purposes:

- Rotation
- Triple Flash
- Alternating Light
- SOS (Morse Code signal)
- Permanent Light (2 LEDs)
- Permanent Light (4 LEDs)

- *Other variations of flashing and steady red light patterns.*

Flashlight Mode (White LEDs)

Cycle through the red warning modes until the 4 white LEDs illuminate continuously. This mode provides a steady, bright white light suitable for general illumination tasks.

Using the Carabiner

The integrated carabiner allows for convenient attachment. You can clip the warning light to clothing, bags, vehicle components, or other suitable anchor points for hands-free operation or to increase its visibility from different angles.

Maintenance

Proper care will ensure the longevity and optimal performance of your LED Warning Light:

- **Cleaning:** Wipe the device with a soft, slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the casing or LEDs.
- **Battery Care:** Replace batteries when the light dims, flickers, or stops functioning. Always use fresh, high-quality AAA batteries. Do not mix old and new batteries or different types of batteries.
- **Storage:** Store the warning light in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Remove batteries if storing for extended periods (more than a month) to prevent potential leakage and damage.

Troubleshooting

If you encounter any issues with your Cartrend 10636 LED Warning Light, refer to the following common problems and solutions:

Light does not turn on:

- Check if batteries are inserted correctly with the positive (+) and negative (-) terminals aligned as indicated.
- Replace with fresh AAA batteries. Old or depleted batteries may not provide enough power.
- Ensure the battery compartment cover is securely closed.

Light is dim or flickers:

- Batteries may be low. Replace with fresh AAA batteries.

Cannot change modes:

- Ensure the power button is being pressed firmly and released.
- If the issue persists, try replacing the batteries.

If these steps do not resolve the issue, please contact Cartrend customer support for further assistance.

Specifications

Technical details for the Cartrend 10636 LED Warning Light:

Model Number	10636
LEDs	16 (12 Red, 4 White)
Light Programs	9 Red Warning Modes, 1 White Flashlight Mode
Power Source	3 x AAA Batteries (included)
Dimensions (L x W x H)	11 x 15 x 4 cm (approximately 4.3 x 5.9 x 1.6 inches)

Weight	1.42 kg (approximately 3.13 lbs) *(Note: This weight appears unusually high for a device of this size and type. Please verify upon receipt.)*
Manufacturer	CARTREND
ASIN	B07ZQV42LC
International Article Code (EAN)	04038373064776

Warranty and Support

Cartrend products are manufactured to high-quality standards. For specific warranty information, including terms and duration, please refer to the documentation included with your purchase. For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please visit the official Cartrend website or contact their customer service department. Please retain your proof of purchase for any warranty claims.

© 2023 Cartrend. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07ZQV42LC

More documents and user manuals: **https://manuals.plus/**