Innsky IS-AF002

Innsky IS-AF002 Air Fryer Oven User Manual

Comprehensive Guide for Operation and Maintenance

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

2. Product Overview

The Innsky IS-AF002 Air Fryer Oven is a versatile 10-in-1 kitchen appliance designed for healthy cooking with

minimal oil. It combines the functions of an air fryer, rotisserie, dehydrator, and oven, offering a wide range of cooking possibilities.



Figure 2.1: Front view of the Innsky IS-AF002 Air Fryer Oven, showcasing its digital display and transparent cooking window.

Key Features:

- **10-in-1 Functionality:** Air fryer, barbecue, fruit dehydrator, pizza oven, and conventional oven.
- **Healthy Cooking:** Utilizes 360° hot air circulation to reduce oil usage by up to 80% compared to traditional frying.
- **Large Capacity:** 10-liter extra-large capacity, suitable for family meals.
- **Digital LED Display:** Intuitive touch screen for easy program selection and control.
- **Rotation Mode:** Ensures even heating without manual shaking, ideal for rotisserie chicken or fries.

- **Internal Light Function:** Allows monitoring of cooking progress without opening the door.
- **Wide Temperature Range:** From 80°C to 200°C for various cooking methods.
- **Stainless Steel Construction:** Durable and easy to clean.

3. Package Contents

Please check the package contents upon unboxing to ensure all items are present and undamaged:

- Innsky IS-AF002 Air Fryer Oven Main Unit
- 2 x Dehydration/Cooking Racks
- 6 x Skewers
- 1 x Rotisserie Basket (Drum Basket)
- 1 x Rotisserie Spit
- 1 x Rotisserie Forks
- 1 x Drip Tray
- 1 x Rotisserie Removal Tool
- Recipe Book
- User Manual (this document)



Figure 3.1: Included accessories for the Innsky Air Fryer Oven, showing the various racks, skewers, and rotisserie tools.

4. Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials and accessories from the unit.

2. **Cleaning:** Wipe the exterior of the appliance with a damp cloth. Wash all removable parts (racks, basket, drip tray, etc.) with warm soapy water. Rinse and dry thoroughly.
3. **Placement:** Place the main unit on a stable, heat-resistant, and level surface, away from walls or other appliances to allow for proper air circulation. Ensure there is at least 10 cm of clear space on all sides.
4. **Power Connection:** Plug the power cord into a grounded wall outlet.
5. **Pre-heating (First Use):** For the first use, it is recommended to run the appliance empty for about 10-15 minutes at 180°C (350°F) to burn off any manufacturing residues. A slight odor may be present, which is normal and will dissipate.

5. Operating Instructions

The Innsky Air Fryer Oven features an intuitive digital LED touch screen for easy operation.



Figure 5.1: Digital LED control panel with various preset program icons and control buttons.

5.1 Basic Operation

- **Power On/Off:** Press the power icon () to turn the unit on or off.
- **Temperature Adjustment:** Use the temperature icons (**+** / **-**) to increase or decrease the cooking temperature. The range is typically 80°C to 200°C.

- **Time Adjustment:** Use the time icons (+ / -) to increase or decrease the cooking time.
- **Start/Pause:** Press the start/pause icon to begin or temporarily stop the cooking process.

5.2 Preset Programs

The appliance comes with 10 pre-defined programs for common dishes. Simply touch the corresponding icon to select a program. The default time and temperature will be set, which can then be adjusted manually if needed.

Program	Description	Typical Use
Fries	For crispy French fries.	Potatoes, sweet potato fries.
Steak	For various cuts of steak.	Beef, lamb, pork steaks.
Fish	For cooking fish fillets.	Salmon, cod, tilapia.
Shrimp	For quick and even shrimp cooking.	Fresh or frozen shrimp.
Pizza	For heating or baking pizzas.	Frozen pizza, homemade pizza.
Chicken	For chicken pieces or whole chicken.	Chicken wings, drumsticks, whole chicken (using rotisserie).
Cake	For baking cakes and pastries.	Muffins, small cakes.
Roast	For roasting larger cuts of meat.	Pork roast, beef roast.
Fruit	For dehydrating fruits.	Apple slices, banana chips, dried berries.
Dehydrate	General dehydrating function.	Vegetables, herbs, jerky.

5.3 Special Functions

- **Rotation Function:** Press the rotation icon (↻) to activate the rotisserie function. This is essential when using the rotisserie basket or spit to ensure even cooking.
- **Internal Light:** Press the light icon () to illuminate the interior of the oven, allowing you to check the cooking progress without opening the door and losing heat.
- **Preheat Function:** Some models may include a preheat function. If available, press the preheat icon to bring the oven to the desired temperature before adding food.



Figure 5.2: The air fryer oven demonstrating its multi-functionality, including 360° hot air circulation for efficient cooking.

6. Using Accessories

The Innsky Air Fryer Oven comes with a variety of accessories to expand your cooking options.



Dehydration/Cooking Racks

These perforated racks allow for multi-level cooking and are ideal for dehydrating fruits and vegetables, or for cooking items like chicken wings and pastries.



Skewer Rack & Skewers

Use the skewer rack with the included skewers for preparing kebabs with meat, vegetables, or fruit. Insert the skewers into the designated slots on the rack.



Rotisserie Basket (Drum Basket)

Ideal for cooking smaller items like French fries, nuts, or popcorn. Place food inside, secure the lid, and insert into the rotisserie mounts. Activate the rotation function.



Rotisserie Spit & Forks

Used for roasting whole chickens or larger cuts of meat. Secure the meat with the forks on the spit, then insert the spit into the rotisserie mounts inside the oven. Ensure the rotation function is active.



Drip Tray

Always place the drip tray at the bottom of the oven to collect any oil or food drippings, making cleanup easier.

7. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your appliance.

1. **Unplug and Cool:** Always unplug the air fryer oven from the power outlet and allow it to cool completely before cleaning.
2. **Removable Parts:** All removable parts, including the racks, rotisserie basket, skewers, spit, and drip tray, are dishwasher safe. Alternatively, wash them with warm water and a mild dish soap. Rinse thoroughly and dry completely before storing or reassembling.
3. **Interior Cleaning:** Wipe the interior of the oven with a damp cloth and mild detergent. For stubborn food residues, use a non-abrasive sponge. Do not use abrasive cleaners or metal scouring pads, as they can damage the non-stick coating.
4. **Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Storage:** Ensure the appliance and all accessories are clean and dry before storing. Store in a cool, dry place.

8. Troubleshooting

If you encounter any issues with your Innsky Air Fryer Oven, please refer to the following table before contacting customer support.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in. Power outlet malfunction.	Ensure the power cord is securely plugged into a grounded outlet. Test the outlet with another appliance.
Food is not cooked evenly.	Overcrowding. Incorrect temperature/time. Rotation function not active (for rotisserie).	Do not overcrowd the basket/racks. Cook in batches if necessary. Adjust temperature and time according to recipe. Ensure rotation function is activated for rotisserie cooking.
White smoke coming from the appliance.	Grease/oil residue in drip tray. Fatty food being cooked.	Clean the drip tray thoroughly after each use. Place a small amount of water in the drip tray when cooking very fatty foods to prevent smoke.
Food is not crispy.	Too much moisture. Not enough oil (for certain foods). Overcrowding.	Pat food dry before air frying. Lightly spray or toss food with a small amount of oil. Cook in smaller batches.

9. Specifications

Feature	Detail
Model Number	IS-AF002
Brand	Innsky
Capacity	10 Liters
Power	1500 Watts
Voltage	2.3E+2 Volts (230V)
Material	Stainless Steel
Color	Metallic Silver
Dimensions (L x W x H)	38.4 x 39.1 x 44.5 cm
Item Weight	100 Grams *(Note: This weight appears to be a data entry anomaly and may not reflect the actual product weight.)*
Control Method	Touch
Noise Level	65 dB

10. Warranty and Support

Innsky products are manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Innsky website.

If you have any questions, require technical assistance, or need to report an issue, please contact Innsky Customer Support. Contact details can typically be found on the product packaging, the official website, or the warranty card.

Please have your model number (IS-AF002) and purchase details ready when contacting support.

© 2024 Innsky. All rights reserved.