Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY NH312UP

User Manual for ALLIMITY NH312UP Replacement Remote Control

Model: NH312UP

Introduction

This manual provides instructions for the setup, operation, and maintenance of your new ALLIMITY NH312UP Replacement Remote Control. This remote is designed as a direct replacement for various Sanyo LED LCD HDTV models, requiring no programming. Simply insert batteries, and it is ready for use.

Package Contents

- 1 x ALLIMITY NH312UP Replacement Remote Control

Note: Batteries are not included and must be purchased separately.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.





Image: Rear view of the NH312UP remote control with the battery cover removed, illustrating the battery insertion process. Two AAA battery slots are visible.

Once batteries are installed, the remote control is ready for immediate use with compatible Sanyo LED LCD HDTV models without any additional programming.

Operating Instructions

Basic Operation

To operate your Sanyo LED LCD HDTV using the NH312UP remote control, point the remote directly towards the infrared (IR) sensor on your television. Ensure there are no obstacles between the remote and the TV's sensor that could block the signal.





Image: Front view of the NH312UP remote control, displaying its full button layout. Key buttons include Power, Source, Number Pad, Volume Up/Down, Channel Up/Down, Menu, Back, Info, and a central navigation cluster with OK button.

Key Functions

- **Power ( )**: Turns the TV on or off.
- **Source**: Cycles through input sources (HDMI, AV, Component, etc.).
- **Number Pad (0-9)**: Directly enters channel numbers.
- **VOL +/-**: Adjusts the volume level.
- **CH +/-**: Changes the television channel.
- **Mute ( )**: Mutes or unmutes the TV audio.
- **Menu**: Accesses the TV's main menu for settings and options.
- **Navigation Arrows (▲ ▼ ◀ ▶) & OK**: Navigates through menus and confirms selections.
- **Back**: Returns to the previous screen or menu.
- **Info**: Displays information about the current program or input.
- **CC (Closed Caption)**: Toggles closed captions on or off.
- **Sleep**: Sets a timer for the TV to turn off automatically.
- **PIC/SOUND MODE**: Adjusts picture or sound presets.
- **PIX SHAPE**: Adjusts the picture aspect ratio.
- **SAP (Secondary Audio Program)**: Toggles secondary audio programs.
- **PREV.CH**: Returns to the previously viewed channel.

Compatible Models

This ALLIMITY NH312UP Replacement Remote Control is compatible with the following Sanyo LED LCD HDTV models:

- FW32D06F, FW32D06FB, FW32D06F-B
- FW32D08F
- FW40D36F, FW40D36FB, FW40D36F-B
- FW40D48F
- FW43D25F, FW43D47F
- FW50D36F, FW50D36FB, FW50D36F-B
- FW50D48F
- FW55D25F

If your specific Sanyo TV model is not listed, but matches the remote's appearance and button layout, it may still be compatible. For confirmation, please refer to your TV's original manual or contact customer support.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.
- **Avoid Damage:** Do not drop the remote, expose it to extreme temperatures, or immerse it in water.

Troubleshooting

Problem	Possible Cause / Solution
Remote control is not working.	• **Batteries:** Check if batteries are inserted correctly (polarity). Replace with new AAA batteries. • **Line of Sight:** Ensure there are no obstructions between the remote and the TV's IR sensor. Point the remote directly at the TV. • **Distance:** Make sure you are within the effective operating range of the remote (typically up to 20 feet). • **TV Sensor:** Verify that the TV's IR sensor is not blocked or damaged.
Some buttons are not responding.	• **Battery Level:** Low battery power can cause intermittent button response. Replace batteries. • **Dirt/Debris:** Clean the remote, especially around the unresponsive buttons, to ensure no debris is preventing contact.

Specifications

- **Model Number:** NH312UP
- **Product Material:** Plastic
- **Connective Technology:** Infrared (IR)
- **Power Source:** 2 x AAA Batteries (not included)
- **Dimensions:** Approximately 7 x 2 x 0.65 inches
- **Weight:** Approximately 2.11 ounces (without batteries)
- **Compatible Devices:** Sanyo LED LCD HDTVs (specific models listed in "Compatible Models" section)

Warranty and Support

This product is a replacement remote control and typically comes with a standard return/replacement policy. For specific warranty details or if you encounter issues not covered in this manual, please contact the seller directly through your purchase platform.
For further assistance, you may contact ALLIMITY customer support. Please refer to your purchase documentation for contact information or visit the ALLIMITY official website.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07ZYQC8KL

More documents and user manuals: **https://manuals.plus/**