Beyblade E7729

Beyblade Burst Rise Hypersphere Dual Pack Lord Spryzen S5 and Roktavor R5-1 Instruction Manual

Model: E7729

Introduction

This manual provides essential instructions for the assembly, operation, and care of your Beyblade Burst Rise Hypersphere Dual Pack, featuring Lord Spryzen S5 and Roktavor R5-1 battling tops. Please read these instructions carefully before use to ensure proper functionality and safety.

Safety Information

WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years.
Always use Beyblade Burst products in a safe environment, away from obstacles and other people. Do not aim tops at eyes or face. Use only official Beyblade Burst components.

Package Contents



Image: Front view of the Beyblade Burst Rise Hypersphere Dual Pack packaging, displaying the two tops and indicating additional items required for play.

- 1x Lord Spryzen S5 Battling Top (Energy Layer, Forge Disc D69, Performance Tip TH21)
- 1x Roktavor R5 Battling Top (Energy Layer, Forge Disc D07, Performance Tip TH14)
- Instructions

Note: Beyblade Burst Hypersphere Beystadium and launchers are required for play and are sold separately.

Setup and Assembly

Each Beyblade Burst top consists of three main components: an Energy Layer, a Forge Disc, and a Performance Tip. Follow these steps to assemble your tops:

1. **Attach the Forge Disc:** Align the Forge Disc with the slots on the underside of the Energy Layer. Press firmly until it clicks into place.
2. **Attach the Performance Tip:** Align the Performance Tip with the center of the Forge Disc. Twist until it locks securely.
3. **Verify Assembly:** Ensure all components are firmly attached before launching.



Image: Exploded view of Lord Spryzen S5 and Roktavor R5 components, illustrating how the Energy Layer, Forge Disc, and Performance Tip connect.



Image: Fully assembled Lord Spryzen S5 and Roktavor R5 battling tops.

Operating Instructions

To engage in a Beyblade Burst battle, you will need a Beyblade Burst Hypersphere Beystadium and a Beyblade Burst launcher (both sold separately).

1. **Load the Top:** Attach your assembled Beyblade Burst top to a Beyblade Burst launcher. Ensure it is securely locked.
2. **Launch:** Hold the launcher over the Beyblade Burst Hypersphere Beystadium. Pull the rip cord or press the launch button to release the top into the stadium.
3. **Hypersphere Advantage:** The specialized Hypersphere Performance Tips are designed to allow tops to climb the vertical wall of a Hypersphere Beystadium, speed along the brink, and drop into the center for dynamic battles.
4. **Spin Direction:** Lord Spryzen S5 features a unique right/left-spin GT Chip in its Energy Layer, allowing it to be launched in either direction. Roktavor R5 is a right-spin top.
5. **Digital Battles:** Scan the code on the Energy Layer of your Beyblade Burst Hypersphere tops using the Beyblade Burst app to unlock them for digital battles and customize components within the app.

Maintenance

- **Cleaning:** Wipe tops with a dry cloth to remove dust and debris. Do not use water or cleaning solutions, as this may damage the components.
- **Storage:** Store tops and launchers in a cool, dry place away from direct sunlight to prevent material degradation.
- **Inspection:** Regularly inspect components for wear or damage. Replace any damaged parts to ensure optimal performance and safety.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Top does not spin or spins weakly.	Improper loading onto launcher, worn-out launcher, or damaged top components.	Ensure top is securely attached to the launcher. Check launcher for damage. Inspect top components for wear and replace if necessary.
Top bursts frequently.	Loose assembly, incompatible components, or aggressive battle style.	Verify all components are tightly assembled. Ensure components are compatible Beyblade Burst parts. Experiment with different launch techniques.
Top does not climb Hypersphere wall effectively.	Incorrect Beystadium, worn Performance Tip, or insufficient launch power.	Ensure you are using a Beyblade Burst Hypersphere Beystadium. Check Performance Tip for wear. Practice launching with consistent power.

Specifications

Model Number: E7729

Product Dimensions: 1.5 x 6 x 8 inches

Item Weight: 3.52 ounces

Manufacturer Recommended Age: 8 years and up

Manufacturer: Hasbro

Release Date: April 20, 2020

Warranty and Support

For warranty information or product support, please contact Hasbro customer service. Details can typically be found on the product packaging or the official Hasbro website. Keep your purchase receipt as proof of purchase.
For additional information and resources, visit the official Beyblade website or the Beyblade Burst app.

© 2023 Beyblade. All rights reserved. Beyblade and all related terms are trademarks of Hasbro.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question