Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

oneisall 54328c19-d947-4ae2-b345-87fb3c7822bb

oneisall Low Noise Dog Clippers Replacement Charger User Manual

Model: 54328c19-d947-4ae2-b345-87fb3c7822bb

1. Introduction

This manual provides essential information for the safe and effective use of your oneisall Replacement Charger for Low Noise Dog Clippers. Please read this manual thoroughly before use and retain it for future reference.
This charger is specifically designed for use with compatible oneisall Low Noise Dog Clippers models. It is crucial to verify your clipper model's compatibility before connecting the charger.

2. Safety Information

Please observe the following safety precautions to prevent damage to the charger, clippers, or personal injury:

- **Compatibility:** ONLY use this charger with the specified oneisall dog clipper models. Using it with incompatible devices or other brands may cause damage or fire.
- **Indoor Use Only:** This charger is intended for indoor use in dry conditions. Do not expose it to water, moisture, or high humidity.
- **Power Source:** Connect the charger only to a standard electrical outlet with the correct voltage (100-240V AC).
- **Inspect Before Use:** Before each use, inspect the charger cord and plug for any signs of damage. Do not use if damaged.
- **Unplug When Not In Use:** Disconnect the charger from the power outlet when not in use or during electrical storms.
- **Keep Away From Children:** Store the charger out of reach of children and pets.
- **Ventilation:** Ensure adequate ventilation around the charger during operation. Do not cover it.
- **Disassembly:** Do not attempt to disassemble or repair the charger yourself. Contact customer support for assistance.

3. Package Contents

Upon opening the package, please ensure all items are present and in good condition:

- oneisall Replacement Charger (1 unit)



Image: The oneisall replacement charger, featuring a standard US two-prong power plug on one end and a barrel connector on the other, connected by a black power cord.

4. Setup

Follow these steps to set up your oneisall Replacement Charger:

1. **Unpack:** Carefully remove the charger from its packaging.
2. **Inspect:** Check the charger and cord for any visible damage. If damaged, do not proceed.
3. **Identify Charging Port:** Locate the charging port on your oneisall dog clippers. Ensure it matches the barrel connector of this charger.
4. **Connect to Clippers:** Insert the barrel connector end of the charger firmly into the charging port of your oneisall dog clippers.
5. **Connect to Power:** Plug the two-prong power plug into a standard 100-240V AC wall outlet.



Image: A close-up view of the oneisall replacement charger, highlighting the barrel connector and the power adapter unit with its specifications label.

5. Operating Instructions

Once properly connected, the charger will begin to supply power to your oneisall dog clippers. The charging indicator on your clippers (if present) will typically illuminate to show charging status.

- **Charging Time:** Refer to your specific oneisall dog clipper manual for recommended charging times. Avoid overcharging.
- **Charging Environment:** Charge the clippers in a well-ventilated area, away from direct sunlight or heat sources.
- **Disconnecting:** Once charging is complete, first unplug the charger from the wall outlet, then disconnect the barrel connector from the clippers.

6. Maintenance

Proper care will extend the life of your charger:

- **Cleaning:** Disconnect the charger from power before cleaning. Wipe the exterior with a soft, dry cloth. Do not use

liquid cleaners or abrasive materials.

- **Storage:** Store the charger in a cool, dry place when not in use. Avoid tightly winding the cord to prevent damage.
- **Cord Care:** Do not pull on the cord to unplug the charger from the wall or the clippers. Always grasp the plug or connector directly.

7. Troubleshooting

Problem	Possible Cause	Solution
Charger not working / Clippers not charging	◦ Charger not properly plugged in. ◦ Wall outlet has no power. ◦ Charger or cord is damaged. ◦ Clippers are incompatible with this charger. ◦ Clippers' charging port is damaged.	◦ Ensure both ends of the charger are securely connected. ◦ Test the wall outlet with another device. ◦ Inspect charger and cord for damage. If damaged, discontinue use and replace. ◦ Verify your clipper model against the compatible list in this manual. ◦ Contact oneisall customer support for clipper repair or replacement.
Charger feels warm during use	Normal operation.	This is normal. If it becomes excessively hot or emits smoke/odor, unplug immediately and discontinue use.

8. Specifications

Model Number	54328c19-d947-4ae2-b345-87fb3c7822bb
Brand	oneisall
Input Voltage	100-240V AC
Output Wattage	5 Watts
Output Current	1 Amp
Connector Type	Barrel Connector
Compatible Clipper Models	26225202-003DE, P2, X3, X2, C61, N6, A11, K52NTS, B01HRSZRXM, B07H9WJYK2, B01LW145RS, B0999J4PTJ, B0999L43RQ, B082Y1XZVG, B083QHKD16, B098D92VSC, B098BGFSL6, B098BFT3CF, B098BCHLB4
Incompatible Clipper Models	B07G0FRD1D, B07D329CRD, B07C1LBYXPMX, B071SSK0M4
Dimensions (Package)	4.8 x 2.56 x 1.38 inches
Item Weight	2.39 ounces

9. Warranty and Support

The product information does not explicitly state a warranty period for this specific charger. However, oneisall generally offers customer support.
For product support, warranty inquiries, or to report issues, please contact oneisall customer service. You can typically find contact information on the official oneisall website or through your purchase platform.
Manufacturer: oneisall
Date First Available: November 8, 2019

© 2023 oneisall. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0816SJ7JW

More documents and user manuals: **https://manuals.plus/**