Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Innsky IS-AF002

Innsky 10L 1500W Air Fryer Oven Instruction Manual

Model: IS-AF002

Introduction

Thank you for choosing the Innsky 10L 1500W Air Fryer Oven, Model IS-AF002. This appliance is designed to provide a healthier way to cook your favorite meals with minimal oil. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new air fryer oven. Please read it thoroughly before first use and retain it for future reference.



This image displays the front view of the Innsky 10L Air Fryer Oven, highlighting its digital control panel and the transparent cooking window with a rotating drum basket inside.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury. Please read all instructions carefully.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.

- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Adequate space (at least 10 cm) should be left on all sides of the appliance for proper ventilation.

Product Overview

Key Features

- **Low Oil and Delicious:** Utilizes 360° hot air circulation for crispy fries and juicy chicken, reducing oil consumption by 80% compared to traditional deep frying. Operates below 65 dB.
- **10-in-1 Appliance:** Functions as an air fryer, grill, fruit dehydrator, pizza oven, and conventional oven. Offers a wide temperature range of 80°C to 200°C.
- **Large Capacity:** Extra-large 10-liter capacity with two cooking levels, suitable for preparing meals for multiple family members.
- **Easy to Use and Safe:** Features an intuitive touch screen, a rotation mode for even cooking, and an internal light to monitor progress.
- **Simplify Household Chores:** Designed for easy cleaning with a removable door and dishwasher-safe detachable parts.

Components and Accessories

Your Innsky Air Fryer Oven comes with several components and accessories to enhance your cooking experience.



This image showcases the six included dishwasher-safe accessories: two mesh racks for multi-level cooking, a drip tray for easy cleanup, a rotisserie shaft for whole poultry, a removal tool for hot accessories, six skewers for kebabs, and a rotating drum basket for fries or nuts.

- **Main Unit:** The air fryer oven body with control panel and transparent door.
- **Mesh Trays (2):** For dehydration and multi-level cooking.
- **Drip Tray (1):** Collects excess oil and food particles for easier cleaning.

- **Rotisserie Shaft (1):** For roasting whole chicken or other large items.
- **Rotisserie Fork (1):** Tool for safely removing the rotisserie shaft.
- **Skewers (6):** For preparing kebabs.
- **Rotating Drum Basket (1):** Ideal for fries, nuts, or other small items that require tumbling.

Setup

1. **Unpack:** Carefully remove all packaging materials and accessories from the box.
2. **Clean:** Wipe the exterior of the appliance with a damp cloth. Wash all accessories (mesh trays, drip tray, rotisserie shaft, skewers, drum basket) with warm soapy water, rinse thoroughly, and dry completely.
3. **Placement:** Place the main unit on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of clear space around all sides of the appliance for adequate ventilation.
4. **First Use Burn-Off:** Before cooking food, operate the air fryer oven empty for approximately 15-20 minutes at 200°C (390°F) to burn off any manufacturing residues. A slight odor or smoke may be present during this process; this is normal. Ensure the area is well-ventilated. Allow the unit to cool completely afterward.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.



An illustration showing the compact dimensions of the Innsky 10L Air Fryer Oven, measuring 33.6 cm in width, 33.6 cm in depth, and 37 cm in height, suitable for various kitchen spaces.

Operating Instructions

Control Panel

The Innsky Air Fryer Oven features an intuitive LED touch control panel for easy operation.



A close-up of the Innsky Air Fryer Oven's intuitive touch control panel, demonstrating how users can easily adjust settings for temperature, activate the interior light, manage power, control rotation, preheat, and set the timer.

- **Power Button:** Turns the appliance on/off.
- **Temperature Control (+/-):** Adjusts cooking temperature (80°C - 200°C).

- **Time Control (+/-):** Adjusts cooking time.
- **Preset Icons:** Select from 10 pre-programmed cooking functions (e.g., fries, chicken, fish, steak, pizza, bake, dehydrate).
- **Rotation Button:** Activates/deactivates the rotisserie function for even cooking.
- **Light Button:** Turns the interior light on/off to monitor food.
- **Preheat Button:** Initiates a preheating cycle.

General Cooking Steps

1. Prepare your food and place it on the appropriate accessory (mesh tray, drum basket, or rotisserie shaft).
2. Insert the accessory into the air fryer oven. Ensure the drip tray is at the bottom to catch any drippings.
3. Close the door securely.
4. Press the Power Button to turn on the appliance.
5. Select a preset cooking function or manually set the desired temperature and time using the Temperature and Time Control buttons.
6. If using the rotisserie or drum basket, press the Rotation Button.
7. Press the Start/Pause button (often integrated with the Power button or a separate icon) to begin cooking.
8. Monitor cooking progress using the interior light and transparent window.
9. Once cooking is complete, the appliance will beep and automatically shut off.
10. Carefully remove the cooked food and accessories using heat-resistant gloves and the rotisserie fork if applicable.

Using the Rotisserie Function

The rotisserie function is ideal for roasting whole chickens or other large cuts of meat, ensuring even cooking and a crispy exterior.

1. Prepare your food (e.g., a whole chicken) and secure it onto the rotisserie shaft using the forks. Ensure it is balanced.
2. Insert the rotisserie shaft into the designated slots inside the oven.
3. Select your desired cooking settings (temperature and time).
4. Press the Rotation Button to activate the rotisserie.
5. When cooking is complete, use the rotisserie fork to safely remove the hot shaft and food from the oven.



A visual comparison showing a raw chicken on the left and a golden-brown, crispy roasted chicken on the right, illustrating the cooking capabilities of the air fryer.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your Innsky Air Fryer Oven.

- **Always unplug** the appliance and allow it to cool completely before cleaning.

- **Removable Door:** The oven door can be easily removed for thorough cleaning. Open the door to a 45-degree angle, then gently lift it upwards to detach. Wash with warm soapy water, rinse, and dry.
- **Interior:** Wipe the interior with a damp cloth and mild detergent. For stubborn food residue, use a non-abrasive sponge. Avoid abrasive cleaners or metal scouring pads.
- **Exterior:** Wipe the exterior with a soft, damp cloth. Do not immerse the main unit in water.
- **Accessories:** All detachable accessories (mesh trays, drip tray, rotisserie shaft, skewers, drum basket) are dishwasher-safe. Alternatively, wash them by hand with warm soapy water and a non-abrasive sponge.
- **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.



This composite image highlights key design features: an integrated light for monitoring cooking progress, a removable door that opens to a 45-degree angle for easy cleaning, a transparent window to view food, and a durable stainless steel interior.

TROUBLESHOOTING

If you encounter any issues with your air fryer oven, please refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; appliance damaged.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If still not working, contact customer support.
Food is not cooked evenly.	Overcrowding; incorrect temperature/time; rotation not activated.	Do not overcrowd the basket/trays. Ensure food is spread in a single layer. Adjust temperature/time as needed. Activate the rotation function for items like fries or whole chicken.

Problem	Possible Cause	Solution
White smoke coming from the appliance.	Grease/oil residue; fatty food; initial burn-off.	Clean the drip tray and interior thoroughly. For fatty foods, ensure the drip tray is in place. This is normal during initial use.
Food is not crispy.	Too much moisture; not enough oil (for certain foods); overcrowding.	Pat food dry before cooking. A light spray of oil can help. Avoid overcrowding. Increase cooking time or temperature slightly.
Appliance makes loud noise.	Normal fan operation; accessory not properly seated.	A certain level of fan noise is normal. Ensure all accessories, especially the rotating basket or rotisserie, are correctly installed and secured.

Specifications

Feature	Detail
Brand	Innsky
Model Number	IS-AF002
Color	Black, Grey
Product Dimensions	41 x 41 x 46 cm (16.1 x 16.1 x 18.1 inches)
Weight	7 kg (15.4 lbs)
Capacity	10 Liters
Power	1500 Watts
Voltage	220 Volts (AC)
Material	Stainless Steel with BPA-free Plastic
Noise Level	65 dB
Special Features	Automatic shut-off, Programmable, Timer
Recommended Uses	Roasting, Defrosting, Dehydrating, Baking, Reheating

Warranty and Support

Innsky products are manufactured to the highest quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Innsky website. If you have any questions, require technical assistance, or need to claim warranty service, please contact Innsky customer support through their official channels. Please have your model number (IS-AF002) and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0817CTLQ9

More documents and user manuals: **https://manuals.plus/**