Bosch Professional BGS41PET1 Serie 6 ProAnimal

Bosch BGS41PET1 ProAnimal Series 6 Bagless Vacuum Cleaner User Manual

Model: BGS41PET1 Serie 6 ProAnimal

Introduction

This user manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Bosch BGS41PET1 ProAnimal Series 6 Bagless Vacuum Cleaner. Designed for high performance, especially in homes with pets, this vacuum features Sensor AirCycle technology, SmartSensor Control, and a hygienic HEPA filter. Please read this manual thoroughly before first use and keep it for future reference.

Safety Instructions

Always observe the following safety precautions to prevent injury or damage to the appliance:

- Do not operate the vacuum cleaner without the dust container and filter properly installed.
- Do not vacuum liquids, sharp objects, or hot ashes.
- Keep the power cord away from hot surfaces and sharp edges.
- Unplug the appliance from the power outlet before cleaning or maintenance.
- This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

Package Contents

Verify that all items are present in the packaging:

- Bosch ProAnimal Series 6 Bagless Vacuum Cleaner Unit
- Telescopic Tube
- AirTurbo Plus Brush
- Mini AirTurbo Brush
- Crevice Tool
- Upholstery Tool
- User Manual (this document)



Figure 1: Overview of the Bosch BGS41PET1 vacuum cleaner and its complete set of accessories, including the main unit, telescopic tube, AirTurbo Plus brush, mini AirTurbo brush, crevice tool, and upholstery tool.

Setup

1. **Attach the Hose:** Insert the flexible hose into the suction inlet on the main unit until it clicks securely into place.
2. **Assemble the Telescopic Tube:** Connect the telescopic tube to the hose handle. Adjust the length of the telescopic tube by pressing the release button and sliding it to your desired height.
3. **Attach the Floor Nozzle:** Select the appropriate floor nozzle (e.g., AirTurbo Plus brush for carpets and pet hair, or the hard floor nozzle for delicate surfaces) and attach it to the end of the telescopic tube. Ensure it is firmly connected.
4. **Power Connection:** Extend the power cord from the vacuum cleaner. Plug the power cord into a suitable electrical outlet.

Operating Instructions

Powering On and Off

To turn the vacuum cleaner on, press the power button located on the main unit. Press it again to turn the appliance off.



Figure 2: Location of the power button on the vacuum cleaner for easy operation.

Suction Power Control

The Bosch BGS41PET1 features variable suction control, allowing you to adjust the power according to the surface being cleaned. Use higher suction for carpets and heavily soiled areas, and lower suction for delicate surfaces like curtains or upholstery.

SmartSensor Control and QuattroPower Technology

The integrated SmartSensor Control continuously monitors the airflow and performance, ensuring optimal cleaning results on all floor types. The QuattroPower System combines a high-performance motor, nozzle, seals, and dust bag (or container) to achieve exceptional cleaning results with low energy consumption.



Figure 3: The SmartSensor Control indicator, which provides continuous performance monitoring.



Figure 4: Illustration of the powerful airflow generated by the vacuum cleaner's design, contributing to its high suction efficiency.

Using ProAnimal Brushes

The AirTurbo Plus brush and mini AirTurbo brush are specifically designed for efficient pet hair removal from carpets, upholstery, and other surfaces. The AirTurbo Plus brush features Automatic Power Control to adapt to different floor types.

Maintenance

Emptying the Dust Container

The dust container has an XL capacity and should be emptied regularly to maintain optimal suction performance.

1. Ensure the vacuum cleaner is unplugged.
2. Press the release button to detach the dust container from the main unit.
3. Carefully open the dust container over a waste bin and empty its contents. Tap gently to dislodge any stuck debris.
4. Close the dust container and reattach it to the vacuum cleaner until it clicks into place.



Figure 5: Steps for removing and emptying the vacuum cleaner's dust container.

Cleaning the HEPA Filter and SelfClean Function

The hygienic HEPA filter ensures high air filtration and is designed for effortless maintenance thanks to the automatic SelfClean system. This system helps to keep the filter clean and maintain consistent performance. For thorough cleaning, the filter can also be removed and gently tapped to remove fine dust. Do not wash the HEPA filter with water.

Cleaning Brushes

Regularly check the AirTurbo Plus brush and mini AirTurbo brush for tangled hair or debris.

1. Ensure the vacuum cleaner is unplugged.
2. To remove the brush roll from the AirTurbo Plus brush, locate the release mechanism (often a button or lever) and activate it. Gently pull the brush roll out.
3. Remove any tangled hair or fibers from the brush roll using scissors or a brush cleaning tool.
4. Reinsert the clean brush roll until it clicks securely into place.



Figure 6: The EasyClean feature allows for simple removal of the brush roll for cleaning.



Figure 7: Individual components of the brush head, illustrating how they can be separated for thorough cleaning.

Troubleshooting

Before contacting customer service, please refer to the following common issues and their solutions:

Problem	Possible Cause	Solution
Loss of Suction Power	Dust container is full. Filter is clogged. Hose or nozzle is blocked.	Empty the dust container. Clean the HEPA filter (use SelfClean or tap gently). Check hose, telescopic tube, and nozzles for blockages and remove them.
Unusual Noise During Operation	Blockage in the hose or nozzle. Brush roll is obstructed. Motor issue (less common).	Check and clear any blockages. Clean the brush roll, removing tangled hair or debris. If noise persists after checking for blockages, contact customer support.

Problem	Possible Cause	Solution
Difficulty Removing Brushes/Attachments	Release mechanism not fully engaged. Tight fit.	Ensure you are pressing the designated release button firmly. Apply gentle but firm pressure while wiggling the attachment to loosen it.
Power Cord Retracts During Use	Automatic rewind mechanism is sensitive.	Pull the cord out fully and then release it slightly to engage the lock. Avoid pulling it too far or too quickly during operation.

Specifications

Feature	Detail
Brand	Bosch Professional
Model Number	BGS41PET1 Serie 6 ProAnimal
Color	Red
Dust Container Capacity	4 Liters (XL)
Filter Type	Hygienic HEPA Filter
Special Feature	Designed for pet hair removal
Operating Radius	10 Meters
Sound Level	72 dB
Weight (without accessories)	5.6 kg

Warranty and Support

Your Bosch BGS41PET1 ProAnimal Series 6 Bagless Vacuum Cleaner comes with a manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions, including warranty period and coverage details.
For technical support, spare parts, or warranty claims, please contact Bosch customer service. You can find contact information on the official Bosch Professional website or through the retailer where you purchased the product.
Online Resources: Visit the official Bosch Home Appliances website for product registration, FAQs, and additional support.

© 2024 Bosch Professional. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question