Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beurer 73579

Beurer GS 400 Signature Line Glass Personal Scale User Manual

Model: GS 400 (73579)
Brand: Beurer

Introduction

The Beurer GS 400 Signature Line Glass Personal Scale is designed for precise and reliable body weight measurement. Featuring a modern design with a large platform made of super white safety glass and a stylish black XL display, this scale offers both functionality and aesthetic appeal. This manual provides essential information for the safe and effective use of your new personal scale.



Image: Beurer GS 400 White Signature Line Glass Personal Scale. The scale is white with a large glass surface and a black digital display showing "62.4 kg".

Safety Information

Please read these safety instructions carefully before using the device. Keep this manual for future reference.

- Always place the scale on a firm, level surface to ensure accurate measurements.
- Do not use the scale in areas with high humidity or near water.
- The scale is designed for personal use only and is not intended for commercial or medical purposes.
- Do not jump on the scale or subject it to sudden impacts.
- Clean the scale with a damp cloth; do not use abrasive cleaners or immerse it in water.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of batteries and the device in accordance with local regulations.

Package Contents

Verify that all items are present in the package:

- 1x Beurer GS 400 White Personal Scale
- 3x 1.5 V AAA Batteries
- 1x Instruction Manual (this document)

Setup

1. Battery Installation

1. Locate the battery compartment on the underside of the scale.
2. Open the battery compartment cover.
3. Insert the three (3) 1.5 V AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

2. Initial Placement

- Place the scale on a hard, flat, and stable surface. Avoid carpets or uneven flooring, as this can affect accuracy.
- Ensure the scale is not exposed to direct sunlight or extreme temperature changes.

Operating Instructions

1. Weighing Procedure (Quick Start Technology)

1. Gently tap the center of the scale with your foot to activate it. The display will show "0.0 kg" (or your selected unit).
2. Once "0.0 kg" is displayed, step onto the scale barefoot and stand still, distributing your weight evenly.
3. Your weight will be displayed for a few seconds. The scale will automatically switch off after use to conserve battery life.

2. Changing Weight Units

The Beurer GS 400 allows you to switch between different weight units (kilograms, pounds, or stones).

- Locate the unit conversion button on the back of the scale.
- Press this button to cycle through the available units: kg (kilograms), lb (pounds), and st (stones).
- The selected unit will be indicated on the display during weighing.

Maintenance and Care

- **Cleaning:** Clean the scale surface with a slightly damp cloth. Do not use harsh chemical cleaners or abrasive materials. Ensure no water enters the interior of the scale.
- **Storage:** Store the scale in a dry place, away from extreme temperatures and direct sunlight.
- **Battery Replacement:** When the battery indicator appears on the display, replace all three AAA batteries simultaneously. Do not mix old and new batteries.

Troubleshooting

Problem	Possible Cause	Solution
Display shows "Lo"	Low battery power.	Replace all three 1.5 V AAA batteries.
Display shows "Err" or "O-Ld"	Overload. The maximum weight capacity has been exceeded.	Step off the scale. The maximum capacity is 200 kg (440 lb / 31 st 6 lb).

Problem	Possible Cause	Solution
Inaccurate readings	Scale is on an uneven surface, or has been moved.	Place the scale on a hard, flat surface. Recalibrate by tapping the scale and waiting for "0.0" before stepping on.
No display	Batteries are incorrectly inserted or dead.	Check battery polarity or replace batteries.

Specifications

Model: Beurer GS 400 (73579)

Dimensions: 31 x 31 x 2.8 cm

Weight: 2.1 kg

Maximum Load Capacity: 200 kg (440 lb / 31 st 6 lb)

Graduation: 100 g (0.2 lb / 0.2 st)

Display: XL LCD, Digit height 39 mm

Units: kg / lb / st

Power Source: 3 x 1.5 V AAA batteries (included)

Features: Quick Start technology, Automatic switch-off, Overload indicator

Material: Super white 8mm safety glass platform

Manufacturer: Beurer

Warranty and Support

Beurer products are manufactured to the highest quality standards. For information regarding warranty terms and conditions, please refer to the warranty card included with your product or visit the official Beurer website.
For technical support, troubleshooting assistance, or spare parts, please contact Beurer customer service. Contact details can typically be found on the Beurer website or on the product packaging.
Beurer Official Website: www.beurer.com

© 2024 Beurer GmbH. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B081NVDZZ5

More documents and user manuals: **https://manuals.plus/**