Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lorex LHWF1006G32

Lorex LHWF1006G32 1080p Wire-Free Camera Recorder User Manual

Model: LHWF1006G32

1. Introduction

This manual provides comprehensive instructions for the Lorex LHWF1006G32 1080p 6-channel recorder, designed for use with Lorex wire-free cameras. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance of your security system. This recorder is compatible with Lorex LWB4800, LWB4900, LWB5800, and LWB6800 series wire-free cameras.

2. Package Contents

Verify that all components are present in your package:

- Lorex LHWF1006G32 6-Channel Recorder
- Power Adapter
- HDMI Cable
- USB Mouse
- Ethernet Cable
- Quick Start Guide

3. Device Overview

Familiarize yourself with the recorder's front and rear panels.



Figure 3.1: Front View of the Lorex LHWF1006G32 Recorder. This image displays the front of the recorder, highlighting the power and recording indicator lights, and the Lorex branding.



Figure 3.2: Rear View of the Lorex LHWF1006G32 Recorder. This image illustrates the connectivity options available on the back of the device, including video output, network, USB, and power ports.

Front Panel Indicators:

- **PWR (Power) LED:** Indicates the power status of the recorder.
- **REC (Record) LED:** Illuminates when the recorder is actively recording.

Rear Panel Ports:

- **HDMI:** Connects to a TV or monitor for video output.
- **LAN:** Ethernet port for network connection.
- **Mouse (USB):** Connects the included USB mouse for navigation.
- **Micro SD:** Slot for the internal 32GB microSD card for local storage.
- **Storage (USB):** Additional USB port for external storage or backup devices.
- **12V Power Input:** Connects the power adapter.

4. Setup

4.1 Initial Hardware Connection

1. Connect the included HDMI cable from the recorder's HDMI port to an HDMI input on your TV or monitor.
2. Connect the included USB mouse to the 'Mouse' USB port on the recorder.
3. For network access and remote viewing, connect an Ethernet cable from the recorder's LAN port to your router.
4. Connect the power adapter to the 12V Power Input port on the recorder, then plug the adapter into a power outlet. The recorder will power on automatically.

4.2 Pairing Wire-Free Cameras

The Lorex LHWF1006G32 recorder is designed for easy wireless connection with compatible Lorex wire-free cameras.

1. Ensure your wire-free camera is powered on and within range of the recorder.
2. On the recorder's interface (viewed on your connected monitor), navigate to the camera pairing settings.
3. Select the desired channel for the camera you wish to pair.
4. Press the 'Pair' button on your wire-free camera within 30 seconds of initiating the pairing process on the recorder.
5. A confirmation message will appear on the screen once pairing is successful. Repeat for additional cameras up to 6 channels.

4.3 Lorex Cirrus App Connection

To enable remote viewing and notifications, connect your recorder to the Lorex Cirrus app:

1. Download the Lorex Cirrus app from your smartphone or tablet's app store.
2. Create an account or log in if you already have one.
3. Follow the in-app instructions to add your LHWF1006G32 recorder. This typically involves scanning a QR code displayed on the recorder's monitor or manually entering its device ID.
4. Once connected, you can view live feeds, review past events, and receive motion detection notifications directly on your mobile device.

5. Operating Instructions

5.1 Recording

The LHWF1006G32 recorder captures video in 1080p HD resolution on all six channels. Recordings are stored locally on the integrated 32GB microSD card. The system is optimized for wire-free cameras, which typically record in short segments to conserve storage.

5.2 Viewing Live and Recorded Footage

- **Local Viewing:** Use the connected TV/monitor and USB mouse to navigate the recorder's interface. You can view live feeds from all connected cameras and access recorded footage via the playback menu.
- **Remote Viewing (Lorex Cirrus App):** Open the Lorex Cirrus app on your smartphone or tablet. Select your recorder to view live streams from your cameras. The app also provides an easy-to-read history timeline to review past motion events.

5.3 Motion Detection and Notifications

When connected to the Lorex Cirrus app, the system can send push notifications to your mobile device if a connected camera detects motion. Ensure motion detection settings are configured correctly within the recorder's

menu and the app.

6. Maintenance

6.1 General Care

- Keep the recorder in a well-ventilated area, away from direct sunlight, heat sources, and moisture.
- Clean the exterior with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- Ensure all cables are securely connected.

6.2 Storage Management

The recorder uses a 32GB microSD card for local storage. While wire-free cameras record efficiently, it is good practice to periodically review and manage stored footage. The system will typically overwrite the oldest recordings when the storage is full.

6.3 Firmware Updates

Periodically check the Lorex support website for available firmware updates for your LHWF1006G32 recorder. Firmware updates can improve performance, add new features, and enhance security. Follow the instructions provided with the update carefully.

7. Troubleshooting

7.1 No Video Output on Monitor

- Ensure the HDMI cable is securely connected to both the recorder and the monitor.
- Verify the monitor is set to the correct HDMI input source.
- Check if the recorder's power adapter is properly connected and the PWR LED is illuminated.

7.2 Camera Not Pairing

- Ensure the camera is powered on and within wireless range of the recorder.
- Confirm you are pressing the 'Pair' button on the camera within the 30-second window after initiating pairing on the recorder.
- Try resetting the camera and the recorder, then attempt pairing again.

7.3 Lorex Cirrus App Connectivity Issues

- Verify the recorder is connected to your network via the Ethernet cable and has internet access.
- Ensure your smartphone or tablet has a stable internet connection.
- Check if the Lorex Cirrus app is updated to the latest version.
- Restart both the recorder and your mobile device.

8. Specifications

Feature	Specification
Model Number	LHWF1006G32

Video Resolution	1080p HD
Channels	6 Channel
Internal Storage	32 GB (microSD)
Connectivity	Wired (LAN), Wireless (for cameras)
Video Output	HDMI
Compatible Cameras	Lorex LWB4800, LWB4900, LWB5800, LWB6800 series

9. Warranty and Support

9.1 Warranty Information

For detailed warranty information regarding your Lorex LHWF1006G32 recorder, please refer to the warranty card included with your product or visit the official Lorex website. Warranty terms and conditions may vary by region and product.

9.2 Technical Support

If you encounter issues not covered in this manual or require further assistance, please contact Lorex Technical Support. You can find contact information, FAQs, and additional resources on the official Lorex website: www.lorex.com/support

© 2023 Lorex Technology Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B081P8Z6J6

More documents and user manuals: **https://manuals.plus/**